NEW MEXICO OIL CONSERVATION COMMISSION Santa Fe, New Mexico

MISCELLANEOUS NOTICES IS A PORTION OF THE PROPERTY OF THE PROP

Submit this notice in TRIPLICATE to the District Office, Oil Conservation Commission, before the work specified is to begin. A copy will be

OUST HISH OCHORS IN CITE TECHNO	and Regulat	ons of the Commission.			ot begin until approval is ob	
		Indicate Nature of No	ice by Checki	ng Below		
Notice of Intention to Change Plans		Notice of Intention T Temporarily Abandon	WELL		Notice of Intention to Drill Deeper	
Notice of Intention to Pluo Well		Notice of Intention to Plug Back			Notice of Intention to Set Liner	
Notice of Intention to Squeeze		Notice of Intention to Acidize	x		Notice of Intention to Shoot (Nitro)	
Notice of Intention to Gun Perforate	x	Notice of Intention (Other)			Notice of Intention (Other)	
OIL CONSERVATION COM SANTA FE, NEW MEXICO	MISSION	Ros	well, New	Mexic	April 20,	1960
SANTA PE, NEW MEMICO		(P	lace)		(244)	
Gentlemen:						
Following is a Notice of I	ntention to	lo certain work as describe	d below at the			••••••
Shell	Odi Comp	anv S	tate A	,	Mali Na in	٠
(Comp	any or Operate	ž <u> </u>	37E	мрм	Denton-Devonian	Ро
(40-acre Subdivision)		, 1, r				
1. Kill well &	pull tul	w INSTRUCTIONS IN bing. Bridge Plug at 12,199', 12,210'	12 2651 &	esn W	/cement.	
3. Perforate 12 12,322 w/2- 4. Run tubing w to formation 5. Swab test.	-1/2" jet /packer n w/no or	wash perforation	ons and th	nen in	ject 1000 gallons 1	
3. Perforate 12 12,322' w/2- 4. Run tubing w to formation 5. Swab test. 6. If well will 7. Swab test an	-1/2" jet /packer: n w/no or not flund place	wash perforation werflush. Wash perforation werflush. The production on production.	ons and the	men in	ject 1000 gallons 1	5% MCA
3. Perforate 12 12,322 w/2- 4. Run tubing w to formation 5. Swab test. 6. If well will 7. Swab test an	-1/2" jet /packer: n w/no or not flund place	wash perforation werflush. Wash perforation werflush. The production on production.	ons and the	Shell	oil Company Company or Operator rigins	5% MCA
3. Perforate 12 12,322' w/2- 4. Run tubing w to formation 5. Swab test. 6. If well will 7. Swab test an	-1/2" jet /packer: n w/no or not flund place	wash perforation werflush. Wash perforation werflush. The production on production.	ons and the gallons 1!	Shell	oil Company	I Signed By

Shell Oil Company

Address Box 815, Roswell, New Mexico