

OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- _____	7. Unit Agreement Name
2. Name of Operator <b>Nucorp Energy, Inc.</b>	8. Farm or Lease Name <b>Mona Wilson</b>
3. Address of Operator <b>c/o Oil Reports &amp; Gas Services, Inc., Box 763, Hobbs, NM 88240</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>M</b> <b>990</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>21</b> TOWNSHIP <b>16S</b> RANGE <b>38E</b> NMPM.	10. Field and Pool, or Wildcat <b>Wildcat</b>
15. Elevation (Show whether LF, RT, GR, etc.) <b>3723 GR</b>	12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <u>Supplemental Well History</u> <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Perf 7940-44, 7956-71, 7992-8002, 8013-19, 8029-37, 8067-74, 8079-86 with 1 shot per foot. Treat with 4000 gal MCA, 5000 gal 7 1/2% acid, frac with 72,198 bbls fluid, 81,380# sand. Swab 100% water. Set CIBP at 7001. Perf 6450-62, 6514-20, 6575-94. Treat with 4000 gal 15% acid. Swab 90% water. Set CIBP at 6300. Perf 5410-16, 5496-5503, 5508-12, 5522-27, 5543-51. Treat with 2000 gal 15% acid, acid-frac with 15,000 gal gelled 15% acid, 20,000 gal WF-30 & 18,000# sand. Swab 95% water. Set CIBP at 5350 and cap with 30' cement. Perf 5060 with 2 shots per foot, squeeze with 135 sacks cement. Drilled out to 5061, perf 4977-5178 and treat with 2500 gals 15% NE acid. Swab 90% water

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Hernandez TITLE Agent DATE 8/11/80

APPROVED BY Jerry Hernandez TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: