

9) If hole is loaded, treat Abo perms. with 2000 gal.
15% H₂E acid

10) Swab Abo off

11) Return to production for packer leakage test

DM Jones
8/21/68