

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-101
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDY NOTICES AND REPORTS ON WELLS DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO CEMENT OR PLUG WELLS TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT WITH FORM C-101 FOR SUCH PROPOSALS.		5a. Indicate Type of Lease State ☐ Fee ☒				
2. Name of Operator TEXACO Inc.		5. State Oil & Gas Lease No. -				
3. Address of Operator P. O. Box 728 - Hobbs, New Mexico 88240		6. Farm or Lease Name H. T. Mattern				
4. Location of Well UNIT LETTER L 3300 FEET FROM THE North LINE AND 4620 FEET FROM THE East LINE, SECTION 20 TOWNSHIP 19-S RANGE 37-E N.M.P.M.		7. Unit Agreement Name -				
15. Elevation (Show whether DF, RT, GR, etc.) 3637' (GR)		8. Well No. 1				
16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data <table border="0"> <tr> <td> NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK ☐ TEMPORARILY ABANDON ☐ PULL OR ALTER CASING ☐ OTHER ☐ </td> <td> PLUG AND ABANDON ☐ CHANGE PLANS ☐ </td> <td> SUBSEQUENT REPORT OF: REMEDIAL WORK ☒ COMMENCE DRILLING OPNS. ☐ CASING TEST AND CEMENT JOBS ☐ OTHER ☐ </td> <td> ALTERING CASING ☐ PLUG AND ABANDONMENT ☐ </td> </tr> </table>		NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK ☐ TEMPORARILY ABANDON ☐ PULL OR ALTER CASING ☐ OTHER ☐	PLUG AND ABANDON ☐ CHANGE PLANS ☐	SUBSEQUENT REPORT OF: REMEDIAL WORK ☒ COMMENCE DRILLING OPNS. ☐ CASING TEST AND CEMENT JOBS ☐ OTHER ☐	ALTERING CASING ☐ PLUG AND ABANDONMENT ☐	9. Field and Pool, or Wildcat Eunice Monument Grayburg San Andres
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK ☐ TEMPORARILY ABANDON ☐ PULL OR ALTER CASING ☐ OTHER ☐	PLUG AND ABANDON ☐ CHANGE PLANS ☐	SUBSEQUENT REPORT OF: REMEDIAL WORK ☒ COMMENCE DRILLING OPNS. ☐ CASING TEST AND CEMENT JOBS ☐ OTHER ☐	ALTERING CASING ☐ PLUG AND ABANDONMENT ☐			
12. County Lea						

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1403.

1. Rigged up. Pulled rods and pump. Install BOP.
2. Clean out to 3965' (TD).
3. Perforate open hole w/2 JSPF @ 3836', 50', 60', 66', 72', 81', 91', 97', 3904' & 3910'.
4. Set pkr. @ 3750'. Acidize open-hole 3826-3968' w/2500 gals. 15% HCL NE acid & 1000# Rock Salt in 3 equal stages.
5. Install pumping equipment. Test & return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>John B. Brown</u>	TITLE Asst. Dist. Supt.	DATE 10-20-77
APPROVED BY <u>John B. Brown</u>	TITLE	DATE 10-21-1977
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

APR 11 1977

OIL CONSERVATION COMM.
HOBBS, N. M.