

**ATTACHMENT TO FORM C-105  
COLLINS & WARE, INC.  
GILL DEEP #1**

**26. Perforation Record.**

6526 - 6572	(56 holes)	ZR
6612 - 6673	(62 shots)	9/77 ZR
6175 - 6295	(35 holes)	10/96

**27. Treatment Record.**

6526 - 6572	AT with 3000 gals 15% NE acid.
6526 - 6572	AT with 1400 gals 15% NE acid. 9/75
6526 - 6572	FT with 21,000 gals UF-15 + 24,000# 20/40 sand. 9/75
6612 - 6673	AT with 5000 gals 15% BDA acid. 9/77
6612 - 6673	FT with 50,000 gals + 75,000# 20/40 sand. 9/77
6600	Set CIBP at 6600' with 10' cement on top. 9/87
6526 - 6572	AT with 2000 gals 15% NEFE acid. 9/87
6500	Set CIBP at 6500' with 5 sx cement on top.
6175 - 6295	AT with 2500 gals 15% Ferchek acid.
6175 - 6295	FT with 55,000 gals Delta Frac 25 + 150,000# 16/30 sand.