

OIL CONSERVATION DIVISION
P. O. BOX 2086
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-76

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.B.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO GELPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL ☒ GAS WELL ☐ OTHER ☐

Name of Operator
Anadarko Production Company

Address of Operator
P.O. Box 806 Eunice, New Mexico 88231

Location of Well
UNIT LETTER K, 1980 FEET FROM THE South LINE AND 1980 FEET FROM
West THE LINE, SECTION 22 TOWNSHIP 22S RANGE 37E NMPM.

7. Unit Agreement Name
LMPSU

8. Farm or Lease Name
Tract #4

9. Well No.
2

10. Field and Pool, or Whdcat
Langlie Mattix-Penrose

12. County
Lea

15. Elevation (Show whether DF, RT, GR, etc.)
Not Available

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

<p>PERFORM REMEDIAL WORK <input checked="" type="checkbox"/></p> <p>TEMPORARILY ABANDON <input type="checkbox"/></p> <p>PLUG OR ALTER CASING <input type="checkbox"/></p> <p>OTHER Run 5½" Liner & cement Top to Bottom <input type="checkbox"/></p>	<p>PLUG AND ABANDON <input type="checkbox"/></p> <p>CHANGE PLANS <input type="checkbox"/></p>	<p>REMEDIAL WORK <input type="checkbox"/></p> <p>COMMENCE DRILLING OPHS. <input type="checkbox"/></p> <p>CASING TEST AND CEMENT JOBS <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p>	<p>ALTERING CASING <input type="checkbox"/></p> <p>PLUG AND ABANDONMENT <input type="checkbox"/></p>
--	---	---	--

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- MIRUPU TOH w/ 2 7/8" tbg.
- RURU TIH w/ Cutrite shoe and mill off ragged csg @ 2300'. TOH w/ shoe & TIH w/ string mill. Clean up bad spot in 7" csg.
- TIH w/ 5½" csg (inside 7") to @ 3420'.
- TIH w/ umbrella bridge & set @ 3436' in OH Dump 4' of sand on top of bridge. Set 10' Cal-seal plug on top of sand.
- Tag up on Cal-seal plug w/ csg shoe.
- RU Halliburton & cement w/ sufficient Lite cement to circ hole. Upon Lite cement circulating pump 200 SX Class "C" w/ 2% CaCL as tail in & displace rubber plug to @ 3300'. WOC 24 hrs.
- RURU & drill out cement & plug. CO to TD. TOH w/ bit.
- Run production string & POP.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED BY Howard O. Schell TITLE Field Foreman DATE July 9, 1985

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

APPROVED BY _____ TITLE _____ DATE _____

REVISIONS OF APPROVAL, IF ANY:

2000-000

JUL 10 1965

1000-000