NO. OF COMIES PECLIACO	·		-	to .	Form C-103
	1				Supersedes Old C-102 and C-103
DISTRIBUTION	NEWMEXIC	TO OIL CONSI	ERVATION COMMISSION		Effective 1-1-65
SANTAFE	1	,0 014 00110			
r II.C				50	. Indicate Type of Lease
U.S.G.S.	-			1	State Tee XX
LAND OFFICE	4			5.	Store Oll & Goz Leose No.
CPERATOR					
					TTTTTTTTTTT
SUND:	RY HOTICES AND RI	EPORTS ON	VELLS CK TO A DIFFERENT RESERVOIR	. (	
LOO HOT USE THIS TO APPLICAT	TION TON PERMIT -" INCENT	C-101, rea sus	( rachusals.1		Unit Agreement Nume
1.					·
WELL XX WELL	OTHER.			ny	ers Langlie Mattix
z. Name of Operator				'	
Getty Oil Company					<u>ers Langlie Mattix</u> Well No.
3. Aldress of Operator					
P.O. Box 730 Hobbs, New Mexico 88240					207 Field and Fool, or Wildeat
5. Legation of Well			7.000	l l	
F 1	980 FERT FROM THE	North	LINE AND 1980	FEET FROM	anglie Mattix
West LINE, SECTION 12 TOWNSHIP 24S RANGE 36E NM					
West	12 TOWN	24S	RANGE 36E	нмрм.	
THECIRE, SECTI				\\	
THITTITITITITITITITITITITITITITITITITIT	15, Elevation	(Skow whether	DF, RT, CR, etc.)		County ()
	3226	6' DF			Lea (\\\\\\\\
16. Charle	Jensonista Boy To	Indicate N	ature of Notice, Repo	rt or Other	Data .
		marchie 10	subs	EQUENT R	EPORT OF:
NOTICE OF I	NTENTION TO:			•	
اسا			REMEDIAL WORK	$\Box$	ALTERING CASING
PERFORM REMEDIAL WORK	PLUG AKO	ABAHDON	COMMENCE DRILLING OPHS.	Ħ	PLUG AND ABAHDONMENT
TEMPORARILY ABANDON				. )=	
PULL OR ALTER CASING	CHANGE F	PLANS	CASING TEST AND CEMENT JO		ſ
Olympia labora como	nt around aga:	ing [	OTHER		
OTHER Circulate ceme			•		
17. Describe Proposed of Completed O	merations (Clearly state a	Il pertinent deta	ils, and give pertinent dates,	, including est	imated date of starting any propose
work) SEE RULE 1103.	•				
(1) Dia un nulli	na unit				
(1) Rig up pulling unit					
(2) Pull rods, pump and tubing. (3) Set retrievable bridge plug at 3000' and test casing.					
(4) Run free pipe log to find top of cement.					
(4) Run Tree pipe log to lind top of coment.					
(5) Perforate 2 holes at top of cement. (6) Establish circulation down casing and out bradenhead.					
(6) Establish Cl	reulation down	l Casing	determine com	ont 370111	ıme
(7) Pump 50 barrels color-dyed plug to determine cement volume.					
(8) Mix sufficient volume of cement to circulate to surface. (9) Displace cement within 100 feet of perforations.					
(9) Displace cem	ient within Iu	o reet o.	periorations.		
(10) W O C 24 hrs	•				
(11) Drill out ce		casing.			
(12) Pull bridge	plug.	•	1 1 1 1		
(13) Run tubing,	rods, and pum	p and pu	c well back to	հատեւսե.	
				eiclED.	
			CON MUST BE NO	INC WORK	•
	TH	IE COMMIS	SION MUST BE NOT RIOR TO COMMENC	HACK SAME	
·	24	HOURS P	SION MUST BE NO RIOR TO COMMENC		
18, I hereby certify that the information	n above is true and comple	ete to the best c	I my knowledge and belief.		
Michen Dale P. Contac	H (1117-T)	wAre	a Superintenden	<u>t</u>	B-18-77
11chrn. [](10 11. 676174	The state of the s	11100-22-03			
0	rig. Signor		•		4 6 9 1 <b>3/1/</b>
7,	STY SOXIOR				UATE
	Het L. Sopv.	TITLE			•
COMBITIONS OF APPROVAL, IF AN	YI				•

CIL CONSERVATORY COMM.