

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPlicate  
COPY TO BUREAU  
CONSERVATION

Form approved.  
Budget Bureau No. 42 R1424.

LEASE DESIGNATION AND SERIAL NO.

LC-062368 N-1-0137129

6. LEASEE, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

1. This form is to be used for notices and reports on wells, including a plug back to a different reservoir, or a change in the well's status. (See instructions on the reverse side.)

2. If the well is a water well, check the appropriate box.

3. Name of the owner or operator

TEXACO Inc.

4. Complete address of the owner or operator

P. O. Box 729 - Hobbs, New Mexico 88240

5. If the well is a water well, check the appropriate box. (See instructions on the reverse side.)

Well is located 1980' from North Line and 1650' from West line of Section 19, T-25-S, R-38-E, Unit Letter F.

6. If the well is a water well, check the appropriate box. (See instructions on the reverse side.)

Regular

3081' DF

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

C. E. Penny Fed. NCT-4

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Langlie Mattix

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 19, T-25-S, R-38-E

12. COUNTY OR PARISH 13. STATE

Lea

New Mexico

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NATURE OF INTENTION TO

SUBSEQUENT REPORT OF:

1. WATER SURFACE

2. REPAIR OR ALTER CASING

3. WATER SURFACE

4. REPAIRING WELL

5. REPAIR OR ALTER CASING

6. REPAIR OR ALTER CASING

7. REPAIR OR ALTER CASING

8. ALTERING CASING

9. REPAIR OR ALTER CASING

10. ABANDONMENT

11. SHOOTING OR CHANGING

12. ABANDONMENT\*

13. OTHER

14. OTHER

15. OTHER

Convert to injection (SWD)

Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

16. If the well is a water well, check the appropriate box. (See instructions on the reverse side.)

TEXACO Inc. proposed to do the following work on subject well:

1. Rig up Pulling Unit and tag bottom w/tubing.
2. Clean to TD (3,415') w/sand pump if necessary.
3. Run 2 7/8" plastic coated tubing w/Suibercon tension shorty packer and set at 3,230'.
4. Install wellhead equipment.
5. Connect to SWD line pipe and began injection.

17. I hereby certify that the foregoing is true and correct.

SIGNED

*[Signature]*

Assistant District

TITLE

Superintendent

DATE

11-9-70

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED  
NOV 13 1970  
*[Signature]*

\*See Instructions on Reverse Side