

## REENTRY OPERATIONS

1. Dig out cellar and install head & BOP.
2. Start drilling with a fresh water system.
3. Test BOP to 2000#.
4. Drill out surface plug.
5. Drill out plug @ 1260' - 1365'.
6. Test casing to 1500# for integrity.
7. Perforate Yates 7-Rivers sequence.
8. Acidize & frac perfs.
9. Install producing equipment.