

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

5. Lease Designation and Serial No.
MINI CC 32618A

6. If Indian, Allottee or Tribe Name

SUBMIT IN TRIPLICATE

7. If Unit or CA, Agreement Designation

1. Type of Well

Oil Well Gas Well Other

8. Well Name and No.

E.B. Egg A #6

2. Name of Operator

INVEST ENERGY CORPORATION

9. API Well No.

30025225450051

3. Address and Telephone No.

2401 Fountain View, Suite 700, Houston, TX 77057

10. Field and Pool, or Exploratory Area

WALMAT T-Y-SR

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit B
330' FNL & 1650' FEL, Sec. 35, T24S, R-36-E

11. County or Parish, State

LEA County
NEW MEXICO

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- Notice of Intent
 Subsequent Report
 Final Abandonment Notice

TYPE OF ACTION

- Abandonment
 Recompletion
 Plugging Back
 Casing Repair
 Altering Casing
 Other _____
- Change of Plans
 New Construction
 Non-Routine Fracturing
 Water Shut-Off
 Conversion to Injection
 Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) Notify BLM, prior to any work, @ (505) 393-3612
- 2) MI-RU Rig. POOH w/ PRODUCTION EGMT. LD ALL EXCEPT TBG.
- 3) GIM + SET CIBP @ 2880'. Spot 35' cement on top of CIBP w/ biter.
- 4) Displace hole w/ 9.00 spg mud.
- 5) Perforate, if necessary, to spot cement plug from 2845-2945 2580'. TAG PLUG.
- 6) Cut 5 1/2" CSG + pull from 422'
- 7) Set cement plug from 422 to 322'. TAG PLUG.
- 8) Set cement plug from 100' to surface.
- 9) Cut off CSG's. 4' below ground level. WELD ON PLATE + MARKER w/ I.D. SIGN.
- 10) Level + Restore Location.

14. I hereby certify that the foregoing is true and correct

Signed E. J. [Signature]

Title Agent

Date 2/4/92

(This space for Federal or State office use)

Approved by _____
Conditions of approval, if any:

Title PETROLEUM ENGINEER

Date 2/23/92

Well: I.B. Ogg A #6
 Formation: Yates
 TD: 3910' PBTD: 3140'
 Elevation: 3290' K.B.

