

Memo

From
ROY JOHNSON
Geologist

To

11-16-84

Recommended Plugging
Procedure.

Miles Minerals # 2-L

25 sacks TD. 2225'

25 sacks Top Sandia 1750'

25 sacks Top Perm 950 ?

25 sacks 575 50' in and out
of 7 5/8 casing shoe.

10 sack plug at surface.

10.0 lb/gal mud
between all plugs