

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
2040 Pacheco St.
Santa Fe, NM 87505

WELL API NO.
30-059-20148

5. Indicate Type of Lease
STATE FEE

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name
BDCDGU-1934

8. Well No.
331

9. Pool name or Wildcat
Tubb

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL GAS WELL OTHER C02

2. Name of Operator
Amoco Production Company

3. Address of Operator
PO Box 606, Clayton, NM 88415

4. Well Location
Unit Letter G : 1980 Feet From The North Line and 1980 Feet From The East Line
Section 33 Township 19N Range 34E NMPM Union County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
48' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK
TEMPORARILY ABANDON
PULL OR ALTER CASING
OTHER: Install Casing Liner

PLUG AND ABANDON
CHANGE PLANS

SUBSEQUENT REPORT OF:

REMEDIAL WORK
COMMENCE DRILLING OPNS.
CASING TEST AND CEMENT JOB
OTHER:

ALTERING CASING
PLUG AND ABANDONMENT

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

MIRUSU
RUN & SET 1.625 BLK PLG IN PROFILE NIP
BLEED DOWN TBG
NIPPLE UP BOP
REL ON/OFF TOOL
SWAB & BLOW WELL DRY
LAY DOWN FG TBG & ON/OFF TOOL OS
RUN POLYBORE GAUGE RING TO PKR
CHANGE RAMS IN BOP
RUN ON/OFF TOOL OS W/SW
LATCH ON TO PKR W/WS
RIG UP RIG ASSISTED SNUBBING UNIT
REL PKR
SNUB TBG, PKR, TAILPIPE OUT OF WELL
SHUT IN WELL W/BLIND RAMS
RIG DOWN SNUBBING UNIT
INSTALL SS WELLHEAD BONNET ON TOP OF BOP

SNUB AND POLYBORE PROCEDURE

INSTALL PRODUCTION EQUIPMENT
RWTP UP 5.5 STEEL CSG
PRODUCE FOR 12 TO 20 DAYS
MOVE IN RIG UP SERVICE UNIT
SHUT IN BOP-BLINDS
RUN BAKER WIRE LINE, SET INFLATTABLE BP
SET IBP ABOVE TOP PERF
BLEED CSG TO 0 PSI
RUN 9-31/8" DRILL COLLARS
RIG UP RRU
RUN POLYLINER TO INFLATTABLE BP
RUN 23/8" WORK STRING & PULL DRILL COLLARS
FUSE ON WELLHEAD FLANGE
INSTALL SS ADAPTER
RETRIEVE IBP WITH WIRELINE
RWTP
RDMOSU

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Billy E. Prichard TITLE Field Foreman DATE 2/27/97

TYPE OR PRINT NAME Billy E Prichard TELEPHONE NO. 374-3053

(This space for State Use)

APPROVED BY Ry E Johnson TITLE DISTRICT SUPERVISOR DATE 3/17/97

CONDITIONS OF APPROVAL, IF ANY