

AP - 2

STAGE 1 & 2

REPORTS
(APPENDIX V)

DATE:

MAY 2003

APPENDIX V

Westgate Walk-A-Round Air Monitoring Data

March – October 2002

Westgate Stage 2 Abatement Plan- Remediation Activities Report Hobbs, New Mexico

Prepared for:
Shell Exploration & Production Company
Houston, Texas

May 2003

Prepared by:
BBC International, Inc.

WESTGATE SUBDIVISION GRIMES BATTERY & TASKER ROAD

Stage 2 Abatement Plan Soil Remediation Activities Report

May 2003

RECEIVED

MAY 30 2003

ENVIRONMENTAL BUREAU
OIL CONSERVATION DIVISION

**SHELL EXPLORATION & PRODUCTION COMPANY
HOUSTON, TEXAS**

Prepared By:

**BBC International, Inc.
Hobbs, New Mexico**



Westgate Air Monitoring Westgate Neighborhood

Date: 4-15-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:15	9:17	9:20	9:24	9:28	9:33
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 4-15-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	5:20	5:23	5:27	5:30
Foxboro TVA 1000	PID 0.03 ppm	PID 0.98 ppm	PID 0.04 ppm	PID 1.31 ppm
	FID 0.10 ppm	FID 1.32 ppm	FID 0.07 ppm	FID 1.96 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:35
Foxboro TVA 1000	PID 2.73 ppm
	FID 7.17 ppm
Cal.	
Mini RAE 2000	PID 3.2 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.216 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
Time	9:15	9:18	9:22	9:27	9:32	9:35
Foxboro TVA 1000	PID 0.09 ppm	PID 0.07 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.13 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
IME PDR 1000	Conc. 0.011 Mg/m ³	Conc. 0.072 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 4-16-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:50	4:53	4:56	5:00	5:04	5:09
Foxboro TVA 1000	PID 0.13 ppm	PID 0.00 ppm	PID 0.11 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.07 ppm	FID 0.00 ppm	FID 0.07 ppm	FID 0.00 ppm	FID 0.03 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 4-16-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	5:13	5:16	5:20	5:23
Foxboro TVA 1000	PID 0.02 ppm	PID 1.08 ppm	PID 0.07 ppm	PID 1.45 ppm
	FID 0.00 ppm	FID 5.60 ppm	FID 0.00 ppm	FID 6.30 ppm
Cal.				
Mini RAE 2000	PID 0.1 ppm	PID 2.5 ppm	PID 0.0 ppm	PID 3.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:30
Foxboro TVA 1000	PID 3.90 ppm
	FID 14.00 ppm
Cal.	
Mini RAE 2000	PID 5.9 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.331 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-17-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	9:20		9:23		9:26		9:30		9:34		9:40	
Foxboro TVA 1000	PID	0.00 ppm			PID	0.00 ppm	PID	0.09 ppm	PID	0.11 ppm	PID	0.00 ppm
	FID	0.00 ppm	FID	0.00 ppm	FID	0.00 ppm	FID	0.72 ppm	FID	0.69 ppm	FID	0.00 ppm
Cal.												
Mini RAE 2000	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm
Cal.												
Jerome 431-X		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³
Jerome 631-X		.000 H ₂ S ppm		.000 H ₂ S ppm		.001 H ₂ S ppm		.001 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm
Gastech GT 201		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL
		0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm
		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂
Cal.												
MIE PDR 1000	Conc.	0.029 Mg/m ³	Conc.	0.173 Mg/m ³	Conc.	0.000 Mg/m ³	Conc.	0.453 Mg/m ³	Conc.	0.112 Mg/m ³	Conc.	0.333 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 4-17-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:35	3:40	3:43	3:48	3:52	3:55
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 4-17-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:00	4:03	4:05	4:08
Foxboro TVA 1000	PID 0.07 ppm	PID 0.97 ppm	PID 0.02 ppm	PID 1.31 ppm
	FID 0.04 ppm	FID 2.13 ppm	FID 0.06 ppm	FID 3.06 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:15
Foxboro TVA 1000	PID 3.98 ppm
	FID 12.42 ppm
Cal.	
Mini RAE 2000	PID 6.1 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.004 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.306 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
Time	10:05	10:10	10:13	10:17	10:20	10:23
Foxboro TVA 1000	PID 0.01 ppm	0.07	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.03 ppm
	FID 0.00 ppm	FID 0.01 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.007 Mg/m ³	Conc. 0.072 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 4-18-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	3:45		3:48		3:52		3:55		3:58		4:03	
Foxboro TVA 1000	PID	0.00 ppm	0.11		PID	0.00 ppm	PID	0.00 ppm	PID	0.00 ppm	PID	0.00 ppm
	FID	0.00 ppm	FID	0.03 ppm	FID	0.00 ppm	FID	0.00 ppm	FID	0.01 ppm	FID	0.00 ppm
Cal.												
Mini RAE 2000	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm
Cal.												
Jerome 431-X		.000 Hg Mg/m ³	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X		.000 H ₂ S ppm	.001 H ₂ S ppm		.000 H ₂ S ppm		.002 H ₂ S ppm		.002 H ₂ S ppm		.001 H ₂ S ppm	
Gastech GT 201		000 % LEL	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
		0000 ppm	0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
		20.9 %O ₂	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc.	0.007 Mg/m ³	Conc.	0.000 Mg/m ³	Conc.	0.001 Mg/m ³	Conc.	0.000 Mg/m ³	Conc.	0.009 Mg/m ³	Conc.	0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 4-18-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:10	4:13	4:17	4:20
Foxboro TVA 1000	PID 0.00 ppm	PID 0.11 ppm	PID 0.05 ppm	PID 0.09 ppm
	FID 0.00 ppm	FID 0.07 ppm	FID 0.01 ppm	FID 0.03 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:25
Foxboro TVA 1000	PID 0.16 ppm
	FID 0.11 ppm
Cal.	
Mini RAE 2000	PID 0.2 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.072 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-19-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:20	9:23	9:27	9:30	9:33	9:37
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.01 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.01 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.004 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



4-19-02

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 4-19-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	3:10	3:13	3:17	3:18
Foxboro TVA 1000	PID 0.07 ppm	PID 0.10 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.30 ppm	FID 0.60 ppm	FID 0.02 ppm	FID 0.00 ppm
Cal.				
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	3:25
Foxboro TVA 1000	PID 0.17 ppm
	FID 0.10 ppm
Cal.	
Mini RAE 2000	PID 0.2 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-22-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	10:10		10:13		10:17		10:20		10:24		10:28	
Foxboro TVA 1000	PID 0.01 ppm		0.00		PID 0.03 ppm		PID 0.01 ppm		PID 0.00 ppm		PID 0.03 ppm	
	FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.01 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.001 H ₂ S ppm		.000 H ₂ S ppm		.001 H ₂ S ppm		.002 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm	
Gastech GT 201	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
	0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.001 Mg/m ³		Conc. 0.001 Mg/m ³		Conc. 0.007 Mg/m ³	

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 4-22-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:40	4:43	4:46	4:50	4:53	4:57
Foxboro TVA 1000	PID 0.09 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.04 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.002 H ₂ S ppm	.002 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 4-22-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.01 ppm	PID 0.06 ppm	PID 0.00 ppm	PID 0.07 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.01 ppm
Cal.				
Mini RAE 2000	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.00 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-23-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:15	9:18	9:22	9:27	9:30	9:33
Foxboro TVA 1000	PID 0.00 ppm	0.01	PID 0.07 ppm	PID 0.01 ppm	PID 0.07 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.42 ppm	FID 0.13 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.011 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



4-23-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:05	4:10	4:13	4:17	4:20	4:24
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.01 ppm	PID 0.06 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.001 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 4-23-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:30	4:33	4:36	4:40
Foxboro TVA 1000	PID 0.47 ppm	PID 0.66 ppm	PID 0.10 ppm	PID 0.17 ppm
	FID 1.21 ppm	FID 0.97 ppm	FID 0.03 ppm	FID 0.00 ppm
Cal.				
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:45
Foxboro TVA 1000	PID 0.67 ppm
	FID 0.23 ppm
Cal.	
Mini RAE 2000	PID 0.3 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.111 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-24-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:50	9:54	9:58	10:03	10:06	10:10
Foxboro TVA 1000	PID 0.11 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.62 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.213 Mg/m ³	Conc. 0.079 Mg/m ³	Conc. 0.119 Mg/m ³	Conc. 0.106 Mg/m ³	Conc. 0.071 Mg/m ³	Conc. 0.016 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 4-24-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:20	3:23	3:27	3:30	3:34	3:38
Foxboro TVA 1000	PID 0.00 ppm	0.09	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.01 ppm	FID 0.13 ppm	FID 0.16 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.076 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 4-24-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	3:44	3:47	3:50	3:52
Foxboro TVA 1000	PID 0.13 ppm	PID 0.00 ppm	PID 0.17 ppm	PID 0.21 ppm
	FID 1.16 ppm	FID 1.00 ppm	FID 0.64 ppm	FID 0.13 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	3:57
Foxboro TVA 1000	PID 0.06 ppm
	FID 0.92 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³

Date: 4-25-02[illegible]



4-25-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:14	4:22	4:31	4:42	4:48	4:57
Foxboro TVA 1000	PID 0.04 ppm	0.06	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.03 ppm
	FID 1.24 ppm	FID 1.23 ppm	FID 1.15 ppm	FID 1.25 ppm	FID 1.27 ppm	FID 0.98 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 4-25-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	5:00	5:04	5:08	5:15
Foxboro TVA 1000	PID 0.05 ppm	PID 0.13 ppm	PID 0.06 ppm	PID 0.31 ppm
	FID 0.12 ppm	FID 2.00 ppm	FID 0.27 ppm	FID 1.18 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:25
Foxboro TVA 1000	PID 0.36 ppm
	FID 1.33 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.015 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.202 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-26-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:50	10:05	10:11	10:16	10:23	10:30
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 2.42 ppm	FID 1.92 ppm	FID 1.32 ppm	FID 0.85 ppm	FID 1.59 ppm	FID 1.94 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	21.0 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

light wind from s.w.



Westgate Air Monitoring Westgate Neighborhood

Date: 4-26-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:26	3:34	3:44	3:55	4:01	4:10
Foxboro TVA 1000	PID 0.04 ppm	0.02	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 1.24 ppm	FID 1.62 ppm	FID 1.33 ppm	FID 1.32 ppm	FID 1.19 ppm	FID 0.89 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0040 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.8 %O ₂	20.7 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

light wind from s.w.



Westgate Air Monitoring Air Filtration System

Date: 4-26-02

	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:15	4:16	4:18	4:20
Foxboro TVA 1000	PID 0.06 ppm	PID 0.12 ppm	PID 0.02 ppm	PID 0.22 ppm
	FID 1.55 ppm	FID 1.35 ppm	FID 1.15 ppm	FID 2.52 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.3 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure		
Time	4:33		
Foxboro TVA 1000	PID	0.20	ppm
	FID	1.30	ppm
Cal.			
Mini RAE 2000	PID	0.4	ppm
Cal.			
Jerome 431-X	.000	Hg	Mg/m ³
Jerome 631-X	.023	H ₂ S	ppm
Gastech GT 201			
	000	%	LEL
	0000		ppm
	20.8	%	O ₂
Cal.			
MIE PDR 1000	Conc.	0.000	Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-29-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	10:29	10:35	10:40	10:45	10:50	10:58
Foxboro TVA 1000	PID 0.60 ppm	0.59	PID 0.59 ppm	PID 0.54 ppm	PID 0.51 ppm	PID 0.50 ppm
	FID 1.54 ppm	FID 1.32 ppm	FID 1.31 ppm	FID 0.92 ppm	FID 0.77 ppm	FID 0.90 ppm
Cal. 4-29-02						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal. 4-29-02						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments:	wind from the west at 10-13 mph					



4-29-02

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 4-29-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	3:30	3:32	3:34	3:36
Foxboro TVA 1000	PID 0.76 ppm	PID 0.87 ppm	PID 0.14 ppm	PID 0.68 ppm
	FID 0.97 ppm	FID 1.50 ppm	FID 0.71 ppm	FID 1.53 ppm
Cal. 4-29-02				
Mini RAE 2000	PID 0.3 ppm	PID 0.5 ppm	PID 0.0 ppm	PID 0.3 ppm
Cal. 4-29-02				
Comment: Winds calm				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.30 ppm
	FID 0.00 ppm
Cal. 4-29-02	
Mini RAE 2000	PID 0.0 ppm
Cal. 4-29-02	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.012 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-30-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	11:25	11:30	11:35	11:40	11:44	11:48
Foxboro TVA 1000	PID 0.06 ppm	0.05	PID 0.05 ppm	PID 0.03 ppm	PID 0.03 ppm	PID 0.01 ppm
	FID 1.20 ppm	FID 1.78 ppm	FID 0.72 ppm	FID 1.63 ppm	FID 1.23 ppm	FID 0.40 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

Windy. Winds from the west at 16mph.



Westgate Air Monitoring Westgate Neighborhood

Date: 4-30-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:00	3:10	3:15	3:20	3:27	3:35
Foxboro TVA 1000	PID 0.03 ppm	0.04	PID 0.03 ppm	PID 0.01 ppm	PID 0.01 ppm	PID 0.00 ppm
	FID 1.40 ppm	FID 1.45 ppm	FID 1.82 ppm	FID 1.63 ppm	FID 1.28 ppm	FID 0.75 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.8 %O ₂	20.8 %O ₂	20.8 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.085 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments:	Wind speed 20-25 mph out of the west.					



Westgate Air Monitoring Air Filtration System

Date: 4-30-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	3:50	3:53	3:40	3:45
Foxboro TVA 1000	PID 0.05 ppm	PID 0.33 ppm	PID 0.06 ppm	PID 0.36 ppm
	FID 0.32 ppm	FID 2.09 ppm	FID 0.39 ppm	FID 1.22 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.37 ppm
	FID 1.56 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.015 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.392 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-1-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	10:36	10:41	10:47	10:52	10:57	11:04
Foxboro TVA 1000	PID 0.08 ppm	0.08	PID 0.05 ppm	PID 0.04 ppm	PID 0.03 ppm	PID 0.04 ppm
	FID 1.86 ppm	FID 1.88 ppm	FID 1.98 ppm	FID 1.77 ppm	FID 0.99 ppm	FID 1.67 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.009 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.033 Mg/m ³	Conc. 0.340 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

Wind speed 20 mph out of the west.



Westgate Air Monitoring Westgate Neighborhood

Date: 5-1-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	2:55	3:00	3:06	3:10	3:14	3:19
Foxboro TVA 1000	PID 0.11 ppm	0.10	PID 0.09 ppm	PID 0.09 ppm	PID 0.08 ppm	PID 0.08 ppm
	FID 2.62 ppm	FID 2.52 ppm	FID 1.92 ppm	FID 2.02 ppm	FID 2.11 ppm	FID 1.89 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.094 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.032 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

Wind speed 22 mph out of the west.



Westgate Air Monitoring Air Filtration System

Date: 5-1-02

	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	3:25	3:27	3:29	3:30
Foxboro TVA 1000	PID 0.15 ppm	PID 0.40 ppm	PID 0.15 ppm	PID 0.53 ppm
	FID 1.85 ppm	FID 2.42 ppm	FID 1.53 ppm	FID 2.25 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.3 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	3:35
Foxboro TVA 1000	PID 0.21 ppm
	FID 1.92 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.015 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.235 Mg/m ³



5-2-02

[illegible]



5-2-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
Foxboro TVA 1000	PID 4:43 0.18 ppm	4:48 0.16	4:53 PID 0.16 ppm	4:58 PID 0.14 ppm	5:02 PID 0.12 ppm	5:10 PID 0.12 ppm
	FID 3.23 ppm	FID 2.49 ppm	FID 1.97 ppm	FID 3.23 ppm	FID 2.40 ppm	FID 2.51 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.005 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments:						



Westgate Air Monitoring Air Filtration System

Date: 5-2-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	5:14	5:15	5:17	5:19
Foxboro TVA 1000	PID 0.15 ppm	PID 0.35 ppm	PID 0.17 ppm	PID 0.33 ppm
	FID 2.55 ppm	FID 3.03 ppm	FID 1.90 ppm	FID 3.36 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
5:20	
Foxboro TVA 1000	PID 0.32 ppm
	FID 2.68 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.016 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.016 Mg/m ³



Date: 5-3-02

[illegible]



Westgate Air Monitoring Westgate Neighborhood

Date: 5-3-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:02	4:06	4:14	4:19	4:26	4:31
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.10 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.002 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

Wind speed 6 mph out of the southwest.



Westgate Air Monitoring Air Filtration System

Date: 5-3-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:36	4:37	4:38	4:40
Foxboro TVA 1000	PID 0.75 ppm	PID 0.22 ppm	PID 0.03 ppm	PID 0.52 ppm
	FID 0.00 ppm	FID 0.32 ppm	FID 0.42 ppm	FID 0.92 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.4 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:46
Foxboro TVA 1000	PID 0.27 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.192 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-6-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	2:10	2:15	2:20	2:24	2:27	2:33
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal. 5-6-02						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal. 5-6-02						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 5-6-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:43	4:49	4:55	5:00	5:05	5:10
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.006 Mg/m ³

Comments:

Wind speed 29 mph out of the southwest.



Westgate Air Monitoring Air Filtration System

Date: 5-6-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.00 ppm FID 0.00 ppm	PID 0.18 ppm FID 0.42 ppm	PID 0.05 ppm FID 0.00 ppm	PID 0.18 ppm FID 0.00 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.5 ppm	PID 0.0 ppm	PID 0.3 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.13 ppm FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.9 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.033 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-7-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	10:00		10:04		10:09		10:14		10:19		10:23	
Foxboro TVA 1000	PID 0.04 ppm		0.04		PID 0.06 ppm		PID 0.00 ppm		PID 0.01 ppm		PID 0.00 ppm	
	FID 0.87 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.14 ppm		FID 0.00 ppm		FID 0.00 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.002 H ₂ S ppm		.002 H ₂ S ppm		.002 H ₂ S ppm		.001 H ₂ S ppm		.001 H ₂ S ppm		.001 H ₂ S ppm	
Gastech GT 201	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
	0000 ppm		0002 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.000 Mg/m ³		Conc. 0.009 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³	

Comments:

Wind speed 20 mph out of the west.



Westgate Air Monitoring Westgate Neighborhood

Date: 5-7-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	4:30		4:35		4:40		4:45		4:50		4:56	
Foxboro TVA 1000	PID 0.01 ppm		0.00		PID 0.12 ppm		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm	
	FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.001 H ₂ S ppm		.001 H ₂ S ppm		.001 H ₂ S ppm		.002 H ₂ S ppm		.001 H ₂ S ppm		.002 H ₂ S ppm	
Gastech GT 201	.000 % LEL		.000 % LEL		.000 % LEL		.000 % LEL		.000 % LEL		.000 % LEL	
	.0000 ppm		.0000 ppm		.0000 ppm		.0000 ppm		.0000 ppm		.0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.013 Mg/m ³		Conc. 0.023 Mg/m ³		Conc. 0.024 Mg/m ³		Conc. 0.119 Mg/m ³		Conc. 0.139 Mg/m ³		Conc. 0.186 Mg/m ³	

Comments:

Wind speed 27 mph out of the southwest.



Westgate Air Monitoring Air Filtration System

Date: 5-7-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.00 ppm FID 0.00 ppm	PID 0.22 ppm FID 0.46 ppm	PID 0.00 ppm FID 0.00 ppm	PID 0.23 ppm FID 0.49 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.9 ppm	PID 0.0 ppm	PID 0.8 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.26 ppm FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.4 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.004 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.340 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-8-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	10:50	10:54	10:59	11:02	11:08	11:13
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

Wind speed 19 mph out of the southwest.



Westgate Air Monitoring Westgate Neighborhood

Date: 5-8-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:30	4:35	4:40	4:45	4:50	4:55
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.034 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.177 Mg/m ³	Conc. 0.526 Mg/m ³	Conc. 0.032 Mg/m ³	Conc. 0.105 Mg/m ³

Comments:

Wind speed 24 mph out of the southwest.



Westgate Air Monitoring Air Filtration System

Date: 5-8-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.00 ppm	PID 0.09 ppm	PID 0.00 ppm	PID 0.07 ppm
	FID 0.00 ppm	FID 0.60 ppm	FID 0.00 ppm	FID 0.23 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.2 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.26 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.5 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.476 Mg/m ³



5-9-02

Wind speed 15 mph out of the northeast.



Westgate Air Monitoring Westgate Neighborhood

Date: 5-9-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:43	4:48	4:52	4:56	4:59	5:03
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.178 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.123 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

Wind speed 8 mph out of the southeast.



Westgate Air Monitoring Air Filtration System

Date: 5-9-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	5:07	5:09	5:11	5:14
Foxboro TVA 1000	PID 0.00 ppm	PID 0.08 ppm	PID 0.00 ppm	PID 0.07 ppm
	FID 0.00 ppm	FID 0.57 ppm	FID 0.00 ppm	FID 0.23 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.2 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:11
Foxboro TVA 1000	PID 0.24 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.5 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.330 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-10-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	11:37	11:41	11:45	11:49	11:54	11:58
Foxboro TVA 1000	PID 1.74 ppm	1.28	PID 0.70 ppm	PID 0.83 ppm	PID 0.70 ppm	PID 0.78 ppm
	FID 0.70 ppm	FID 0.10 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

Wind speed 17 mph out of the southeast.



Westgate Air Monitoring Westgate Neighborhood

Date: 5-10-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:58	4:01	4:05	4:09	4:14	4:17
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

Wind speed 10 mph out of the southeast.



Westgate Air Monitoring Air Filtration System

Date: 5-10-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:20	4:23	4:25	4:27
Foxboro TVA 1000	PID 0.00 ppm	PID 0.07 ppm	PID 0.00 ppm	PID 0.06 ppm
	FID 0.00 ppm	FID 0.48 ppm	FID 0.00 ppm	FID 0.20 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:30
Foxboro TVA 1000	PID 0.52 ppm
	FID 1.77 ppm
Cal.	
Mini RAE 2000	PID 1.3 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.142 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-16-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:11	4:15	4:19	4:22	4:25	4:28
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.55 ppm	FID 0.33 ppm	FID 0.39 ppm	FID 0.98 ppm	FID 0.21 ppm	FID 0.09 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.138 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 5-16-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:30	4:32	4:34	4:37
Foxboro TVA 1000	PID 0.09 ppm	PID 0.37 ppm	PID 0.12 ppm	PID 0.36 ppm
	FID 0.12 ppm	FID 0.12 ppm	FID 0.00 ppm	FID 0.10 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:42
Foxboro TVA 1000	PID 0.13 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.024 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.356 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-17-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:10	4:15	4:22	4:28	4:33	4:42
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.35 ppm	FID 0.32 ppm	FID 0.41 ppm	FID 0.74 ppm	FID 0.28 ppm	FID 0.20 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 5-17-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:45	4:47	4:50	4:54
Foxboro TVA 1000	PID 0.06 ppm	PID 0.16 ppm	PID 0.11 ppm	PID 0.27 ppm
	FID 0.13 ppm	FID 0.12 ppm	FID 0.00 ppm	FID 0.09 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:00
Foxboro TVA 1000	PID 0.13 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.012 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.012 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-20-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:45	3:50	3:54	3:59	4:03	4:08
Foxboro TVA 1000	PID 0.19 ppm	0.00	PID 0.00 ppm	PID 0.89 ppm	PID 0.19 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 1.07 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.084 Mg/m ³	Conc. 0.070 Mg/m ³	Conc. 0.119 Mg/m ³	Conc. 0.177 Mg/m ³	Conc. 0.172 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

Winds from the southeast at 22 mph.



Westgate Air Monitoring Air Filtration System

Date: 5-20-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.05 ppm FID 0.32 ppm	PID 0.33 ppm FID 2.09 ppm	PID 0.06 ppm FID 0.39 ppm	PID 0.36 ppm FID 1.20 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.13 ppm FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.024 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.356 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-21-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:15	4:19	4:24	4:30	4:34	4:38
Foxboro TVA 1000	PID 0.22 ppm	0.21	PID 0.17 ppm	PID 0.18 ppm	PID 0.07 ppm	PID 0.19 ppm
	FID 0.97 ppm	FID 0.90 ppm	FID 0.09 ppm	FID 0.07 ppm	FID 0.19 ppm	FID 0.05 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.198 Mg/m ³	Conc. 0.189 Mg/m ³	Conc. 0.176 Mg/m ³	Conc. 0.179 Mg/m ³	Conc. 0.192 Mg/m ³	Conc. 0.181 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 5-21-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:41	4:43	4:46	4:51
Foxboro TVA 1000	PID 0.04 ppm	PID 0.29 ppm	PID 0.06 ppm	PID 0.37 ppm
	FID 0.28 ppm	FID 2.00 ppm	FID 0.17 ppm	FID 1.20 ppm
Cal.				
Mini RAE 2000	PID 0.2 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:56
Foxboro TVA 1000	PID 0.30 ppm
	FID 0.44 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.533 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-22-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:18	4:22	4:27	4:32	4:37	4:43
Foxboro TVA 1000	PID 0.11 ppm	0.12	PID 0.09 ppm	PID 0.29 ppm	PID 0.17 ppm	PID 0.08 ppm
	FID 0.17 ppm	FID 0.20 ppm	FID 0.04 ppm	FID 0.36 ppm	FID 0.22 ppm	FID 0.03 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.102 Mg/m ³	Conc. 1.107 Mg/m ³	Conc. 0.109 Mg/m ³	Conc. 0.112 Mg/m ³	Conc. 0.107 Mg/m ³	Conc. 0.115 Mg/m ³

Comments:

Winds out of the south at 20 mph.



Westgate Air Monitoring Air Filtration System

Date: 5-22-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.03 ppm FID 0.20 ppm	PID 0.19 ppm FID 0.00 ppm	PID 0.04 ppm FID 0.20 ppm	PID 0.22 ppm FID 1.09 ppm
Cal.				
Mini RAE 2000	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.27 ppm FID 0.09 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.340 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-23-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	4:10		4:15		4:21		4:26		4:31		4:37	
Foxboro TVA 1000	PID 0.07 ppm		0.12		PID 0.04 ppm		PID 0.03 ppm		PID 0.00 ppm		PID 0.09 ppm	
	FID 0.04 ppm		FID 0.03 ppm		FID 0.06 ppm		FID 0.07 ppm		FID 0.00 ppm		FID 0.04 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm	
Gastech GT 201	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
	0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.120 Mg/m ³		Conc. 0.100 Mg/m ³		Conc. 0.104 Mg/m ³		Conc. 0.012 Mg/m ³		Conc. 0.103 Mg/m ³		Conc. 0.009 Mg/m ³	

Comments:

Southwest winds at 13 mph.



Westgate Air Monitoring Air Filtration System

Date: 5-23-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID ppm	PID ppm	PID 0.03 ppm	PID 0.22 ppm
	FID ppm	FID ppm	FID 0.18 ppm	FID 0.84 ppm
Cal.				
Mini RAE 2000	PID ppm	PID ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.27 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.321 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-24-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:32	3:38	3:42	3:47	3:52	3:57
Foxboro TVA 1000	PID 0.09 ppm	0.02	PID 0.03 ppm	PID 0.01 ppm	PID 0.08 ppm	PID 0.02 ppm
	FID 0.03 ppm	FID 0.04 ppm	FID 0.08 ppm	FID 0.04 ppm	FID 0.12 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.102 Mg/m ³	Conc. 0.092 Mg/m ³	Conc. 0.102 Mg/m ³	Conc. 0.008 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.001 Mg/m ³

Comments

Southwest winds at 11 mph.



Westgate Air Monitoring Air Filtration System

Date: 5-24-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID ppm	PID ppm	PID 0.02 ppm	PID 0.20 ppm
	FID ppm	FID ppm	FID 0.15 ppm	FID 0.76 ppm
Cal.				
Mini RAE 2000	PID ppm	PID ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.24 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.341 Mg/m ³

[illegible]



Westgate Air Monitoring Westgate Neighborhood

Date: 6-17-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	4:45		4:48		4:50		4:52		4:55		4:58	
Foxboro TVA 1000	PID 0.05 ppm		0.05		PID 0.03 ppm		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm	
	FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.010 Hg Mg/m ³		.005 Hg Mg/m ³		.005 Hg Mg/m ³		.005 Hg Mg/m ³		.004 Hg Mg/m ³		.004 Hg Mg/m ³	
Jerome 631-X	.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm	
Gastech GT 201	.000 % LEL		.000 % LEL		.000 % LEL		.000 % LEL		.000 % LEL		.000 % LEL	
	.0000 ppm		.0000 ppm		.0000 ppm		.0000 ppm		.0000 ppm		.0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³	

Comments:



Westgate Air Monitoring Air Filtration System

Date: 6-17-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	5:02	5:05	5:08	5:10
Foxboro TVA 1000	PID 0.24 ppm	PID 0.48 ppm	PID 0.21 ppm	PID 0.23 ppm
	FID 0.45 ppm	FID 0.89 ppm	FID 0.33 ppm	FID 0.42 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:20
Foxboro TVA 1000	PID 0.10 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.005 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 6-18-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:28	9:33	9:36	9:42	9:46	9:49
Foxboro TVA 1000	PID 3.71 ppm	2.57	PID 1.67 ppm	PID 1.37 ppm	PID 1.04 ppm	PID 1.20 ppm
	FID 0.37 ppm	FID 0.43 ppm	FID 0.39 ppm	FID 0.18 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.003 Hg Mg/m ³	.005 Hg Mg/m ³	.004 Hg Mg/m ³	.004 Hg Mg/m ³	.003 Hg Mg/m ³	.003 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

Winds out of south southeast at 13 mph.



Westgate Air Monitoring Westgate Neighborhood

Date: 6-18-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:58	5:03	5:06	5:08	5:12	5:15
Foxboro TVA 1000	PID 0.02 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.8 %O ₂	20.8 %O ₂	20.8 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

Winds from the south at 15 mph.



Westgate Air Monitoring Air Filtration System

Date: 6-18-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.61 ppm FID 0.00 ppm	PID 6.12 ppm FID 28.17 ppm	PID 0.57 ppm FID 0.03 ppm	PID 5.89 ppm FID 27.78 ppm
Cal.				
Mini RAE 2000	PID 0.6 ppm	PID 20.3 ppm	PID 0.5 ppm	PID 19.9 ppm
Cal.				
Comments:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 14.26 ppm FID 49.22 ppm
Cal.	
Mini RAE 2000	PID 23.7 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.027 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	0180 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.541 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 6-19-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:15	9:22	9:27	9:35	9:40	9:44
Foxboro TVA 1000	PID 2.06 ppm	1.97	PID 0.46 ppm	PID 1.03 ppm	PID 1.07 ppm	PID 0.11 ppm
	FID 1.46 ppm	FID 2.00 ppm	FID 0.17 ppm	FID 0.18 ppm	FID 0.21 ppm	FID 0.07 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.016 Mg/m ³	Conc. 0.022 Mg/m ³	Conc. 0.110 Mg/m ³	Conc. 0.216 Mg/m ³	Conc. 0.087 Mg/m ³	Conc. 0.118 Mg/m ³

Comments:

[illegible]

Comments:



Westgate Air Monitoring Air Filtration System

Date: 6-19-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.28 ppm FID 0.19 ppm	PID 1.29 ppm FID 5.30 ppm	PID 0.38 ppm FID 0.50 ppm	PID 0.96 ppm FID 4.53 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 1.7 ppm	PID 0.0 ppm	PID 1.3 ppm
Cal.				
Comments:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 4.62 ppm FID 9.48 ppm
Cal.	
Mini RAE 2000	PID 4.3 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.007 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.076 Mg/m ³



Date: -

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 6-20-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	2:40	2:43	2:45	2:48	2:50	2:55
Foxboro TVA 1000	PID 0.54 ppm	0.55	PID 0.51 ppm	PID 0.44 ppm	PID 0.41 ppm	PID 0.25 ppm
	FID 1.18 ppm	FID 1.24 ppm	FID 0.87 ppm	FID 0.74 ppm	FID 0.69 ppm	FID 0.50 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.010 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.004 Mg/m ³	Conc. 0.029 Mg/m ³	Conc. 0.032 Mg/m ³	Conc. 0.020 Mg/m ³

Comments:

Winds from southeast at 18 mph.



Westgate Air Monitoring Air Filtration System

Date: 6-20-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.52 ppm FID 1.33 ppm	PID 1.59 ppm FID 6.13 ppm	PID 0.55 ppm FID 1.98 ppm	PID 1.03 ppm FID 3.40 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 1.4 ppm	PID 0.0 ppm	PID 0.4 ppm
Cal.				
Comments:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 1.33 ppm FID 2.14 ppm
Cal.	
Mini RAE 2000	PID 1.6 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.033 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.813 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 6-21-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:37	9:43	9:50	9:58	10:00	10:09
Foxboro TVA 1000	PID 1.72 ppm	1.32	PID 1.10 ppm	PID 0.48 ppm	PID 0.70 ppm	PID 0.88 ppm
	FID 1.10 ppm	FID 0.70 ppm	FID 0.60 ppm	FID 0.63 ppm	FID 0.00 ppm	FID 0.62 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.018 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.018 Mg/m ³

Comments:

wind out of sw at 10 mph.



Westgate Air Monitoring Westgate Neighborhood

Date: 6-21-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:17	4:20	4:23	4:26	4:29	4:32
Foxboro TVA 1000	PID 0.25 ppm	0.30	PID 0.18 ppm	PID 0.15 ppm	PID 0.13 ppm	PID 0.12 ppm
	FID 2.01 ppm	FID 1.95 ppm	FID 2.54 ppm	FID 1.63 ppm	FID 1.44 ppm	FID 0.98 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

Winds from south at 16 mph.



Westgate Air Monitoring Air Filtration System

Date: 6-21-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:34	4:35	4:37	4:39
Foxboro TVA 1000	PID 0.28 ppm	PID 0.72 ppm	PID 0.30 ppm	PID 0.67 ppm
	FID 0.88 ppm	FID 3.39 ppm	FID 0.81 ppm	FID 3.83 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.4 ppm	PID 0.0 ppm	PID 0.3 ppm
Cal.				
Comments:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 1.16 ppm
	FID 4.54 ppm
Cal.	
Mini RAE 2000	PID 1.2 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.010 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.149 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 6-24-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:13	9:17	9:19	9:24	9:27	9:30
Foxboro TVA 1000	PID 0.11 ppm	0.05	PID 0.04 ppm	PID 0.01 ppm	PID 0.02 ppm	PID 0.00 ppm
	FID 0.14 ppm	FID 0.05 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal. 6-24-02						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal. 6-24-02						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal. 6-24-02						
MIE PDR 1000	Conc. 0.036 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.015 Mg/m ³	Conc. 0.024 Mg/m ³	Conc. 0.006 Mg/m ³

Comments:



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
Time	3:50	3:55	3:58	4:03	4:07	4:16
Foxboro TVA 1000	PID 0.04 ppm	0.02	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.006 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.003 Ma/m ³	Conc. 0.015 Ma/m ³	Conc. 0.012 Ma/m ³	Conc. 0.013 Ma/m ³	Conc. 0.026 Ma/m ³	Conc. 0.018 Ma/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 6-24-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:19	4:20	4:22	4:24
Foxboro TVA 1000	PID 0.02 ppm	PID 1.25 ppm	PID 0.07 ppm	PID 1.42 ppm
	FID 0.00 ppm	FID 6.02 ppm	FID 0.00 ppm	FID 6.77 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 3.6 ppm	PID 0.0 ppm	PID 3.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:27
Foxboro TVA 1000	PID 4.08 ppm
	FID 16.52 ppm
Cal.	
Mini RAE 2000	PID 6.4 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.009 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.296 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 6-25-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	9:58		10:02		10:05		10:07		10:11		10:14	
Foxboro TVA 1000	PID 0.05 ppm		0.06		PID 0.01 ppm		PID 0.01 ppm		PID 0.00 ppm		PID 0.00 ppm	
	FID 0.98 ppm		FID 0.33 ppm		FID 0.85 ppm		FID 0.19 ppm		FID 0.00 ppm		FID 0.16 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.002 H ₂ S ppm		.001 H ₂ S ppm		.000 H ₂ S ppm		.002 H ₂ S ppm		.002 H ₂ S ppm		.000 H ₂ S ppm	
Gastech GT 201	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
	0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.014 Mg/m ³		Conc. 0.022 Mg/m ³		Conc. 0.008 Mg/m ³		Conc. 0.032 Mg/m ³		Conc. 0.034 Mg/m ³		Conc. 0.039 Mg/m ³	

Comments

Winds at 10 mph out of the southeast.



Westgate Air Monitoring Westgate Neighborhood

Date: 6-25-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:00	4:04	4:07	4:11	4:15	4:19
Foxboro TVA 1000	PID 0.09 ppm	0.02	PID 0.04 ppm	PID 0.05 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.72 ppm	FID 0.30 ppm	FID 0.40 ppm	FID 0.28 ppm	FID 0.00 ppm	FID 0.17 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.015 Mg/m ³	Conc. 0.021 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.034 Mg/m ³	Conc. 0.037 Mg/m ³	Conc. 0.028 Mg/m ³

Comments:

Winds from the southeast at 5 mph.



Westgate Air Monitoring Air Filtration System

Date: 6-25-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.02 ppm FID 0.00 ppm	PID 1.20 ppm FID 6.01 ppm	PID 0.08 ppm FID 0.00 ppm	PID 1.48 ppm FID 6.72 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 3.4 ppm	PID 0.0 ppm	PID 3.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 4.07 ppm FID 16.48 ppm
Cal.	
Mini RAE 2000	PID 6.2 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.007 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.278 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 6-26-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	10:22		10:26		10:30		10:34		10:38		10:41	
Foxboro TVA 1000	PID 0.00 ppm		0.01		PID 0.01 ppm		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm	
	FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.01 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.001 H ₂ S ppm		.001 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.001 H ₂ S ppm		.002 H ₂ S ppm	
Gastech GT 201	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
	0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.004 Mg/m ³		Conc. 0.011 Mg/m ³		Conc. 0.014 Mg/m ³		Conc. 0.012 Mg/m ³		Conc. 0.021 Mg/m ³		Conc. 0.019 Mg/m ³	

Comments:

Winds at 5 mph out of the southeast.



Westgate Air Monitoring Westgate Neighborhood

Date: 6-26-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:10	4:14	4:19	4:23	4:27	4:32
Foxboro TVA 1000	PID 0.02 ppm	0.00	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.003 Mg/m ³	Conc. 0.012 Mg/m ³	Conc. 0.021 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.008 Mg/m ³	Conc. 0.008 Mg/m ³

Comments

Winds from the southeast at 8 mph.



Westgate Air Monitoring Air Filtration System

Date: 6-26-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.02 ppm	PID 1.08 ppm	PID 0.07 ppm	PID 1.45 ppm
	FID 0.00 ppm	FID 5.39 ppm	FID 0.00 ppm	FID 6.70 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 2.5 ppm	PID 0.0 ppm	PID 3.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 3.98 ppm
	FID 14.50 ppm
Cal.	
Mini RAE 2000	PID 5.9 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.006 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.253 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 6-27-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:30	9:34	9:39	9:42	9:45	9:49
Foxboro TVA 1000	PID 0.09 ppm	0.07	PID 0.03 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.01 ppm
	FID 0.21 ppm	FID 0.30 ppm	FID 0.25 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.020 Mg/m ³	Conc. 0.018 Mg/m ³	Conc. 0.033 Mg/m ³	Conc. 0.031 Mg/m ³	Conc. 0.024 Mg/m ³	Conc. 0.011 Mg/m ³

Comments:

Winds at 6 mph out of the south.



Westgate Air Monitoring Westgate Neighborhood

Date: 6-27-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:23	4:26	4:32	4:37	4:42	4:47
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.01 ppm	FID 0.02 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.02 ppm	FID 0.01 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.019 Mg/m ³	Conc. 0.021 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.010 Mg/m ³	Conc. 0.028 Mg/m ³	Conc. 0.014 Mg/m ³

Comments:

Winds from the southeast at 8 mph.



Westgate Air Monitoring Air Filtration System

Date: 6-27-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.02 ppm FID 0.00 ppm	PID 1.02 ppm FID 4.87 ppm	PID 0.08 ppm FID 0.00 ppm	PID 1.37 ppm FID 5.72 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 3.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 4.17 ppm FID 13.09 ppm
Cal.	
Mini RAE 2000	PID 5.7 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.008 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.209 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 6-28-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	10:10	10:14	10:19	10:24	10:28	10:32
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.01 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.02 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.009 Mg/m ³	Conc. 0.008 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.012 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.006 Mg/m ³

Comments

Winds at 2 mph out of the south.



Westgate Air Monitoring Westgate Neighborhood

Date: 6-28-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:20	4:25	4:29	4:34	4:37	4:42
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.01 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.01 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.018 Mg/m ³	Conc. 0.022 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.028 Mg/m ³	Conc. 0.014 Mg/m ³

Comments:

Winds from the southeast at 10 mph.



Westgate Air Monitoring Air Filtration System

Date: 6-28-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.02 ppm	PID 1.09 ppm	PID 0.06 ppm	PID 1.30 ppm
	FID 0.00 ppm	FID 3.87 ppm	FID 0.00 ppm	FID 4.89 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 3.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 4.18 ppm
	FID 12.80 ppm
Cal.	
Mini RAE 2000	PID 4.5 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.005 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.198 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 7-1-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	10:05		10:14		10:18		10:23		10:28		10:34	
Foxboro TVA 1000	PID 0.00 ppm		0.00		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm	
	FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.001 H ₂ S ppm		.001 H ₂ S ppm		.000 H ₂ S ppm		.001 H ₂ S ppm		.001 H ₂ S ppm		.000 H ₂ S ppm	
Gastech GT 201	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
	0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.020 Mg/m ³		Conc. 0.011 Mg/m ³		Conc. 0.014 Mg/m ³		Conc. 0.028 Mg/m ³		Conc. 0.014 Mg/m ³		Conc. 0.017 Mg/m ³	

Comments:

Winds at 11 mph out of the southeast.



7-1-02

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 7-1-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:03	4:07	4:10	4:13
Foxboro TVA 1000	PID 0.02 ppm	PID 1.08 ppm	PID 0.05 ppm	PID 1.12 ppm
	FID 0.00 ppm	FID 3.09 ppm	FID 0.00 ppm	FID 3.49 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 3.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:16
Foxboro TVA 1000	PID 3.78 ppm
	FID 9.78 ppm
Cal.	
Mini RAE 2000	PID 14.5 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.166 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 7-2-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	10:23	10:26	10:30	10:34	10:37	10:41
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.010 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.008 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.009 Mg/m ³

Comments:

Winds at 14 mph out of the southeast.



Westgate Air Monitoring Westgate Neighborhood

Date: 7-2-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:11	4:16	4:19	4:23	4:27	4:32
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.006 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.005 Mg/m ³

Comments:

Southeast winds at 8 mph.



Westgate Air Monitoring Air Filtration System

Date: 7-2-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.02 ppm FID 0.00 ppm	PID 1.06 ppm FID 2.98 ppm	PID 0.05 ppm FID 0.00 ppm	PID 1.20 ppm FID 3.51 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 2.3 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 4.18 ppm FID 12.75 ppm
Cal.	
Mini RAE 2000	PID 4.5 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.241 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 7-3-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
Foxboro TVA 1000	9:40 PID 0.00 ppm	9:43 0.00	9:46 PID 0.00 ppm	9:49 PID 0.00 ppm	9:54 PID 0.00 ppm	9:59 PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.009 Mg/m ³	Conc. 0.008 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.000 Mg/m ³

Comments

Northwest winds at 8 mph.



Westgate Air Monitoring Westgate Neighborhood

Date: 7-3-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	3:36		3:40		3:44		3:48		3:52		3:57	
Foxboro TVA 1000	PID	0.00 ppm			PID	0.00 ppm	PID	0.00 ppm	PID	0.00 ppm	PID	0.00 ppm
	FID	0.00 ppm	FID	0.00 ppm	FID	0.00 ppm	FID	0.00 ppm	FID	0.00 ppm	FID	0.00 ppm
Cal.												
Mini RAE 2000	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm
Cal.												
Jerome 431-X		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³
Jerome 631-X		.000 H ₂ S ppm		.001 H ₂ S ppm		.000 H ₂ S ppm		.001 H ₂ S ppm		.001 H ₂ S ppm		.001 H ₂ S ppm
Gastech GT 201		.000 % LEL		.000 % LEL		.000 % LEL		.000 % LEL		.000 % LEL		.000 % LEL
		.0000 ppm		.0000 ppm		.0000 ppm		.0000 ppm		.0000 ppm		.0000 ppm
		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂
Cal.												
MIE PDR 1000	Conc.	0.011 Mg/m ³	Conc.	0.014 Mg/m ³	Conc.	0.005 Mg/m ³	Conc.	0.020 Mg/m ³	Conc.	0.015 Mg/m ³	Conc.	0.009 Mg/m ³

Comments:

Southeast winds at 13 mph.



Westgate Air Monitoring Air Filtration System

Date: 7-3-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.00 ppm	PID 1.09 ppm	PID 0.00 ppm	PID 1.73 ppm
	FID 0.00 ppm	FID 6.01 ppm	FID 0.00 ppm	FID 5.58 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 3.4 ppm	PID 0.0 ppm	PID 2.6 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 3.09 ppm
	FID 12.40 ppm
Cal.	
Mini RAE 2000	PID 4.2 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.005 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.275 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 7-8-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:00	9:07	9:13	9:19	9:23	9:29
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.07 ppm	PID 0.02 ppm	PID 0.00 ppm	PID 0.12 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 7-8-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:02	4:09	4:16	4:20	4:26	4:30
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.01 ppm	PID 0.01 ppm	PID 0.12 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 7-8-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.17 ppm	PID 1.59 ppm	PID 0.45 ppm	PID 0.30 ppm
	FID 0.00 ppm	FID 6.13 ppm	FID 1.87 ppm	FID 1.11 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 1.4 ppm	PID 0.4 ppm	PID 0.2 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 1.33 ppm
	FID 2.70 ppm
Cal.	
Mini RAE 2000	PID 1.6 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.015 Mg/m ³



Date: -

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 7-9-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:50	4:55	5:00	5:06	5:09	5:15
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 7-9-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	5:20	5:22	5:25	5:28
Foxboro TVA 1000	PID 0.00 ppm	PID 0.30 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.90 ppm	FID 0.10 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.				
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:40
Foxboro TVA 1000	PID 0.30 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.003 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 7-10-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:35	9:38	9:44	9:48	9:52	9:55
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



7-10-02

Comments:



Westgate Air Monitoring Air Filtration System

Date: 7-10-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	2:55	2:57	2:59	3:02
Foxboro TVA 1000	PID 0.00 ppm	PID 0.07 ppm	PID 0.06 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.48 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	3:10
Foxboro TVA 1000	PID 1.60 ppm
	FID 1.35 ppm
Cal.	
Mini RAE 2000	PID 1.9 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 7-17-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	10:14		10:17		10:21		10:24		10:27		10:30	
Foxboro TVA 1000	PID 0.09 ppm		0.17		PID 0.30 ppm		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm	
	FID 0.47 ppm		FID 0.88 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.21 ppm		FID 0.07 ppm	
Cal.												
Mini RAE 2000	PID 0.1 ppm		PID 0.1 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.002 H ₂ S ppm		.001 H ₂ S ppm		.002 H ₂ S ppm		.001 H ₂ S ppm		.000 H ₂ S ppm		.001 H ₂ S ppm	
Gastech GT 201	.000 % LEL		.000 % LEL		.000 % LEL		.000 % LEL		.000 % LEL		.000 % LEL	
	.0000 ppm		.0000 ppm		.0000 ppm		.0000 ppm		.0000 ppm		.0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.102 Mg/m ³		Conc. 0.109 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³	

Comments:



Westgate Air Monitoring Air Filtration System

Date: 7-17-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	3:50	3:52	3:54	3:56
Foxboro TVA 1000	PID 0.16 ppm	PID 0.54 ppm	PID 0.17 ppm	PID 0.26 ppm
	FID 0.07 ppm	FID 0.64 ppm	FID 1.21 ppm	FID 0.07 ppm
Cal.				
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:00
Foxboro TVA 1000	PID 0.91 ppm
	FID 0.87 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.173 Mg/m ³



7-18-02

Comments:



Westgate Air Monitoring Air Filtration System

Date: 7-18-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:15	4:17	4:18	4:20
Foxboro TVA 1000	PID 0.17 ppm	PID 0.10 ppm	PID 0.00 ppm	PID 0.71 ppm
	FID 0.00 ppm	FID 0.92 ppm	FID 0.13 ppm	FID 0.24 ppm
Cal.				
Mini RAE 2000	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:30
Foxboro TVA 1000	PID 0.17 ppm
	FID 0.43 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.001 Mg/m ³



Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	8:50	8:53	8:58	9:03	9:07	9:10
Foxboro TVA 1000	PID 0.27 ppm	0.00	PID 0.00 ppm	PID 0.17 ppm	PID 0.01 ppm	PID 0.00 ppm
	FID 0.09 ppm	FID 0.21 ppm	FID 0.16 ppm	FID 0.00 ppm	FID 0.16 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.001 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.073 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 7-19-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:40	4:42	4:44	4:46
Foxboro TVA 1000	PID 0.11 ppm	PID 0.07 ppm	PID 0.09 ppm	PID 0.00 ppm
	FID 0.27 ppm	FID 0.01 ppm	FID 1.23 ppm	FID 0.00 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.1 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:55
Foxboro TVA 1000	PID 0.91 ppm
	FID 0.11 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³



Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:55	4:00	4:04	4:08	4:13	4:16
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.017 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 7-22-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:20	4:22	4:23	4:25
Foxboro TVA 1000	PID 0.17 ppm	PID 0.91 ppm	PID 0.38 ppm	PID 0.00 ppm
	FID 0.36 ppm	FID 0.03 ppm	FID 1.12 ppm	FID 0.03 ppm
Cal.				
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:35
Foxboro TVA 1000	PID 0.00 ppm
	FID 0.76 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³



7-23-02

Comments:



Westgate Air Monitoring Air Filtration System

Date: 7-23-02

	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:50	4:52	4:53	4:55
Foxboro TVA 1000	PID 0.01 ppm	PID 0.00 ppm	PID 0.01 ppm	PID 0.00 ppm
	FID 0.16 ppm	FID 0.34 ppm	FID 0.00 ppm	FID 0.16 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.1 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
5:15	
Foxboro TVA 1000	PID 0.47 ppm
	FID 1.00 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 7-24-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	3:20		3:24		3:27		3:30		3:34		3:38	
Foxboro TVA 1000	PID 0.01 ppm		0.00		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm	
	FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.002 H ₂ S ppm		.000 H ₂ S ppm	
Gastech GT 201	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
	0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.000 Mg/m ³		Conc. 0.019 Mg/m ³		Conc. 0.173 Mg/m ³		Conc. 0.200 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.214 Mg/m ³	

Comments:



Westgate Air Monitoring Air Filtration System

Date: 7-24-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.11 ppm FID 0.34 ppm	PID 0.00 ppm FID 0.02 ppm	PID 0.72 ppm FID 1.20 ppm	PID 0.33 ppm FID 1.16 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.11 ppm FID 0.29 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 7-25-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:10	4:14	4:17	4:21	4:25	4:28
Foxboro TVA 1000	PID 0.07 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.24 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 7-25-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:40	4:44	4:47	4:50
Foxboro TVA 1000	PID 0.00 ppm	PID 0.05 ppm	PID 0.07 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.18 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:05
Foxboro TVA 1000	PID 1.12 ppm
	FID 1.09 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-12-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	8:55	9:00	9:05	9:10	9:15	9:22
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.02 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.011 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.004 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.001 Mg/m ³

Comments:



Date: _____

Comments:



Westgate Air Monitoring Air Filtration System

Date: 8-12-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	5:15	5:17	5:19	5:23
Foxboro TVA 1000	PID 0.02 ppm	PID 0.07 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.02 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.				
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:40
Foxboro TVA 1000	PID 1.27 ppm
	FID 2.60 ppm
Cal.	
Mini RAE 2000	PID 1.9 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.800 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-13-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
Foxboro TVA 1000	9:45 PID 0.00 ppm	9:50 0.00	9:55 PID 0.00 ppm	10:00 PID 0.00 ppm	10:04 PID 0.00 ppm	10:09 PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.006 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:

Southeast winds at 8 mph.



Westgate Air Monitoring Westgate Neighborhood

Date: 8-13-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:30	3:35	3:42	3:45	3:50	3:55
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.003 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 8-13-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:05	4:08	4:11	4:15
Foxboro TVA 1000	PID 0.38 ppm	PID 1.13 ppm	PID 0.40 ppm	PID 1.10 ppm
	FID 1.31 ppm	FID 1.87 ppm	FID 1.63 ppm	FID 1.99 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.5 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:25
Foxboro TVA 1000	PID 1.12 ppm
	FID 2.00 ppm
Cal.	
Mini RAE 2000	PID 0.4 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.010 Mg/m ³



8-14-02

[illegible]



8-14-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
Time	3:45	3:50	3:55	3:58	4:00	4:05
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.01 ppm	PID 0.00 ppm	PID 0.02 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.004 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.010 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.015 Mg/m ³
Comments:						



Westgate Air Monitoring Air Filtration System

Date: 8-14-02

	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:15	4:18	4:21	4:25
Foxboro TVA 1000	PID 0.03 ppm	PID 1.07 ppm	PID 0.05 ppm	PID 1.23 ppm
	FID 0.00 ppm	FID 3.12 ppm	FID 0.00 ppm	FID 4.00 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 1.3 ppm	PID 0.0 ppm	PID 1.5 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:40
Foxboro TVA 1000	PID 1.31 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 1.5 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.002 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-15-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	11:05	11:10	11:15	11:19	11:25	11:30
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.01 ppm	FID 0.02 ppm	FID 0.01 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.020 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.010 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 8-15-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:20	4:25	4:30	4:35	4:40	4:45
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.011 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.023 Mg/m ³	Conc. 0.008 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 8-15-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	5:00	5:03	5:07	5:11
Foxboro TVA 1000	PID 0.02 ppm	PID 1.10 ppm	PID 0.07 ppm	PID 1.13 ppm
	FID 0.00 ppm	FID 2.02 ppm	FID 0.00 ppm	FID 3.10 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 1.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:16
Foxboro TVA 1000	PID 1.42 ppm
	FID 4.47 ppm
Cal.	
Mini RAE 2000	PID 7.3 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.118 Mg/m ³



8-16-02

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 8-16-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	4:15		4:20		4:25		4:30		4:35		4:40	
Foxboro TVA 1000	PID 4.21 ppm		3.51		PID 2.20 ppm		PID 1.01 ppm		PID 1.09 ppm		PID 1.34 ppm	
	FID 0.47 ppm		FID 0.15 ppm		FID 0.36 ppm		FID 0.22 ppm		FID 0.19 ppm		FID 1.04 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.001 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.001 Hg Mg/m ³		.001 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.002 H ₂ S ppm		.001 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.001 H ₂ S ppm		.002 H ₂ S ppm	
Gastech GT 201	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
	0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.012 Mg/m ³		Conc. 0.019 Mg/m ³		Conc. 0.004 Mg/m ³		Conc. 0.016 Mg/m ³		Conc. 0.001 Mg/m ³		Conc. 0.003 Mg/m ³	

Comments:



Westgate Air Monitoring Air Filtration System

Date: 8-16-02

	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:45	4:48	4:54	4:59
Foxboro TVA 1000	PID 0.73 ppm	PID 6.34 ppm	PID 0.55 ppm	PID 6.37 ppm
	FID 0.00 ppm	FID 18.11 ppm	FID 0.03 ppm	FID 20.45 ppm
Cal.				
Mini RAE 2000	PID 0.5 ppm	PID 21.7 ppm	PID 0.7 ppm	PID 18.3 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:05
Foxboro TVA 1000	PID 12.35 ppm
	FID 44.19 ppm
Cal.	
Mini RAE 2000	PID 27.3 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.014 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	0120 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.623 Mg/m ³



8-19-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	8:50	8:55	9:00	9:05	9:10	9:15
Foxboro TVA 1000	PID 0.00 ppm	0.01	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.01 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.005 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.015 Mg/m ³	Conc. 0.010 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.015 Mg/m ³

Comments:



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
Time	4:20	4:25	4:30	4:35	4:40	4:45
Foxboro TVA 1000	PID 0.01 ppm	0.00	PID 0.02 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.01 ppm
	FID 0.00 ppm	FID 0.01 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.002 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIIE PDR 1000	Conc. 0.004 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.009 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 8-19-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:50	4:53	4:59	5:03
Foxboro TVA 1000	PID 0.04 ppm	PID 1.13 ppm	PID 0.05 ppm	PID 1.76 ppm
	FID 0.00 ppm	FID 6.27 ppm	FID 0.00 ppm	FID 5.97 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 2.9 ppm	PID 0.0 ppm	PID 2.7 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:15
Foxboro TVA 1000	PID 4.02 ppm
	FID 13.97 ppm
Cal.	
Mini RAE 2000	PID 6.3 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.007 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.298 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-20-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:30	9:34	9:39	9:42	9:45	9:50
Foxboro TVA 1000	PID 0.09 ppm	0.05	PID 0.04 ppm	PID 0.00 ppm	PID 0.01 ppm	PID 0.02 ppm
	FID 0.22 ppm	FID 0.25 ppm	FID 0.20 ppm	FID 0.00 ppm	FID 0.14 ppm	FID 0.07 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.018 Mg/m ³	Conc. 0.015 Mg/m ³	Conc. 0.027 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.028 Mg/m ³	Conc. 0.027 Mg/m ³

Comments:



8-20-02

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 8-20-02

	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:00	4:03	4:05	4:08
Foxboro TVA 1000	PID 0.03 ppm	PID 2.31 ppm	PID 0.07 ppm	PID 1.47 ppm
	FID 0.01 ppm	FID 5.19 ppm	FID 0.03 ppm	FID 6.23 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 2.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:15
Foxboro TVA 1000	PID 5.02 ppm
	FID 11.26 ppm
Cal.	
Mini RAE 2000	PID 3.7 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.004 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.316 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-21-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	9:30		9:35		9:39		9:43		9:47		9:50	
Foxboro TVA 1000	PID	0.11 ppm	0.13		PID	0.06 ppm	PID	0.03 ppm	PID	0.00 ppm	PID	0.06 ppm
	FID	0.18 ppm	FID	0.09 ppm	FID	0.21 ppm	FID	0.09 ppm	FID	0.00 ppm	FID	0.02 ppm
Cal.												
Mini RAE 2000	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm
Cal.												
Jerome 431-X	.002	Hg Mg/m ³	.001	Hg Mg/m ³	.000	Hg Mg/m ³	.001	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³
Jerome 631-X	.003	H ₂ S ppm	.002	H ₂ S ppm	.000	H ₂ S ppm	.001	H ₂ S ppm	.001	H ₂ S ppm	.001	H ₂ S ppm
Gastech GT 201	000	% LEL	000	% LEL	000	% LEL	000	% LEL	000	% LEL	000	% LEL
	0000	ppm	0000	ppm	0000	ppm	0000	ppm	0000	ppm	0000	ppm
	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂
Cal.												
MIE PDR 1000	Conc.	0.017 Mg/m ³	Conc.	0.021 Mg/m ³	Conc.	0.033 Mg/m ³	Conc.	0.027 Mg/m ³	Conc.	0.016 Mg/m ³	Conc.	0.090 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 8-21-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:05	4:08	4:12	4:17	4:23	4:30
Foxboro TVA 1000	PID 0.11 ppm	0.05	PID 0.09 ppm	PID 0.02 ppm	PID 0.03 ppm	PID 0.01 ppm
	FID 0.15 ppm	FID 0.17 ppm	FID 0.20 ppm	FID 0.07 ppm	FID 0.09 ppm	FID 0.04 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.001 Hg Mg/m ³	.000 Hg Mg/m ³	.001 Hg Mg/m ³	.000 Hg Mg/m ³	.001 Hg Mg/m ³	.001 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.002 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.017 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.027 Mg/m ³	Conc. 0.020 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.011 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 8-21-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:35	4:38	4:41	4:45
Foxboro TVA 1000	PID 0.05 ppm	PID 1.27 ppm	PID 0.07 ppm	PID 1.73 ppm
	FID 0.03 ppm	FID 5.07 ppm	FID 0.01 ppm	FID 5.63 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 2.3 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:50
Foxboro TVA 1000	PID 3.94 ppm
	FID 10.07 ppm
Cal.	
Mini RAE 2000	PID 3.6 ppm
Cal.	
Jerome 431-X	.002 Hg Mg/m ³
Jerome 631-X	.007 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.127 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-22-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	10:05		10:10		10:14		10:18		10:22		10:29	
Foxboro TVA 1000	PID 0.02 ppm		0.00		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm	
	FID 0.01 ppm		FID 0.00 ppm		FID 0.02 ppm		FID 0.02 ppm		FID 0.00 ppm		FID 0.00 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.000 Hg Mg/m ³		.001 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.001 H ₂ S ppm		.000 H ₂ S ppm		.001 H ₂ S ppm		.000 H ₂ S ppm		.001 H ₂ S ppm		.000 H ₂ S ppm	
Gastech GT 201	0.00 % LEL		0.00 % LEL		0.00 % LEL		0.00 % LEL		0.00 % LEL		0.00 % LEL	
	0.000 ppm		0.000 ppm		0.000 ppm		0.000 ppm		0.000 ppm		0.000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.007 Mg/m ³		Conc. 0.006 Mg/m ³		Conc. 0.001 Mg/m ³		Conc. 0.009 Mg/m ³		Conc. 0.010 Mg/m ³		Conc. 0.002 Mg/m ³	

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 8-22-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:20	4:25	4:28	4:32	4:38	4:44
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.01 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.001 Hg Mg/m ³	.000 Hg Mg/m ³	.001 Hg Mg/m ³	.001 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.017 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.012 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.011 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 8-22-02

	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:50	4:58	4:59	5:02
Foxboro TVA 1000	PID 0.03 ppm	PID 1.19 ppm	PID 0.05 ppm	PID 1.32 ppm
	FID 0.00 ppm	FID 3.77 ppm	FID 0.00 ppm	FID 4.73 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 2.6 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:10
Foxboro TVA 1000	PID 4.23 ppm
	FID 12.11 ppm
Cal.	
Mini RAE 2000	PID 4.0 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.004 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.201 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-23-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:15	9:20	9:24	9:30	9:34	9:38
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.001 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.011 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.211 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.019 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 8-23-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	4:25		4:29		4:35		4:40		4:43		4:48	
Foxboro TVA 1000	PID 0.02 ppm		0.00		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm		PID 0.01 ppm	
	FID 0.04 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.001 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.001 H ₂ S ppm		.002 H ₂ S ppm		.001 H ₂ S ppm		.000 H ₂ S ppm		.001 H ₂ S ppm		.000 H ₂ S ppm	
Gastech GT 201	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
	0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.010 Mg/m ³		Conc. 0.116 Mg/m ³		Conc. 0.006 Mg/m ³		Conc. 0.002 Mg/m ³		Conc. 0.001 Mg/m ³		Conc. 0.001 Mg/m ³	

Comments:



Westgate Air Monitoring Air Filtration System

Date: 8-23-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:53	4:56	5:00	5:03
Foxboro TVA 1000	PID 0.01 ppm	PID 0.79 ppm	PID 0.03 ppm	PID 1.07 ppm
	FID 0.00 ppm	FID 0.27 ppm	FID 0.00 ppm	FID 3.02 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:08
Foxboro TVA 1000	PID 3.12 ppm
	FID 9.01 ppm
Cal.	
Mini RAE 2000	PID 1.6 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.022 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-26-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	8:50	8:55	8:58	9:00	9:04	9:08
Foxboro TVA 1000	PID 0.07 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.11 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.006 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.018 Mg/m ³	Conc. 0.007 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 8-26-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:15	4:18	4:22	4:27	4:33	4:38
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.010 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.007 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 8-26-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:45	4:48	4:52	4:56
Foxboro TVA 1000	PID 0.00 ppm	PID 1.05 ppm	PID 0.00 ppm	PID 1.64 ppm
	FID 0.00 ppm	FID 5.47 ppm	FID 0.00 ppm	FID 4.71 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 3.1 ppm	PID 0.0 ppm	PID 2.2 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:03
Foxboro TVA 1000	PID 2.88 ppm
	FID 10.31 ppm
Cal.	
Mini RAE 2000	PID 3.7 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.005 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.223 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-27-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:50	9:53	10:00	10:04	10:08	10:13
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.16 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.014 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 8-27-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	2:40	2:45	2:48	2:53	2:58	3:03
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.10 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.06 ppm	FID 0.00 ppm	FID 0.20 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.019 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.014 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 8-27-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	3:08	3:12	3:17	3:20
Foxboro TVA 1000	PID 0.00 ppm	PID 1.36 ppm	PID 0.00 ppm	PID 1.97 ppm
	FID 0.07 ppm	FID 4.15 ppm	FID 0.26 ppm	FID 5.73 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 3.9 ppm	PID 0.0 ppm	PID 3.2 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	3:25
Foxboro TVA 1000	PID 2.13 ppm
	FID 1.85 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.007 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.216 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-28-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:00	9:04	9:08	9:13	9:18	9:23
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.016 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.004 Mg/m ³	Conc. 0.020 Mg/m ³	Conc. 0.029 Mg/m ³	Conc. 0.031 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 8-28-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:20	3:23	3:27	3:32	3:37	3:41
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.27 ppm	FID 0.09 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.017 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.021 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.012 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 8-28-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	3:45	3:48	3:51	3:55
Foxboro TVA 1000	PID 0.09 ppm	PID 2.11 ppm	PID 0.13 ppm	PID 2.23 ppm
	FID 1.01 ppm	FID 6.27 ppm	FID 0.97 ppm	FID 4.63 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 2.3 ppm	PID 0.3 ppm	PID 1.7 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:00
Foxboro TVA 1000	PID 1.57 ppm
	FID 2.65 ppm
Cal.	
Mini RAE 2000	PID 1.3 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.057 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-29-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	10:05	10:08	10:14	10:20	10:25	10:28
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.16 ppm	FID 0.27 ppm	FID 0.03 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.011 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.131 Mg/m ³	Conc. 0.071 Mg/m ³	Conc. 0.215 Mg/m ³	Conc. 0.008 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 8-29-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:20	4:25	4:30	4:33	4:39	4:45
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.010 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.113 Mg/m ³	Conc. 0.214 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.111 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 8-29-02

	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	5:00	5:03	5:07	5:10
Foxboro TVA 1000	PID 0.76 ppm	PID 0.34 ppm	PID 0.91 ppm	PID 0.17 ppm
	FID 1.11 ppm	FID 1.76 ppm	FID 0.03 ppm	FID 0.67 ppm
Cal.				
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:15
Foxboro TVA 1000	PID 0.19 ppm
	FID 1.23 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-30-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	8:40	8:45	8:50	8:55	9:00	9:05
Foxboro TVA 1000	PID 0.16 ppm	0.22	PID 0.13 ppm	PID 0.62 ppm	PID 0.01 ppm	PID 0.03 ppm
	FID 0.72 ppm	FID 0.45 ppm	FID 0.72 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.16 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.111 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.072 Mg/m ³	Conc. 0.176 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.009 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 8-30-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:15	3:20	3:25	3:30	3:35	3:40
Foxboro TVA 1000	PID 0.13 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.17 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 1.12 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 8-30-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	3:45	3:48	3:51	3:55
Foxboro TVA 1000	PID 1.27 ppm	PID 1.00 ppm	PID 0.97 ppm	PID 1.00 ppm
	FID 0.76 ppm	FID 1.72 ppm	FID 1.23 ppm	FID 1.00 ppm
Cal.				
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:05
Foxboro TVA 1000	PID 0.76 ppm
	FID 0.87 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.007 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
Time	9:35	9:41	9:45	9:50	9:56	10:00
Foxboro TVA 1000	PID 0.00 ppm	0.04	PID 0.01 ppm	PID 0.00 ppm	PID 0.01 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.016 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.012 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.009 Mg/m ³

Comments:

Comments:



9-2-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
Time	3:45	3:51	3:57	4:00	4:05	4:10
Foxboro TVA 1000	PID 0.09 ppm	0.02	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.01 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.024 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.039 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.019 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-2-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:13	4:14	4:16	4:18
Foxboro TVA 1000	PID 0.03 ppm	PID 1.16 ppm	PID 0.06 ppm	PID 1.37 ppm
	FID 0.00 ppm	FID 5.47 ppm	FID 0.00 ppm	FID 5.89 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 3.4 ppm	PID 0.0 ppm	PID 3.4 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:24
Foxboro TVA 1000	PID 2.15 ppm
	FID 5.79 ppm
Cal.	
Mini RAE 2000	PID 3.2 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.008 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.186 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-3-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	10:15		10:20		10:25		10:27		10:30		10:35	
Foxboro TVA 1000	PID 0.00 ppm		0.01		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm	
	FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm	
Gastech GT 201	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
	0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.009 Mg/m ³		Conc. 0.013 Mg/m ³		Conc. 0.008 Mg/m ³		Conc. 0.011 Mg/m ³		Conc. 0.012 Mg/m ³		Conc. 0.009 Mg/m ³	

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 9-3-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:50	3:55	3:59	4:04	4:10	4:14
Foxboro TVA 1000	PID 0.03 ppm	0.04	PID 0.02 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.019 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.012 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.010 Mg/m ³	Conc. 0.009 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-3-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:19	4:20	4:22	4:23
Foxboro TVA 1000	PID 0.05 ppm	PID 1.05 ppm	PID 0.00 ppm	PID 1.39 ppm
	FID 0.01 ppm	FID 3.34 ppm	FID 0.00 ppm	FID 4.87 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 2.5 ppm	PID 0.0 ppm	PID 3.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 2.06 ppm
	FID 4.97 ppm
Cal.	
Mini RAE 2000	PID 3.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.009 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.234 Mg/m ³



9-4-02

[illegible]



9-4-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:05	4:08	4:13	4:17	4:22	4:25
Foxboro TVA 1000	PID 0.07 ppm	0.04	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.37 ppm	FID 0.11 ppm	FID 0.19 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.111 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.021 Mg/m ³	Conc. 0.061 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.130 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-4-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.02 ppm FID 0.07 ppm	PID 1.17 ppm FID 3.92 ppm	PID 0.01 ppm FID 0.04 ppm	PID 1.42 ppm FID 4.76 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 2.2 ppm	PID 0.1 ppm	PID 2.9 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 1.97 ppm FID 2.33 ppm
Cal.	
Mini RAE 2000	PID 3.1 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.227 Mg/m ³



9-5-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	10:05	10:10	10:15	10:20	10:25	10:30
Foxboro TVA 1000	PID 0.01 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.001 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.007 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.117 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.008 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 9-5-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:30	4:33	4:37	4:42	4:45	4:48
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.13 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.001 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.016 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-5-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:52	4:55	5:00	5:03
Foxboro TVA 1000	PID 0.12 ppm	PID 1.37 ppm	PID 0.03 ppm	PID 1.21 ppm
	FID 0.27 ppm	FID 3.11 ppm	FID 0.09 ppm	FID 3.46 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 3.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:10
Foxboro TVA 1000	PID 3.23 ppm
	FID 7.40 ppm
Cal.	
Mini RAE 2000	PID 11.2 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.173 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-6-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:20	9:23	9:26	9:29	9:33	9:37
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.01 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 9-6-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:10	4:15	4:20	4:23	4:28	4:32
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.09 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.03 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.03 ppm	FID 0.01 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.017 Mg/m ³	Conc. 0.111 Mg/m ³	Conc. 0.119 Mg/m ³	Conc. 0.127 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.003 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-6-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:38	4:40	4:41	4:43
Foxboro TVA 1000	PID 0.02 ppm	PID 1.11 ppm	PID 0.06 ppm	PID 1.24 ppm
	FID 0.01 ppm	FID 3.82 ppm	FID 0.00 ppm	FID 3.14 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 1.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:50
Foxboro TVA 1000	PID 3.75 ppm
	FID 11.62 ppm
Cal.	
Mini RAE 2000	PID 3.8 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.004 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.136 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-9-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	10:20		10:23		10:27		10:30		10:34		10:38	
Foxboro TVA 1000	PID 0.00 ppm		0.00		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm	
	FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.01 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm	
Gastech GT 201	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
	0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³		Conc. 0.000 Mg/m ³	

Comments:



9-9-02

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-9-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	5:05	5:06	5:08	5:10
Foxboro TVA 1000	PID 0.01 ppm	PID 1.09 ppm	PID 0.04 ppm	PID 1.13 ppm
	FID 0.00 ppm	FID 2.59 ppm	FID 0.00 ppm	FID 3.17 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:20
Foxboro TVA 1000	PID 2.95 ppm
	FID 8.78 ppm
Cal.	
Mini RAE 2000	PID 12.3 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.154 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-10-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:40	9:43	9:46	9:49	9:52	9:56
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.06 ppm	FID 0.00 ppm	FID 0.16 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.007 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.012 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
Time	3:55	4:00	4:03	4:07	4:10	4:14
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.29 ppm	FID 1.37 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.001 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.013 Ma/m ³	Conc. 0.020 Ma/m ³	Conc. 0.003 Ma/m ³	Conc. 0.005 Ma/m ³	Conc. 0.015 Mg/m ³	Conc. 0.007 Ma/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-10-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.03 ppm FID 0.00 ppm	PID 1.47 ppm FID 5.82 ppm	PID 0.02 ppm FID 0.01 ppm	PID 1.88 ppm FID 5.73 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 3.3 ppm	PID 0.0 ppm	PID 2.4 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 2.96 ppm FID 12.03 ppm
Cal.	
Mini RAE 2000	PID 4.0 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.004 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.313 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-13-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	11:15		11:18		11:23		11:28		11:32		11:36	
Foxboro TVA 1000	PID 0.12 ppm		0.00		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm		PID 0.00 ppm	
	FID 0.24 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.00 ppm		FID 0.05 ppm		FID 0.00 ppm	
Cal.												
Mini RAE 2000	PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm		PID 0.0 ppm	
Cal.												
Jerome 431-X	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X	.001 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.001 H ₂ S ppm		.000 H ₂ S ppm	
Gastech GT 201	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
	0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc. 0.033 Mg/m ³		Conc. 0.027 Mg/m ³		Conc. 0.003 Mg/m ³		Conc. 0.052 Mg/m ³		Conc. 0.028 Mg/m ³		Conc. 0.008 Mg/m ³	

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 9-13-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:40	4:43	4:47	4:50	4:54	4:58
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.009 Mg/m ³	Conc. 0.112 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.120 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.004 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-13-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	5:03	5:06	5:09	5:13
Foxboro TVA 1000	PID 0.05 ppm	PID 2.10 ppm	PID 0.02 ppm	PID 1.98 ppm
	FID 0.17 ppm	FID 6.37 ppm	FID 0.05 ppm	FID 3.87 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 1.7 ppm	PID 0.0 ppm	PID 1.5 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:20
Foxboro TVA 1000	PID 2.17 ppm
	FID 5.82 ppm
Cal.	
Mini RAE 2000	PID 2.2 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.005 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.316 Mg/m ³



9-16-02

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 9-16-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	4:05		4:08		4:12		4:15		4:20		4:25	
Foxboro TVA 1000	PID	0.06 ppm	0.00		PID	0.00 ppm	PID	0.00 ppm	PID	0.02 ppm	PID	0.00 ppm
	FID	0.13 ppm	FID	0.00 ppm	FID	0.07 ppm	FID	0.15 ppm	FID	0.18 ppm	FID	0.03 ppm
Cal.												
Mini RAE 2000	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm
Cal.												
Jerome 431-X	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³
Jerome 631-X	.001	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm
Gastech GT 201	.000	% LEL	.000	% LEL	.000	% LEL	.000	% LEL	.000	% LEL	.000	% LEL
	.0000	ppm	.0000	ppm	.0000	ppm	.0000	ppm	.0000	ppm	.0000	ppm
	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂
Cal.												
MIE PDR 1000	Conc.	0.071 Mg/m ³	Conc.	0.016 Mg/m ³	Conc.	0.005 Mg/m ³	Conc.	0.039 Mg/m ³	Conc.	0.002 Mg/m ³	Conc.	0.101 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-16-02

	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:30	4:33	4:35	4:38
Foxboro TVA 1000	PID 0.02 ppm	PID 1.05 ppm	PID 0.00 ppm	PID 2.06 ppm
	FID 0.07 ppm	FID 4.97 ppm	FID 0.03 ppm	FID 4.30 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.3 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:45
Foxboro TVA 1000	PID 1.85 ppm
	FID 3.22 ppm
Cal.	
Mini RAE 2000	PID 1.2 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.118 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-18-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	9:05	9:08	9:12	9:15	9:18	9:22
Foxboro TVA 1000	PID 0.07 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.12 ppm	FID 0.09 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.003 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.002 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-18-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:30	4:33	4:36	4:40
Foxboro TVA 1000	PID 0.07 ppm	PID 1.22 ppm	PID 0.04 ppm	PID 0.97 ppm
	FID 0.14 ppm	FID 2.39 ppm	FID 0.07 ppm	FID 1.33 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:45
Foxboro TVA 1000	PID 1.93 ppm
	FID 3.03 ppm
Cal.	
Mini RAE 2000	PID 0.4 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.176 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-19-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:45	3:50	3:53	3:57	4:02	4:05
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.004 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.098 Mg/m ³	Conc. 0.007 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-19-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:10	4:13	4:16	4:20
Foxboro TVA 1000	PID 0.06 ppm	PID 2.16 ppm	PID 0.00 ppm	PID 0.85 ppm
	FID 0.09 ppm	FID 3.04 ppm	FID 0.07 ppm	FID 1.36 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:25
Foxboro TVA 1000	PID 0.23 ppm
	FID 0.47 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.043 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-20-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:40	3:43	3:48	3:52	3:56	4:00
Foxboro TVA 1000	PID 0.13 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.02 ppm	PID 0.00 ppm
	FID 0.26 ppm	FID 0.09 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.021 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.035 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.001 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-20-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:05	4:08	4:10	4:13
Foxboro TVA 1000	PID 0.03 ppm	PID 1.44 ppm	PID 0.00 ppm	PID 1.03 ppm
	FID 0.00 ppm	FID 2.66 ppm	FID 0.00 ppm	FID 3.11 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:20
Foxboro TVA 1000	PID 0.17 ppm
	FID 0.29 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.039 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-23-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	8:50	8:53	8:56	8:59	9:04	9:07
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.02 ppm	PID 0.00 ppm
	FID 0.09 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.13 ppm	FID 0.01 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.017 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.010 Mg/m ³	Conc. 0.004 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.001 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-23-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:10	4:13	4:16	4:20
Foxboro TVA 1000	PID 0.16 ppm	PID 1.84 ppm	PID 0.01 ppm	PID 1.17 ppm
	FID 0.07 ppm	FID 3.01 ppm	FID 0.06 ppm	FID 2.85 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:25
Foxboro TVA 1000	PID 0.97 ppm
	FID 1.26 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.141 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-24-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:25	4:28	4:32	4:37	4:42	4:45
Foxboro TVA 1000	PID 0.11 ppm	0.09	PID 0.13 ppm	PID 0.01 ppm	PID 0.00 ppm	PID 0.07 ppm
	FID 0.53 ppm	FID 0.16 ppm	FID 0.07 ppm	FID 0.10 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.022 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.027 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.003 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-24-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:50	4:53	4:56	4:58
Foxboro TVA 1000	PID 0.02 ppm	PID 0.16 ppm	PID 0.01 ppm	PID 0.27 ppm
	FID 0.07 ppm	FID 0.37 ppm	FID 0.00 ppm	FID 0.06 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:05
Foxboro TVA 1000	PID 0.39 ppm
	FID 1.07 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.101 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-25-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:20	4:25	4:28	4:33	4:37	4:40
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.16 ppm	FID 0.00 ppm	FID 0.19 ppm	FID 0.00 ppm	FID 0.07 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.008 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.037 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.007 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-25-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:45	4:48	4:50	4:53
Foxboro TVA 1000	PID 0.06 ppm	PID 0.59 ppm	PID 0.04 ppm	PID 1.13 ppm
	FID 0.19 ppm	FID 1.35 ppm	FID 0.20 ppm	FID 1.93 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:58
Foxboro TVA 1000	PID 0.41 ppm
	FID 0.88 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.052 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-26-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	3:00	3:03	3:06	3:10	3:13	3:17
Foxboro TVA 1000	PID 0.00 ppm	0.09	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.17 ppm	FID 0.05 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.001 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.027 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.008 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-26-02

	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	3:25	3:28	3:30	3:32
Foxboro TVA 1000	PID 0.01 ppm	PID 1.03 ppm	PID 0.02 ppm	PID 0.81 ppm
	FID 0.05 ppm	FID 0.76 ppm	FID 0.07 ppm	FID 0.88 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	3:40
Foxboro TVA 1000	PID 1.14 ppm
	FID 3.01 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.037 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-27-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:40	4:43	4:46	4:50	4:53	4:56
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.01 ppm	PID 0.00 ppm	PID 0.03 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.007 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.112 Mg/m ³	Conc. 0.010 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-27-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	5:03	5:06	5:09	5:12
Foxboro TVA 1000	PID 0.07 ppm	PID 1.84 ppm	PID 0.01 ppm	PID 0.42 ppm
	FID 0.02 ppm	FID 1.56 ppm	FID 0.00 ppm	FID 0.09 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.1 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:15
Foxboro TVA 1000	PID 1.06 ppm
	FID 1.33 ppm
Cal.	
Mini RAE 2000	PID 1.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.018 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-30-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:05	4:08	4:12	4:15	4:18	4:23
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.005 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.103 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.004 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 9-30-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:30	4:33	4:36	4:40
Foxboro TVA 1000	PID 0.06 ppm	PID 0.97 ppm	PID 0.01 ppm	PID 1.02 ppm
	FID 0.10 ppm	FID 1.21 ppm	FID 0.05 ppm	FID 0.86 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:45
Foxboro TVA 1000	PID 0.93 ppm
	FID 1.30 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.213 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 10-1-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	3:35		3:40		3:43		3:47		3:52		3:55	
Foxboro TVA 1000	PID	0.03 ppm	0.00		PID	0.00 ppm	PID	0.00 ppm	PID	0.00 ppm	PID	0.00 ppm
	FID	0.12 ppm	FID	0.00 ppm	FID	0.00 ppm	FID	0.00 ppm	FID	0.00 ppm	FID	0.00 ppm
Cal.												
Mini RAE 2000	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm
Cal.												
Jerome 431-X	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³
Jerome 631-X	.000	H ₂ S ppm	.000	H ₂ S ppm	.001	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm
Gastech GT 201	.000	% LEL	.000	% LEL	.000	% LEL	.000	% LEL	.000	% LEL	.000	% LEL
	.0000	ppm	.0000	ppm	.0000	ppm	.0000	ppm	.0000	ppm	.0000	ppm
	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂
Cal.												
MIE PDR 1000	Conc.	0.007 Mg/m ³	Conc.	0.011 Mg/m ³	Conc.	0.002 Mg/m ³	Conc.	0.114 Mg/m ³	Conc.	0.006 Mg/m ³	Conc.	0.031 Mg/m ³

Comments:



Westgate Air Monitoring Air Filtration System

Date: 10-1-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:00	4:04	4:06	4:09
Foxboro TVA 1000	PID 0.04 ppm	PID 0.57 ppm	PID 0.00 ppm	PID 0.38 ppm
	FID 0.09 ppm	FID 0.77 ppm	FID 0.00 ppm	FID 0.62 ppm
Cal.				
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.				
Comment:				

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:15
Foxboro TVA 1000	PID 1.31 ppm
	FID 2.01 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.036 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 10-2-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	4:45	4:48	4:52	4:55	5:00	5:03
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.006 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.012 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 10-3-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	11:15	11:20	11:25	11:30	11:35	11:40
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.26 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 10-4-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	11:44	11:46	11:50	11:55	11:58	12:00
Foxboro TVA 1000	PID 0.00 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.45 ppm	FID 0.00 ppm	FID 0.06 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.004 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 10-7-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	3:20		3:21		3:25		3:30		3:33		3:39	
Foxboro TVA 1000	PID	0.00 ppm	0.00		PID	0.00 ppm	PID	0.00 ppm	PID	0.00 ppm	PID	0.00 ppm
	FID	0.00 ppm	FID	0.29 ppm	FID	0.16 ppm	FID	0.00 ppm	FID	0.00 ppm	FID	0.00 ppm
Cal.												
Mini RAE 2000	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm
Cal.												
Jerome 431-X	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³
Jerome 631-X	.000	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm
Gastech GT 201	000	% LEL	000	% LEL	000	% LEL	000	% LEL	000	% LEL	000	% LEL
	0000	ppm	0000	ppm	0000	ppm	0000	ppm	0000	ppm	0000	ppm
	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂
Cal.												
MIE PDR 1000	Conc.	0.002 Mg/m ³	Conc.	0.007 Mg/m ³	Conc.	0.011 Mg/m ³	Conc.	0.007 Mg/m ³	Conc.	0.003 Mg/m ³	Conc.	0.000 Mg/m ³

Comments:



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
Time	2:55	3:00	3:02	3:05	3:10	3:13
Foxboro TVA 1000	PID 0.03 ppm	0.00	PID 0.00 ppm	PID 0.00 ppm	PID 0.01 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.07 ppm	FID 0.18 ppm	FID 0.20 ppm	FID 0.09 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.002 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.001 Mg/m ³

Comments:

Comments:



10-9-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point #6 Background - GMW-7
	1:55	1:58	2:03	2:07	2:11	2:14
Foxboro TVA 1000	PID 0.00 ppm	0.06	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.09 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.017 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.020 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 10-10-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	2:30		2:32		2:36		2:40		2:44		2:50	
Foxboro TVA 1000	PID	0.40 ppm	0.50		PID	0.42 ppm	PID	0.09 ppm	PID	0.19 ppm	PID	0.24 ppm
	FID	0.51 ppm	FID	0.56 ppm	FID	0.57 ppm	FID	0.00 ppm	FID	0.00 ppm	FID	0.00 ppm
Cal.												
Mini RAE 2000	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm
Cal.												
Jerome 431-X	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³	.000	Hg Mg/m ³
Jerome 631-X	.000	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm	.000	H ₂ S ppm
Gastech GT 201	000	% LEL	000	% LEL	000	% LEL	000	% LEL	000	% LEL	000	% LEL
	0000	ppm	0000	ppm	0000	ppm	0000	ppm	0000	ppm	0000	ppm
	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂	20.9	%O ₂
Cal.												
MIE PDR 1000	Conc.	0.007 Mg/m ³	Conc.	0.000 Mg/m ³	Conc.	0.001 Mg/m ³	Conc.	0.000 Mg/m ³	Conc.	0.000 Mg/m ³	Conc.	0.000 Mg/m ³

Comments:



Westgate Air Monitoring Westgate Neighborhood

Date: 10-11-02

Time	Sample Point #1 1701 San Andres		Sample Point #2 1412 Berry		Sample Point #3 1401 Tasker		Sample Point #4 GMW-10		Sample Point #5 Bus Turn-a-round		Sample Point #6 Background - GMW-7	
	3:00		3:05		3:08		3:12		3:15		3:20	
Foxboro TVA 1000	PID	0.00 ppm	0.00		PID	0.00 ppm	PID	0.00 ppm	PID	0.00 ppm	PID	0.00 ppm
	FID	0.00 ppm	FID	0.07 ppm	FID	0.00 ppm	FID	0.00 ppm	FID	0.00 ppm	FID	0.00 ppm
Cal.												
Mini RAE 2000	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm	PID	0.0 ppm
Cal.												
Jerome 431-X		.000 Hg Mg/m ³	.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³		.000 Hg Mg/m ³	
Jerome 631-X		.000 H ₂ S ppm	.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm		.000 H ₂ S ppm	
Gastech GT 201		000 % LEL	000 % LEL		000 % LEL		000 % LEL		000 % LEL		000 % LEL	
		0000 ppm	0000 ppm		0000 ppm		0000 ppm		0000 ppm		0000 ppm	
		20.9 %O ₂	20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂		20.9 %O ₂	
Cal.												
MIE PDR 1000	Conc.	0.000 Mg/m ³	Conc.	0.000 Mg/m ³	Conc.	0.000 Mg/m ³	Conc.	0.000 Mg/m ³	Conc.	0.000 Mg/m ³	Conc.	0.000 Mg/m ³

Comments:

APPENDIX V

Westgate Walk-A-Round Air Monitoring Data

Field Copy

March – October 2002

Westgate Stage 2 Abatement Plan- Remediation Activities Report Hobbs, New Mexico

Prepared for:

Shell Exploration & Production Company
Houston, Texas

May 2003

Prepared by:

BBC International, Inc.



Westgate Air Monitoring Westgate Neighborhood

Date: 4-15-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	9:15	9:17	9:20	9:24	9:28	9:33
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³
Jerome 631-X	000 H ₂ S ppm	000 H ₂ S ppm	000 H ₂ S ppm	000 H ₂ S ppm	000 H ₂ S ppm	000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Date: 4-15-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	4:45	4:50	4:56	5:01	5:05	5:15
Foxboro TVA 1000	PID 0.00 ppm	PID 0.06 ppm	PID 0.02 ppm	PID 0.72 ppm	PID 0.06 ppm	PID 0.12 ppm
	FID 0.60 ppm	FID 0.00 ppm	FID 0.06 ppm	FID 0.14 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.6 ppm	PID 0.00 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.060 Hg Mg/m ³	0.060 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.002 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.002 H ₂ S ppm	0.002 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.060 Mg/m ³	Conc. 0.060 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 4-15-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.03 ppm	PID 0.98 ppm		PID 0.04 ppm	PID 1.31 ppm
	FID 0.10 ppm	FID 1.32 ppm		FID 0.07 ppm	FID 1.96 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 2.73 ppm
	FID 7.17 ppm
Cal.	
Mini RAE 2000	PID 3.2 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.216 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-16-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	9:15	9:18	9:22	9:27	9:32	9:35
Foxboro TVA 1000	PID 0.09 ppm	PID 0.07 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.13 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.006 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.002 H ₂ S ppm	0.006 H ₂ S ppm	0.001 H ₂ S ppm	0.002 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.011 Mg/m ³	Conc. 0.073 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 4-16-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:50	4:53	4:56	5:00	5:04	5:09
Foxboro TVA 1000	PID 0.13 ppm	PID 0.06 ppm	PID 0.11 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.07 ppm	FID 0.00 ppm	FID 0.07 ppm	FID 0.00 ppm	FID 0.03 ppm	FID 0.00 ppm
Cal: 6-17-02						
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal: 6-17-02						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal: 6-17-02						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments



Westgate Air Monitoring Air Filtration System

Date: 4-16-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	5:13	5:16		5:20	5:23
Foxboro TVA 1000	PID 0.02 ppm	PID 1.08 ppm		PID 0.07 ppm	PID 1.45 ppm
	FID 0.000 ppm	FID 5.60 ppm		FID 0.00 ppm	FID 6.30 ppm
Cal.					
Mini RAE 2000	PID 0.1 ppm	PID 2.5 ppm		PID 0.0 ppm	PID 3.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:30
Foxboro TVA 1000	PID 3.90 ppm
	FID 14.00 ppm
Cal.	
Mini RAE 2000	PID 5.9 ppm
Cal.	
Jerome 431-X	0.000 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.33 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-17-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	9:20	9:23	9:26	9:30	9:34	9:40
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.69 ppm	PID 0.11 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.72 ppm	FID 0.69 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.005 Mg/m ³	Conc. 0.173 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.453 Mg/m ³	Conc. 0.112 Mg/m ³	Conc. 0.333 Mg/m ³

Comments

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 4-17-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:00	4:03		4:05	4:08
Foxboro TVA 1000	PID 0.07 ppm	PID 0.97 ppm		PID 0.02 ppm	PID 1.31 ppm
	FID 0.04 ppm	FID 2.13 ppm		FID 0.06 ppm	FID 3.06 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:15
Foxboro TVA 1000	PID 3.98 ppm
	FID 12.42 ppm
Cal.	
Mini RAE 2000	PID 6.1 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.004 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.306 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-18-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	10:05	10:10	10:13	10:17	10:20	10:23
Foxboro TVA 1000	PID 0.01 ppm	PID 0.67 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.03 ppm
	FID 0.00 ppm	FID 0.01 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.02 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm
Gastech GT 201	0.06 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.007 Mg/m ³	Conc. 0.072 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments



Westgate Air Monitoring Westgate Neighborhood

Date: 4-18-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	3:45	3:48	3:52	3:55	3:58	4:03
Foxboro TVA 1000	PID 0.00 ppm	PID 0.11 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.03 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.7 %O ₂	20.9 %O ₂	20.7 %O ₂	20.7 %O ₂	20.7 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.007 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 4-18-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:10	4:13		4:17	4:20
Foxboro TVA 1000	PID 0.00 ppm	PID 0.11 ppm		PID 0.05 ppm	PID 0.09 ppm
	FID 0.00 ppm	FID 0.07 ppm		FID 0.01 ppm	FID 0.03 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:25
Foxboro TVA 1000	PID 0.16 ppm
	FID 0.11 ppm
Cal.	
Mini RAE 2000	PID 0.2 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 % O ₂
Cal.	
MIE PDR 1000	Conc. 0.01 Mg/m ³



Date: 4-19-02

[illegible]



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	2:45	2:48	2:51	2:54	3:00	3:03
Foxboro TVA 1000	PID 0.07 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.12 ppm	PID 0.00 ppm
	FID 0.04 ppm	FID 0.00 ppm	FID 0.60 ppm	FID 0.00 ppm	FID 0.03 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	Hg Mg/m ³	Hg Mg/m ³	Hg Mg/m ³	Hg Mg/m ³	Hg Mg/m ³	Hg Mg/m ³
Jerome 631-X	H ₂ S ppm	H ₂ S ppm	H ₂ S ppm	H ₂ S ppm	H ₂ S ppm	H ₂ S ppm
Gastech GT 201	% LEL	% LEL	% LEL	% LEL	% LEL	% LEL
	ppm	ppm	ppm	ppm	ppm	ppm
	%O ₂	%O ₂	%O ₂	%O ₂	%O ₂	%O ₂
Cal.						
MIE PDR 1000	Conc. 0.006 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.009 Mg/m ³
Comments						



BBC INTERNATIONAL

Westgate Air Monitoring Air Filtration System

Date: 4-19-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	3:10	3:13		3:16	3:18
Foxboro TVA 1000	PID 0.07 ppm	PID 0.10 ppm		PID 0.00 ppm	PID 0.00 ppm
	FID 0.30 ppm	FID 0.60 ppm		FID 0.02 ppm	FID 0.00 ppm
Cal.					
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm		PID 0.1 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	3:25
Foxboro TVA 1000	PID 0.17 ppm
	FID 0.10 ppm
Cal.	
Mini RAE 2000	PID 0.2 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 % O ₂
Cal.	
MIE PDR 1000	Conc. 0.00 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
Time	10:10	16:13	10:17	10:20	10:24	10:28
Foxboro TVA 1000	PID 0.01 ppm	PID 0.00 ppm	PID 0.63 ppm	PID 0.01 ppm	PID 0.00 ppm	PID 0.03 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 6.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.61 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	1.00 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.600 Hg Mg/m ³	.550 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	1.00 H ₂ S ppm	.006 H ₂ S ppm	.001 H ₂ S ppm	.662 H ₂ S ppm	.060 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc 0.00 Mg/m ³	Conc 0.000 Mg/m ³	Conc 0.000 Mg/m ³	Conc 0.001 Mg/m ³	Conc 0.001 Mg/m ³	Conc .0007 Mg/m ³
Comments						

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 4-22-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	5:05	5:08		5:11	5:14
Foxboro TVA 1000	PID 0.01 ppm	PID 0.06 ppm		PID 0.00 ppm	PID 0.07 ppm
	FID 0.00 ppm	FID 0.00 ppm		FID 0.00 ppm	FID 0.01 ppm
Cal.					
Mini RAE 2000	PID 0.1 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:20
Foxboro TVA 1000	PID 0.00 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	000 Hg Mg/m ³
Jerome 631-X	000 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³



Date: 4-23-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	9:15	9:18	9:22	9:27	9:30	9:33
Foxboro TVA 1000	PID 0.00 ppm	PID 0.01 ppm	PID 0.07 ppm	PID 0.01 ppm	PID 0.07 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.42 ppm	FID 0.13 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.02 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.011 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Date: 4-23-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	4:05	4:10	4:13	4:17	4:20	4:24
Foxboro TVA 1000	PID 0.00 ppm	PID 6.06 ppm	PID 0.61 ppm	PID 8.06 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.6 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.05 Hg Mg/m ³	0.00 Hg Mg/m ³	0.06 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.02 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.006 ppm	0.006 ppm	0.006 ppm	0.006 ppm	0.006 ppm	0.006 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
IMIE PDR 1000	Conc. 0.001 Mg/m ³	Conc. 0.012 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 4-23-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:30	4:33		4:36	4:40
Foxboro TVA 1000	PID 0.47 ppm	PID 0.66 ppm		PID 0.10 ppm	PID 0.17 ppm
	FID 1.21 ppm	FID 0.97 ppm		FID 0.03 ppm	FID 0.00 ppm
Cal.					
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm		PID 0.1 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:45
Foxboro TVA 1000	PID 0.67 ppm
	FID 0.23 ppm
Cal.	
Mini RAE 2000	PID 0.3 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	0.20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.111 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	9:50	9:54	9:58	10:03	10:06	10:10
Foxboro TVA 1000	PID 0.11 ppm	PID 0.05 ppm	PID 0.66 ppm	PID 0.00 ppm	PID 0.66 ppm	PID 0.00 ppm
	FID 0.62 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.6 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	-0.00 Hg Mg/m ³	-0.00 Hg Mg/m ³	-0.00 Hg Mg/m ³	-0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.01 H ₂ S ppm	-0.01 H ₂ S ppm	-0.00 H ₂ S ppm	-0.00 H ₂ S ppm	-0.02 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.213 Mg/m ³	Conc. 0.079 Mg/m ³	Conc. 0.119 Mg/m ³	Conc. 0.106 Mg/m ³	Conc. 0.071 Mg/m ³	Conc. 0.016 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 4-24-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	3:20	3:23	3:27	3:30	3:34	3:38
Foxboro TVA 1000	PID 0.00 ppm	PID 0.09 ppm	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.01 ppm	FID 0.13 ppm	FID 0.16 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.002 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.0000 ppm	0.0000 ppm	0.0000 ppm	0.0000 ppm	0.0000 ppm	0.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc 0.000 Mg/m ³	Conc 0.009 Mg/m ³	Conc 0.076 Mg/m ³	Conc 0.000 Mg/m ³	Conc 0.017 Mg/m ³	Conc 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 4-24-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	3:44	3:47		3:50	3:52
Foxboro TVA 1000	PID 0.13 ppm	PID 0.00 ppm		PID 0.17 ppm	PID 0.21 ppm
	FID 1.16 ppm	FID 1.00 ppm		FID 0.64 ppm	FID 0.13 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.1 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
3:57	
Foxboro TVA 1000	PID 0.06 ppm
	FID 0.92 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	26.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.000 Mg/m ³



Date: 4-25-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	8:48	8:56	9:04	9:13	9:24	9:31
Foxboro TVA 1000	PID 0.07 ppm	PID 0.04 ppm	PID 0.02 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.02 ppm
	FID 1.20 ppm	FID 1.60 ppm	FID 1.35 ppm	FID 1.29 ppm	FID 1.11 ppm	FID 1.52 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000Mg/m ³	Conc. 0.000Mg/m ³	Conc. 0.000Mg/m ³	Conc. 0.000Mg/m ³	Conc. 0.000Mg/m ³	Conc. 0.000Mg/m ³
Comments						

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 4-25-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	5:00	5:04		5:08	5:15
Foxboro TVA 1000	PID 0.05 ppm	PID 0.13 ppm		PID 0.06 ppm	PID 0.31 ppm
	FID 0.12 ppm	FID 2.00 ppm		FID 0.27 ppm	FID 1.18 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:25
Foxboro TVA 1000	PID 0.36 ppm
	FID 1.33 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.15 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.43 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-26-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	9:50 a.m.	10:05	10:11	10:16	10:23	10:30
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 2.42 ppm	FID 1.92 ppm	FID 1.32 ppm	FID 0.85 ppm	FID 1.59 ppm	FID 1.94 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.006 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.006 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.006 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	21.0 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	light wind from S.W.					



Westgate Air Monitoring Westgate Neighborhood

Date: 4-26-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	3:26	3:34	3:44	3:55	4:01	4:10
Foxboro TVA 1000	PID 0.04 ppm	PID 0.02 ppm	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 1.24 ppm	FID 1.62 ppm	FID 1.33 ppm	FID 1.32 ppm	FID 1.19 ppm	FID 0.89 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.040 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.8 %O ₂	20.7 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments light wind from S.W.



Westgate Air Monitoring Air Filtration System

Date: 4-26-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:15	4:16		4:18	4:20
Foxboro TVA 1000	PID 0.06 ppm	PID 0.12 ppm		PID 0.03 ppm	PID 0.22 ppm
	FID 1.55 ppm	FID 1.35 ppm		FID 1.15 ppm	FID 2.52 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.3 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Sample Point Inside Structure	
Time 4:33	
Foxboro TVA 1000	PID 0.20 ppm
	FID 1.36 ppm
Cal.	
Mini RAE 2000	PID 0.4 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.23 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.8 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-29-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Foxboro TVA 1000	10:29 PID 0.60 ppm FID 1.54 ppm	10:35 PID 0.59 ppm FID 1.32 ppm	10:40 PID 0.59 ppm FID 1.31 ppm	10:45 PID 0.54 ppm FID 0.92 ppm	10:50 PID 0.51 ppm FID 0.77 ppm	10:58 PID 0.50 ppm FID 0.90 ppm
Cal. 4-29-02						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal. 4-29-02						
Jerome 431-X	0.000 Hg Mg/m ³ 0.002 H ₂ S ppm 0.00 % LEL	0.000 Hg Mg/m ³ 0.002 H ₂ S ppm 0.00 % LEL	0.000 Hg Mg/m ³ 0.000 H ₂ S ppm 0.00 % LEL	0.000 Hg Mg/m ³ 0.001 H ₂ S ppm 0.00 % LEL	0.006 Hg Mg/m ³ 0.061 H ₂ S ppm 0.00 % LEL	0.000 Hg Mg/m ³ 0.061 H ₂ S ppm 0.00 % LEL
Jerome 631-X	0.000 Hg Mg/m ³ 0.002 H ₂ S ppm 0.00 % LEL	0.000 Hg Mg/m ³ 0.002 H ₂ S ppm 0.00 % LEL	0.000 Hg Mg/m ³ 0.000 H ₂ S ppm 0.00 % LEL	0.000 Hg Mg/m ³ 0.001 H ₂ S ppm 0.00 % LEL	0.006 Hg Mg/m ³ 0.061 H ₂ S ppm 0.00 % LEL	0.000 Hg Mg/m ³ 0.061 H ₂ S ppm 0.00 % LEL
Gastech GT 201	0.000 Hg Mg/m ³ 0.002 H ₂ S ppm 0.00 % LEL	0.000 Hg Mg/m ³ 0.002 H ₂ S ppm 0.00 % LEL	0.000 Hg Mg/m ³ 0.000 H ₂ S ppm 0.00 % LEL	0.000 Hg Mg/m ³ 0.001 H ₂ S ppm 0.00 % LEL	0.006 Hg Mg/m ³ 0.061 H ₂ S ppm 0.00 % LEL	0.000 Hg Mg/m ³ 0.061 H ₂ S ppm 0.00 % LEL
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	wind from the west 10-13 mph					



Date: 4-29-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	2:49	2:55	3:00	3:07	3:14	3:20
Foxboro TVA 1000	PID 0.41 ppm	PID 0.43 ppm	PID 0.43 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.15 ppm	FID 0.00 ppm	FID 0.38 ppm	FID 0.28 ppm	FID 0.72 ppm	FID 0.92 ppm
Cal. 4-29-02						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal. 4-29-02						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.002 H ₂ S ppm	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.49 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 4-29-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	3:30	3:32		3:34	3:36
Foxboro TVA 1000	PID 0.76 ppm	PID 0.87 ppm		PID 0.14 ppm	PID 0.68 ppm
	FID 0.97 ppm	FID 1.50 ppm		FID 1.71 ppm	FID 1.53 ppm
Cal. 4-25-02					
Mini RAE 2000	PID 0.3 ppm	PID 0.5 ppm		PID 0.0 ppm	PID 0.3 ppm
Cal. 4-29-02					
Comment: Winds Calm					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	3:52
Foxboro TVA 1000	PID 0.30 ppm
	FID 0.00 ppm
Cal. 4-29-02	
Mini RAE 2000	PID 0.0 ppm
Cal. 4-29-02	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.012 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.000 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 4-30-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	11:25	11:36	11:35	11:40	11:44	11:48
Foxboro TVA 1000	PID 0.06 ppm	PID 0.05 ppm	PID 0.05 ppm	PID 0.03 ppm	PID 0.03 ppm	PID 0.01 ppm
	FID 1.20 ppm	FID 1.78 ppm	FID 0.72 ppm	FID 1.63 ppm	FID 1.23 ppm	FID 0.40 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.002 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	windy, winds coming from the west, 16 mph.					



Westgate Air Monitoring Westgate Neighborhood

Date: 4-30-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	3:00 p.m.	3:10 p.m.	3:15 p.m.	3:20 p.m.	3:27 p.m.	3:35 p.m.
Foxboro TVA 1000	PID 0.03 ppm	PID 0.04 ppm	PID 0.03 ppm	PID 0.01 ppm	PID 0.01 ppm	PID 0.00 ppm
	FID 1.40 ppm	FID 1.45 ppm	FID 1.82 ppm	FID 1.63 ppm	FID 1.28 ppm	FID 0.75 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.002 H ₂ S ppm	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.8 %O ₂	20.8 %O ₂	20.8 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	WS 20-25 mph. out of the West.					



Westgate Air Monitoring Air Filtration System

Date: 4-30-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.05 ppm 3:50 p.m.	PID 0.33 ppm 3:53 p.m.		PID 0.06 ppm 3:40 p.m.	PID 0.36 ppm 3:45 p.m.
Cal.	FID 0.32 ppm	FID 2.09 ppm		FID 0.39 ppm	FID 1.22 ppm
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.37 ppm 4:00
Cal.	FID 1.56 ppm
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.15 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 % O ₂
Cal.	
MIE PDR 1000	Cond. 0.392 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-1-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	10:36	10:41	10:47	10:52	10:57	11:04
Foxboro TVA 1000	PID 0.68 ppm	PID 0.08 ppm	PID 0.05 ppm	PID 0.04 ppm	PID 0.03 ppm	PID 0.04 ppm
	FID 1.86 ppm	FID 1.88 ppm	FID 1.98 ppm	FID 1.77 ppm	FID 0.99 ppm	FID 1.67 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.060 Hg Mg/m ³	0.06 Hg Mg/m ³	0.060 Hg Mg/m ³	0.060 Hg Mg/m ³	0.060 Hg Mg/m ³	0.060 Hg Mg/m ³
Jerome 631-X	0.060 H ₂ S ppm	0.061 H ₂ S ppm	0.061 H ₂ S ppm	0.061 H ₂ S ppm	0.066 H ₂ S ppm	0.062 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.006 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.009 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.033 Mg/m ³	Conc. 0.340 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	winds 20mph winds out of the west					



Westgate Air Monitoring Westgate Neighborhood

Date: 5-1-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	2:55	3:00	3:06	3:10	3:14	3:19
Foxboro TVA 1000	PID 0.11 ppm	PID 0.10 ppm	PID 0.09 ppm	PID 0.09 ppm	PID 0.08 ppm	PID 0.08 ppm
	FID 2.62 ppm	FID 2.52 ppm	FID 1.92 ppm	FID 2.02 ppm	FID 2.11 ppm	FID 1.89 ppm
Cal.						
Mini RAE 2000	PID 0.6 ppm	PID 0.0 ppm	PID 0.6 ppm	PID 0.6 ppm	PID 0.6 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc 0.000 Mg/m ³	Conc 0.094 Mg/m ³	Conc 0.000 Mg/m ³	Conc 0.032 Mg/m ³	Conc 0.000 Mg/m ³	Conc 0.000 Mg/m ³

Comments Wind - straight out of the west
winds at 22mph.



Westgate Air Monitoring Air Filtration System

Date: 5-1-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.15 ppm	PID 0.46 ppm		PID 0.15 ppm	PID 0.53 ppm
	FID 1.85 ppm	FID 2.42 ppm		FID 1.53 ppm	FID 2.25 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.3 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
3:35	
Foxboro TVA 1000	PID 0.21 ppm
	FID 1.92 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	000 Hg Mg/m ³
Jerome 631-X	0.015 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.335 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-2-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	10:10	10:15	10:18	10:23	10:27	10:31
Foxboro TVA 1000	PID 0.24 ppm	PID 0.23 ppm	PID 0.22 ppm	PID 0.23 ppm	PID 0.20 ppm	PID 0.19 ppm
	FID 3.43 ppm	FID 3.40 ppm	FID 2.80 ppm	FID 2.98 ppm	FID 2.88 ppm	FID 2.91 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.600 Hg Mg/m ³	0.600 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	1.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 5-2-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:43	4:48	4:53	4:58	5:02	5:10
Foxboro TVA 1000	PID 0.18 ppm	PID 0.16 ppm	PID 0.16 ppm	PID 0.14 ppm	PID 0.12 ppm	PID 0.12 ppm
	FID 3.20 ppm	FID 2.49 ppm	FID 1.97 ppm	FID 3.23 ppm	FID 2.40 ppm	FID 2.51 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.005 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 5-2-07

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	5:14	5:15		5:17	5:19
Foxboro TVA 1000	PID 0.15 ppm	PID 0.35 ppm		PID 0.17 ppm	PID 0.33 ppm
	FID 2.55 ppm	FID 3.03 ppm		FID 1.90 ppm	FID 3.36 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Sample Point Inside Structure	
Time 5:20	
Foxboro TVA 1000	PID 0.32 ppm
	FID 2.68 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	0.000 Hg Mg/m ³
Jerome 631-X	0.016 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	26.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.016 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	10:07	10:12	10:16	10:21	10:26	10:31
Foxboro TVA 1000	PID 0.00 ppm	PID 0.06 ppm	PID 0.06 ppm	PID 0.06 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.66 ppm	FID 0.26 ppm	FID 0.66 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.04 Hg Mg/m ³	0.00 Hg Mg/m ³	0.03 Hg Mg/m ³	0.63 Hg Mg/m ³	0.06 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.06 H ₂ S ppm	0.00 H ₂ S ppm	0.06 H ₂ S ppm	0.61 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.06 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 5-3-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Foxboro TVA 1000	4:02 PID 0.00 ppm FID 0.10 ppm	4:06 PID 0.00 ppm FID 0.00 ppm	4:14 PID 0.00 ppm FID 0.00 ppm	4:19 PID 0.00 ppm FID 0.00 ppm	4:26 PID 0.00 ppm FID 0.00 ppm	4:31 PID 0.00 ppm FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³
Jerome 631-X	000 H ₂ S ppm	000 H ₂ S ppm	000 H ₂ S ppm	000 H ₂ S ppm	000 H ₂ S ppm	000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	000 ppm	000 ppm	000 ppm	000 ppm	000 ppm	000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	wind at 6 mph. direction SW					



Westgate Air Monitoring Air Filtration System

Date: 5-3-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
4:36		4:37		4:38	4:40
Foxboro TVA 1000	PID 0.75 ppm	PID 0.22 ppm		PID 0.03 ppm	PID 0.52 ppm
	FID 0.00 ppm	FID 0.32 ppm		FID 0.42 ppm	FID 0.92 ppm
Cal.					
Mini RAE 2000	PID 0.00 ppm	PID 0.00 ppm		PID 0.00 ppm	PID 0.4 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Sample Point Inside Structure	
Time 4:46	
Foxboro TVA 1000	PID 0.27 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	000 Hg Mg/m ³
Jerome 631-X	000 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.192 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	2:10	2:15	2:20	2:24	2:27	2:33
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal. 5-6-02						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal. 5-6-02						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000Mg/m ³	Conc. 0.000Mg/m ³	Conc. 0.000Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 5.06.02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:43	4:49	4:55	5:00	5:05	5:10
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	10.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	Wind Speed - 29 mph Wind direction out of the Southwest					



Westgate Air Monitoring Air Filtration System

Date: 5.06.02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	5:12	5:15		5:17	5:19
Foxboro TVA 1000	PID 0.008 ppm	PID 0.18 ppm		PID 0.05 ppm	PID 0.18 ppm
	FID 0.008 ppm	FID 0.42 ppm		FID 0.00 ppm	FID 0.00 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.5 ppm		PID 0.0 ppm	PID 0.3 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:25
Foxboro TVA 1000	PID 0.13 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.9 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.03 H ₂ S ppm
Gastech GT 201	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.033 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-7-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	10:00	10:04	10:09	10:14	10:19	10:22
Foxboro TVA 1000	PID 0.04 ppm	PID 0.04 ppm	PID 0.06 ppm	PID 0.06 ppm	PID 0.01 ppm	PID 0.00 ppm
	FID 0.87 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.14 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.002 H ₂ S ppm	0.002 H ₂ S ppm	0.02 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.002 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	wind speed 20 mph out of west					



Westgate Air Monitoring Westgate Neighborhood

Date: 5.7.02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:30	4:35	4:40	4:45	4:50	4:56
Foxboro TVA 1000	PID 0.01 ppm	PID 0.00 ppm	PID 0.12 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.013 Mg/m ³	Conc. 0.023 Mg/m ³	Conc. 0.024 Mg/m ³	Conc. 0.119 Mg/m ³	Conc. 0.139 Mg/m ³	Conc. 0.186 Mg/m ³
Comments	winds from the southwest at 27 mph.					



Westgate Air Monitoring Air Filtration System

Date: 05-07-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:58	5:00		5:03	5:05
Foxboro TVA 1000	PID 0.00 ppm	PID 0.22 ppm		PID 0.00 ppm	PID 0.23 ppm
	FID 0.00 ppm	FID 0.46 ppm		FID 0.00 ppm	FID 0.49 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.09 ppm		PID 0.0 ppm	PID 0.8 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:10
Foxboro TVA 1000	PID 0.26 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.4 ppm
Cal.	
Jerome 431-X	000 Hg Mg/m ³
Jerome 631-X	004 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.34 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-8-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Foxboro TVA 1000	10:50 PID 0.00 ppm FID 0.00 ppm	10:54 PID 0.66 ppm FID 0.00 ppm	10:59 PID 0.60 ppm FID 0.00 ppm	11:02 PID 0.00 ppm FID 0.00 ppm	11:08 PID 0.00 ppm FID 0.00 ppm	11:12 PID 0.00 ppm FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	Wind speed 19 mph Winds out of South West					



Westgate Air Monitoring Westgate Neighborhood

Date: 5.08.02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:30	4:35	4:40	4:45	4:50	4:55
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.0034 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.177 Mg/m ³	Conc. 0.526 Mg/m ³	Conc. 0.032 Mg/m ³	Conc. 0.105 Mg/m ³

Comments Winds from the South West at 24 mph.



Westgate Air Monitoring Air Filtration System

Date: 5-18-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.00 ppm	PID 0.09 ppm		PID 0.00 ppm	PID 0.07 ppm
	FID 0.00 ppm	FID 0.60 ppm		FID 0.05 ppm	FID 0.23 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.2 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.26 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.5 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm
Gastech GT 201	
	100 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.47 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5.09.02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	12:03	12:08	12:12	12:17	12:22	12:26
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.02 H ₂ S ppm	0.01 H ₂ S ppm	0.02 H ₂ S ppm	0.01 H ₂ S ppm	0.02 H ₂ S ppm	0.01 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	10.9 %O ₂	10.9 %O ₂	10.9 %O ₂	10.9 %O ₂	10.9 %O ₂	10.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.172 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.144 Mg/m ³	Conc. 0.146 Mg/m ³	Conc. 0.075 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	winds from the Northeast at 15 mph.					



Westgate Air Monitoring Westgate Neighborhood

Date: 5.09.02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	4:43	4:48	4:52	4:56	4:59	5:03
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.002 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.002 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.178 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.123 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	winds from the southeast at 8 mph.					



Westgate Air Monitoring Air Filtration System

Date: 5-09-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.00 ppm	PID 0.08 ppm		PID 0.00 ppm	PID 0.07 ppm
	FID 0.00 ppm	FID 0.57 ppm		FID 0.00 ppm	FID 0.23 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.2 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.24 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.5 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.03 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.570 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 05.10.02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	11:37	11:41	11:45	11:49	11:54	11:58
Foxboro TVA 1000	PID 1.74 ppm	PID 1.28 ppm	PID 0.70 ppm	PID 0.89 ppm	PID 0.70 ppm	PID 0.78 ppm
	FID 0.70 ppm	FID 0.10 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments *winds from the southeast at 17 mph.*



Westgate Air Monitoring Westgate Neighborhood

Date: 05.10.02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	3:58	4:01	4:05	4:09	4:14	4:17
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	winds from the southeast at 10 mph					



Westgate Air Monitoring Air Filtration System

Date: 05/01/07

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:20	4:23		4:25	4:27
Foxboro TVA 1000	PID 0.00 ppm	PID 0.07 ppm		PID 0.00 ppm	PID 0.06 ppm
	FID 0.00 ppm	FID 0.48 ppm		FID 0.00 ppm	FID 0.20 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:30
Foxboro TVA 1000	PID 0.57 ppm
	FID 1.77 ppm
Cal.	
Mini RAE 2000	PID 1.3 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.442 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	4:11	4:25	4:19	4:22	4:25	4:28
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.02 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.55 ppm	FID 0.33 ppm	FID 0.39 ppm	FID 0.98 ppm	FID 0.21 ppm	FID 0.09 ppm
Cal.						
Mini RAE 2000	PID 0.00 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIF PDR 1000	Conc 0.170 Ma/m ³	Conc. 0.003 Ma/m ³	Conc. 0.000 Ma/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments



Westgate Air Monitoring Air Filtration System

Date: 5-16-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:30	4:32		4:34	4:37
Foxboro TVA 1000	PID 0.09 ppm	PID 0.37 ppm		PID 0.12 ppm	PID 0.36 ppm
	FID 0.12 ppm	FID 0.12 ppm		FID 0.20 ppm	FID 0.10 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:42
Foxboro TVA 1000	PID 0.13 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.24 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.006 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.356 Mg/m ³

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 5-17-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:45	4:47		4:50	4:54
Foxboro TVA 1000	PID 0.06 ppm	PID 0.16 ppm		PID 0.11 ppm	PID 0.27 ppm
	FID 0.13 ppm	FID 0.12 ppm		FID 0.00 ppm	FID 0.09 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:00
Foxboro TVA 1000	PID 0.13 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.12 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.012 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 05.20.02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	3:45	3:50	3:54	3:59	4:03	4:18
Foxboro TVA 1000	PID 0.19 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.89 ppm	PID 0.19 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 1.07 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.4 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.084 Mg/m ³	Conc. 0.070 Mg/m ³	Conc. 0.119 Mg/m ³	Conc. 0.177 Mg/m ³	Conc. 0.172 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	winds from the southeast at 22 mph.					



Westgate Air Monitoring Air Filtration System

Date: 15-2012

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:11	4:14		4:16	4:18
Foxboro TVA 1000	PID 0.05 ppm	PID 0.33 ppm		PID 0.06 ppm	PID 0.36 ppm
	FID 0.39 ppm	FID 2.09 ppm		FID 0.39 ppm	FID 1.20 ppm
Cal.					
Mini RAE 2000	PID 1.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:22
Foxboro TVA 1000	PID 0.13 ppm
	FID 0.01 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.024 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.256 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-21-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:15	4:19	4:24	4:30	4:34	4:38
Foxboro TVA 1000	PID 0.22 ppm	PID 0.21 ppm	PID 0.17 ppm	PID 0.18 ppm	PID 0.07 ppm	PID 0.19 ppm
	FID 0.97 ppm	FID 0.90 ppm	FID 0.09 ppm	FID 0.07 ppm	FID 0.19 ppm	FID 0.05 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.02 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.198 Mg/m ³	Conc. 0.189 Mg/m ³	Conc. 0.176 Mg/m ³	Conc. 0.179 Mg/m ³	Conc. 0.192 Mg/m ³	Conc. 0.181 Mg/m ³

Comments



Westgate Air Monitoring Air Filtration System

Date: 5-21-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.04 ppm	PID 0.29 ppm		PID 0.06 ppm	PID 0.37 ppm
	FID 0.28 ppm	FID 2.00 ppm		FID 0.17 ppm	FID 1.20 ppm
Cal.					
Mini RAE 2000	PID 0.2 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.30 ppm
	FID 0.44 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.02 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.533 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-22-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:18	4:22	4:27	4:32	4:37	4:43
Foxboro TVA 1000	PID 0.11 ppm	PID 0.12 ppm	PID 0.09 ppm	PID 0.29 ppm	PID 0.17 ppm	PID 0.08 ppm
	FID 0.17 ppm	FID 0.20 ppm	FID 0.04 ppm	FID 0.36 ppm	FID 0.22 ppm	FID 0.03 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.0000 ppm	0.0000 ppm	0.0000 ppm	0.0000 ppm	0.0000 ppm	0.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.102 Mg/m ³	Conc. 1.107 Mg/m ³	Conc. 0.109 Mg/m ³	Conc. 0.112 Mg/m ³	Conc. 0.107 Mg/m ³	Conc. 0.115 Mg/m ³
Comments	Winds from the south at 20 mph.					



Westgate Air Monitoring Air Filtration System

Date: 5-22-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:48	4:52		4:56	4:58
Foxboro TVA 1000	PID 0.03 ppm	PID 0.19 ppm		PID 0.04 ppm	PID 0.22 ppm
	FID 0.20 ppm	FID 0.00 ppm		FID 0.20 ppm	FID 1.09 ppm
Cal.					
Mini RAE 2000	PID 0.1 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:03
Foxboro TVA 1000	PID 0.27 ppm
	FID 0.09 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 % O ₂
Cal.	
MIE PDR 1000	Conc. 0.34 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-23-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	4:10	4:15	4:21	4:26	4:31	4:37
Foxboro TVA 1000	PID 0.07 ppm	PID 0.12 ppm	PID 0.04 ppm	PID 0.03 ppm	PID 0.00 ppm	PID 0.29 ppm
	FID 0.04 ppm	FID 0.03 ppm	FID 0.06 ppm	FID 0.07 ppm	FID 0.00 ppm	FID 0.04 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.120 Mg/m ³	Conc. 0.100 Mg/m ³	Conc. 0.104 Mg/m ³	Conc. 0.112 Mg/m ³	Conc. 0.103 Mg/m ³	Conc. 0.009 Mg/m ³
Comments	S.W. winds @ 13 mph					



Westgate Air Monitoring Air Filtration System

Date: 5-23-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time				4:41	4:44
Foxboro TVA 1000	PID	ppm	ppm	PID 0.03	PID 0.22
	FID	ppm	ppm	FID 0.18	FID 0.84
Cal.					
Mini RAE 2000	PID	ppm	ppm	PID 0.0	PID 0.0
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:46
Foxboro TVA 1000	PID 0.27 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.321 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 5-24-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	3:32	3:38	3:42	3:47	3:52	3:57
Foxboro TVA 1000	PID 0.09 ppm FID 0.03 ppm	PID 0.02 ppm FID 0.04 ppm	PID 0.03 ppm FID 0.08 ppm	PID 0.01 ppm FID 0.04 ppm	PID 0.08 ppm FID 0.12 ppm	PID 0.02 ppm FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.102 Mg/m ³	Conc. 0.092 Mg/m ³	Conc. 0.102 Mg/m ³	Conc. 0.008 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.00 Mg/m ³
Comments	Winds from the southwest @ 11 mph.					



Westgate Air Monitoring Air Filtration System

Date: 5-24-02

	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time				4:00	4:03
Foxboro TVA 1000	PID	ppm	ppm	PID 0.02	PID 0.20
	FID	ppm	ppm	FID 0.15	FID 0.76
Cal.					
Mini RAE 2000	PID	ppm	ppm	PID 0.0	PID 0.0
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:06
Foxboro TVA 1000	PID 0.24
	FID 0.00
Cal.	
Mini RAE 2000	PID 0.0
Cal.	
Jerome 431-X	000 Hg Mg/m ³
Jerome 631-X	000 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.34 / Mg/m ³



Date: 6-17-08

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	10:35 Am	10:40 Am	10:45 Am	10:48 Am	10:51 Am	10:55 Am
Foxboro TVA 1000	PID 0.36 ppm	PID 0.76 ppm	PID 0.26 ppm	PID 0.74 ppm	PID 0.24 ppm	PID 0.24 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal. 6-17-02						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal. 6-17-02						
Jerome 431-X	Hg Mg/m ³	Hg Mg/m ³	Hg Mg/m ³	Hg Mg/m ³	Hg Mg/m ³	Hg Mg/m ³
Jerome 631-X	H ₂ S ppm	H ₂ S ppm	H ₂ S ppm	H ₂ S ppm	H ₂ S ppm	H ₂ S ppm
Gastech GT 201	% LEL	% LEL	% LEL	% LEL	% LEL	% LEL
	ppm	ppm	ppm	ppm	ppm	ppm
	% O ₂	% O ₂	% O ₂	% O ₂	% O ₂	% O ₂
Calculated 6:17 PM						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 6-17-01

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:45 pm	4:48 pm	4:50 pm	4:52 pm	4:55 pm	4:58 pm
Foxboro TVA 1000	PID 0.05 ppm	PID 0.05 ppm	PID 0.03 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.010 Hg Mg/m ³	0.005 Hg Mg/m ³	0.005 Hg Mg/m ³	0.005 Hg Mg/m ³	0.004 Hg Mg/m ³	0.004 Hg Mg/m ³
Jerome 631-X	1.000 H ₂ S ppm	1.000 H ₂ S ppm	1.000 H ₂ S ppm	1.000 H ₂ S ppm	1.000 H ₂ S ppm	1.000 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 6-17-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	5:02 PM	5:05 PM		5:08 PM	5:10 PM
Foxboro TVA 1000	PID 0.24 ppm	PID 0.48 ppm		PID 0.21 ppm	PID 0.23 ppm
	FID 0.45 ppm	FID 0.89 ppm		FID 0.33 ppm	FID 0.42 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:	Wind from SE 9 miles per hr.				

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:20 PM
Foxboro TVA 1000	PID 0.10 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	1.005 Hg Mg/m ³
Jerome 631-X	1.000 H ₂ S ppm
Gastech GT 201	8
	600 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000 Mg/m ³



Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	9:28 AM	9:33 AM	9:36 AM	9:42 AM	9:46 AM	9:49 AM
Foxboro TVA 1000	PID 3.71 ppm	PID 2.57 ppm	PID 1.67 ppm	PID 1.37 ppm	PID 1.04 ppm	PID 1.20 ppm
	FID 0.37 ppm	FID 0.43 ppm	FID 0.39 ppm	FID 0.18 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.03 Hg Mg/m ³	0.05 Hg Mg/m ³	0.04 Hg Mg/m ³	0.04 Hg Mg/m ³	0.03 Hg Mg/m ³	0.03 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	Wind South East 13 mph					

Wind South Southeast 13 mph



6-18-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	4:58	5:03	5:06	5:08	5:12	5:15
Foxboro TVA 1000	PID 0.02 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.8 %O ₂	20.8 %O ₂	20.8 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	Windy from the south at 15 mph.					



Westgate Air Monitoring Air Filtration System

Date: 6.18.02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:30	4:32		4:34	4:36
Foxboro TVA 1000	PID 6.12 6.12 ppm	PID 6.12 ppm		PID 5.89 5.89 ppm	PID 5.89 ppm
	FID 0.00 ppm	FID 28.17 ppm		FID 0.03 ppm	FID 27.78 ppm
Cal.					
Mini RAE 2000	PID 0.6 ppm	PID 20.3 ppm		PID 0.5 ppm	PID 19.9 ppm
Cal.					
Comment:					

Westgate Air Monitor Inside Structure

	Sample Point Inside Structure
Time	5:18
Foxboro TVA 1000	PID 14.26 ppm
	FID 49.22 ppm
Cal.	
Mini RAE 2000	PID 23.7 ppm
Cal.	
Jerome 431-X	100 Hg Mg/m ³
Jerome 631-X	0.027 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0.180 ppm
	70.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.541 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 6-19-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	9:15	9:22	9:27	9:35	9:40	9:44
Foxboro TVA 1000	PID 2.06 ppm	PID 1.97 ppm	PID 0.46 ppm	PID 0.03 ppm	PID 0.07 ppm	PID 0.11 ppm
	FID 1.46 ppm	FID 2.00 ppm	FID 0.17 ppm	FID 0.18 ppm	FID 0.21 ppm	FID 0.07 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂
Cal.						
MIE PDR 1000	Conc. 0.016 Mg/m ³	Conc. 0.022 Mg/m ³	Conc. 0.110 Mg/m ³	Conc. 0.216 Mg/m ³	Conc. 0.08 Mg/m ³	Conc. 0.118 Mg/m ³
Comments						



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	4:30 pm	4:33 pm	4:35 pm	4:38 pm	4:40 pm	4:44 pm
Foxboro TVA 1000	PID 0.01 ppm	PID 0.04 ppm	PID 0.03 ppm	PID 0.01 ppm	PID 0.02 ppm	PID 0.00 ppm
	FID 0.68 ppm	FID 0.20 ppm	FID 0.55 ppm	FID 0.00 ppm	FID 0.02 ppm	FID 0.03 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	1.000 Hg Mg/m ³	1.000 Hg Mg/m ³	1.000 Hg Mg/m ³	1.000 Hg Mg/m ³	1.000 Hg Mg/m ³	1.000 Hg Mg/m ³
Jerome 631-X	1.000 H ₂ S ppm	1.000 H ₂ S ppm	1.000 H ₂ S ppm	1.000 H ₂ S ppm	1.001 H ₂ S ppm	1.001 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.002 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.005 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 6-19-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:47 PM	4:48 PM		4:50 PM	4:52 PM
Foxboro TVA 1000	PID 0.28 ppm	PID 1.29 ppm		PID 0.38 ppm	PID 0.96 ppm
	FID 0.19 ppm	FID 5.30 ppm		FID 0.50 ppm	FID 4.53 ppm
Cal.					
Mini RAE 2000	PID 0.04 ppm	PID 1.7 ppm		PID 0.0 ppm	PID 1.3 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:55 PM
Foxboro TVA 1000	PID 4.62 ppm
	FID 9.48 ppm
Cal.	
Mini RAE 2000	PID 4.3 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.02 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 6-30-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	10:55 AM	11:00 AM	11:03 AM	11:05 AM	11:08 AM	11:11 AM
Foxboro TVA 1000	PID 1.69 ppm	PID 1.41 ppm	PID 1.19 ppm	PID 1.09 ppm	PID 0.94 ppm	PID 0.88 ppm
	FID 1.16 ppm	FID 0.76 ppm	FID 0.63 ppm	FID 0.67 ppm	FID 0.00 ppm	FID 0.62 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.018 Mg/m ³	Conc. 0.004 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.010 Mg/m ³	Conc. 0.018 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 6-10-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	2:40 PM	2:43 PM	2:45 PM	2:48 PM	2:50 PM	2:55 PM
Foxboro TVA 1000	PID 0.54 ppm	PID 0.55 ppm	PID 0.51 ppm	PID 0.44 ppm	PID 0.41 ppm	PID 0.25 ppm
	FID 1.18 ppm	FID 1.24 ppm	FID 0.87 ppm	FID 0.74 ppm	FID 0.65 ppm	FID 0.50 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.010 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.004 Mg/m ³	Conc. 0.029 Mg/m ³	Conc. 0.031 Mg/m ³	Conc. 0.020 Mg/m ³
Comments	Wind from South east at 18.0					



Westgate Air Monitoring Air Filtration System

Date: 6-20-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	3:00 PM	3:03 PM		3:05 PM	3:07 PM
Foxboro TVA 1000	PID 0.52 ppm	PID 1.59 ppm		PID 0.55 ppm	PID 1.03 ppm
	FID 1.33 ppm	FID 6.13 ppm		FID 1.98 ppm	FID 3.40 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 1.4 ppm		PID 0.0 ppm	PID 0.4 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	3:15 PM
Foxboro TVA 1000	PID 1.33 ppm
	FID 2.14 ppm
Cal.	
Mini RAE 2000	PID 1.6 ppm
Cal.	
Jerome 431-X	1.000 Hg Mg/m ³
Jerome 631-X	1.633 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	10.5 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.873 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 6-21-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	9:37	9:43	9:50	9:58	10:00	10:09
Foxboro TVA 1000	PID 1.72 ppm	PID 1.32 ppm	PID 1.10 ppm	PID 0.48 ppm	PID 0.70 ppm	PID 0.88 ppm
	FID 1.10 ppm	FID 0.70 ppm	FID 0.60 ppm	FID 0.63 ppm	FID 0.00 ppm	FID 0.62 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.006 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.002 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.018 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.018 Mg/m ³
Comments	Wind out of the south west at 10 mph					



Date: 6-21-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
Time	4:17	4:20	4:23	4:26	4:29	4:32
Foxboro TVA 1000	PID 0.25 ppm	PID 0.30 ppm	PID 0.18 ppm	PID 0.15 ppm	PID 0.13 ppm	PID 0.12 ppm
	FID 2.01 ppm	FID 1.95 ppm	FID 2.54 ppm	FID 1.63 ppm	FID 1.44 ppm	FID 0.98 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.4 %O ₂	20.4 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	windy from the south at 16 mph.					



Westgate Air Monitoring Air Filtration System

Date: 06/21/02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:34	4:35		4:37	4:39
Foxboro TVA 1000	PID 0.28 ppm	PID 0.72 ppm		PID 0.30 ppm	PID 0.67 ppm
	FID 0.88 ppm	FID 3.39 ppm		FID 0.81 ppm	FID 3.83 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.4 ppm		PID 0.0 ppm	PID 0.3 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:41
Foxboro TVA 1000	PID 1.16 ppm
	FID 4.54 ppm
Cal.	
Mini RAE 2000	PID 1.2 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	0.00 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.149 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
Time	9:13 AM	9:17 AM	9:19 AM	9:24 AM	9:27 AM	9:30 AM
Foxboro TVA 1000	PID 0.11 ppm	PID 0.05 ppm	PID 0.04 ppm	PID 0.01 ppm	PID 0.02 ppm	PID 0.00 ppm
	FID 0.14 ppm	FID 0.05 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal. 6-24-02						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal. 6-24-02						
Jerome 431-X	,000 Hg Mg/m ³	,000 Hg Mg/m ³	,000 Hg Mg/m ³	,000 Hg Mg/m ³	,000 Hg Mg/m ³	,000 Hg Mg/m ³
Jerome 631-X	,000 H ₂ S ppm	,000 H ₂ S ppm	,000 H ₂ S ppm	,000 H ₂ S ppm	,000 H ₂ S ppm	,000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal. check 6-24-02						
MIE PDR 1000	Conc. 0.036 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.015 Mg/m ³	Conc. 0.024 Mg/m ³	Conc. 0.006 Mg/m ³
Comments						

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 6-24-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:19	4:20		4:22	4:24
Foxboro TVA 1000	PID 0.02 ppm	PID 1.25 ppm		PID 0.09 ppm	PID 1.42 ppm
	FID 0.00 ppm	FID 6.02 ppm		FID 0.00 ppm	FID 6.79 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 3.6 ppm		PID 0.0 ppm	PID 3.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time 4:27	
Foxboro TVA 1000	PID 4.08 ppm
	FID 16.52 ppm
Cal.	
Mini RAE 2000	PID 6.4 ppm
Cal.	
Jerome 431-X	4.000 Hg Mg/m ³
Jerome 631-X	1.009 H ₂ S ppm
Gastech GT 201	0.000
	0.00 % LEL
	0.000 ppm
	20.8 %O ₂
Cal.	
MIE PDR 1000	Conc 0.246 Mg/m ³



Date: 6-25-02

[illegible]



Westgate Air Monitoring Westgate Neighborhood

Date: 6.25.02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:00	4:04	4:07	4:11	4:15	4:19
Foxboro TVA 1000	PID 0.09 ppm	PID 0.02 ppm	PID 0.04 ppm	PID 0.05 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.72 ppm	FID 0.30 ppm	FID 0.40 ppm	FID 0.28 ppm	FID 0.00 ppm	FID 0.17 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	• 0.00 Hg Mg/m ³	• 0.00 Hg Mg/m ³	• 0.00 Hg Mg/m ³	• 0.00 Hg Mg/m ³	• 0.00 Hg Mg/m ³	• 0.00 Hg Mg/m ³
Jerome 631-X	• 0.02 H ₂ S ppm	• 0.01 H ₂ S ppm	• 0.01 H ₂ S ppm	• 0.00 H ₂ S ppm	• 0.02 H ₂ S ppm	• 0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.015 Mg/m ³	Conc. 0.024 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.034 Mg/m ³	Conc. 0.037 Mg/m ³	Conc. 0.028 Mg/m ³
Comments	windy from the southeast at 5 mph.					



Westgate Air Monitoring Air Filtration System

Date: 06.25.02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:22	4:24		4:26	4:28
Foxboro TVA 1000	PID 0.02 ppm	PID 1.20 ppm		PID 0.08 ppm	PID 1.48 ppm
	FID 0.00 ppm	FID 6.61 ppm		FID 0.00 ppm	FID 6.72 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 3.4 ppm		PID 0.0 ppm	PID 3.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:33
Foxboro TVA 1000	PID 4.07 ppm
	FID 16.48 ppm
Cal.	
Mini RAE 2000	PID 6.2 ppm
Cal.	
Jerome 431-X	0.000 Hg Mg/m ³
Jerome 631-X	0.07 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.278 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 06-26-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	0.22	10:26	10:30	10:34	10:38	10:41
Foxboro TVA 1000	PID 6.00 ppm	PID 0.01 ppm	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.01 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.02 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.004 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.012 Mg/m ³	Conc. 0.021 Mg/m ³	Conc. 0.019 Mg/m ³
Comments	winds from the Southwest at 5 mph.					



Westgate Air Monitoring Westgate Neighborhood

Date: 06.26.02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
	4:10	4:14	4:19	4:23	4:27	4:32
Foxboro TVA 1000	PID 0.02 ppm	PID 0.06 ppm	PID 0.01 ppm	PID 0.06 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.02 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.003 Mg/m ³	Conc. 0.012 Mg/m ³	Conc. 0.021 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.008 Mg/m ³	Conc. 0.008 Mg/m ³
Comments	Windy from the southeast at 8 mph.					



Westgate Air Monitoring Air Filtration System

Date: 06-26-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:36	4:38		4:41	4:44
Foxboro TVA 1000	PID 0.02 ppm	PID 1.08 ppm		PID 0.07 ppm	PID 1.45 ppm
	FID 0.00 ppm	FID 5.39 ppm		FID 0.00 ppm	FID 6.76 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 2.5 ppm		PID 0.0 ppm	PID 3.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:57
Foxboro TVA 1000	PID 3.98 ppm
	FID 14.50 ppm
Cal.	
Mini RAE 2000	PID 5.9 ppm
Cal.	
Jerome 431-X	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm
Gastech GT 201	
	0.0 % LEL
	0.0 ppm
	10.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.257 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	9:28	9:34	9:39	9:42	9:45	9:49
Foxboro TVA 1000	PID 0.09 ppm	PID 0.07 ppm	PID 0.05 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.01 ppm
	FID 0.21 ppm	FID 0.30 ppm	FID 0.25 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0	PID 0.0	PID 0.0	PID 0.0	PID 0.0	PID 0.0
Cal.						
Jerome 431-X	.00 Hg Mg/m ³	.00 Hg Mg/m ³	.00 Hg Mg/m ³	.00 Hg Mg/m ³	.00 Hg Mg/m ³	.00 Hg Mg/m ³
Jerome 631-X	.01 H ₂ S ppm	.00 H ₂ S ppm	.07 H ₂ S ppm	.01 H ₂ S ppm	.01 H ₂ S ppm	.02 H ₂ S ppm
Gastech GT 201	.00 % LEL	.00 % LEL	.00 % LEL	.00 % LEL	.00 % LEL	.00 % LEL
	.00 ppm	.00 ppm	.00 ppm	.00 ppm	.00 ppm	.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.018 Mg/m ³	Conc. 0.033 Mg/m ³	Conc. 0.031 Mg/m ³	Conc. 0.024 Mg/m ³	Conc. 0.011 Mg/m ³
Comments	Wind from the South at 6 mph					



Westgate Air Monitoring Westgate Neighborhood

Date: 06.27.02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:23	4:26	4:32	4:37	4:42	4:47
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.01 ppm	FID 0.02 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.02 ppm	FID 0.01 ppm
Cal.						
Mini RAE 2000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
Cal.						
Jerome 431-X	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³
Jerome 631-X	PID 0.01 H ₂ S ppm	PID 0.01 H ₂ S ppm	PID 0.01 H ₂ S ppm	PID 0.01 H ₂ S ppm	PID 0.01 H ₂ S ppm	PID 0.01 H ₂ S ppm
Gastech GT 201	PID 0.00 % LEL	PID 0.00 % LEL	PID 0.00 % LEL	PID 0.00 % LEL	PID 0.00 % LEL	PID 0.00 % LEL
	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	PID 0.00 %O ₂	PID 0.00 %O ₂	PID 0.00 %O ₂	PID 0.00 %O ₂	PID 0.00 %O ₂	PID 0.00 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.019 Mg/m ³	Conc. 0.021 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.018 Mg/m ³	Conc. 0.014 Mg/m ³
Comments	wind from the southeast at 8 mph					



Westgate Air Monitoring Air Filtration System

Date: 06.07.02.

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:50	4:52		4:55	4:58
Foxboro TVA 1000	PID 0.02 ppm	PID 1.02 ppm		PID 0.08 ppm	PID 1.32 ppm
	FID 0.00 ppm	FID 4.87 ppm		FID 0.00 ppm	FID 5.72 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 3.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:01
Foxboro TVA 1000	PID 4.17 ppm
	FID 13.09 ppm
Cal.	
Mini RAE 2000	PID 5.7 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	0.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.009 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 06-28-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	10:10	10:14	10:19	10:24	10:28	10:32
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.01 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.02 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.01 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.02 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.009 Mg/m ³	Conc. 0.008 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.012 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.006 Mg/m ³
Comments	windy from the south at 2 mph					



Westgate Air Monitoring Westgate Neighborhood

Date: 06-28-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:16	4:15	4:29	4:34	4:37	4:42
Foxboro TVA 1000	PID .000 ppm	PID .000 ppm	PID .000 ppm	PID .000 ppm	PID .000 ppm	PID .000 ppm
	FID .001 ppm	FID .000 ppm	FID .000 ppm	FID .001 ppm	FID .000 ppm	FID .000 ppm
Cal.						
Mini RAE 2000	PID .00 ppm	PID .00 ppm	PID .00 ppm	PID .00 ppm	PID .00 ppm	PID .00 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. .0018 Mg/m ³	Conc. .0022 Mg/m ³	Conc. .0014 Mg/m ³	Conc. .0016 Mg/m ³	Conc. .0028 Mg/m ³	Conc. .0044 Mg/m ³
Comments	windy from the southeast at 10 mph.					



Westgate Air Monitoring Air Filtration System

Date: Dec 24 02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:46	4:49		4:53	4:57
Foxboro TVA 1000	PID 0.02 ppm	PID 1.09 ppm		PID 0.06 ppm	PID 1.30 ppm
	FID 0.00 ppm	FID 3.87 ppm		FID 0.00 ppm	FID 4.89 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 3.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:03
Foxboro TVA 1000	PID 4.18 ppm
	FID 12.80 ppm
Cal.	
Mini RAE 2000	PID 5.10 4.5 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.05 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 1.198 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 07-01-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	10:05	10:14	10:18	10:23	10:28	10:34
Foxboro TVA 1000	PID 0.00 ppm	PID 0.10 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	0.00 %O ₂	0.00 %O ₂	0.00 %O ₂	0.00 %O ₂	0.00 %O ₂	0.00 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.004 Mg/m ³	Conc. 0.017 Mg/m ³
Comments	windy from the southwest at 11 mph					



Date: 7-1-02

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 07-01-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:03	4:07		4:10	4:13
Foxboro TVA 1000	PID 0.02 ppm	PID 1.04 ppm		PID 0.05 ppm	PID 1.12 ppm
	FID 0.00 ppm	FID 3.09 ppm		FID 0.00 ppm	FID 3.41 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 3.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:16
Foxboro TVA 1000	PID 3.74 ppm
	FID 9.78 ppm
Cal.	
Mini RAE 2000	PID 14.5 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.104 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 17.02.02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	10:23	10:26	10:30	10:34	10:37	10:41
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	0.00 %O ₂	0.00 %O ₂	0.00 %O ₂	0.00 %O ₂	0.00 %O ₂	0.00 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.010 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.008 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.009 Mg/m ³
Comments	winds from the southeast at 14 mph					



Westgate Air Monitoring Westgate Neighborhood

Date: 07.20.02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:11	4:16	4:19	4:23	4:27	4:32
Foxboro TVA 1000	PID .000 ppm	PID .000 ppm	PID .000 ppm	PID .000 ppm	PID .000 ppm	PID .000 ppm
	FID .000 ppm	FID .000 ppm	FID .000 ppm	FID .000 ppm	FID .000 ppm	FID .000 ppm
Cal.						
Mini RAE 2000	PID .00 ppm	PID .00 ppm	PID .00 ppm	PID .00 ppm	PID .00 ppm	PID .00 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm
	.000 %O ₂	.000 %O ₂	.000 %O ₂	.000 %O ₂	.000 %O ₂	.000 %O ₂
Cal.						
MIE PDR 1000	Conc. .0000 Mg/m ³	Conc. .0005 Mg/m ³	Conc. .0000 Mg/m ³	Conc. .0000 Mg/m ³	Conc. .0002 Mg/m ³	Conc. .0005 Mg/m ³
Comments	Southeast winds at 8 mph.					



Westgate Air Monitoring Air Filtration System

Date: 07-02-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:36	4:39		4:43	4:45
Foxboro TVA 1000	PID 0.02 ppm	PID 1.06 ppm		PID 0.05 ppm	PID 1.20 ppm
	FID 0.00 ppm	FID 2.98 ppm		FID 0.00 ppm	FID 3.57 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 2.3 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:47
Foxboro TVA 1000	PID 4.18 ppm
	FID 12.75 ppm
Cal.	
Mini RAE 2000	PID 4.5 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.03 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.241 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 07-3-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	9:40	9:43	9:46	9:49	9:54	9:59
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.004 Mg/m ³	Conc. 0.008 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	Northeast winds at 8 mph					



Westgate Air Monitoring Westgate Neighborhood

Date: 07.03.02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	3:36	3:40	3:44	3:48	3:52	3:57
Foxboro TVA 1000	PID .002 ppm	PID .000 ppm	PID .000 ppm	PID .000 ppm	PID .000 ppm	PID .000 ppm
	FID 0.00 ppm	FID .000 ppm	FID .000 ppm	FID .000 ppm	FID .000 ppm	FID .000 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID .00 ppm	PID 0.0 ppm	PID .00 ppm	PID .00 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm
	.000 %O ₂	.000 %O ₂	.000 %O ₂	.000 %O ₂	.000 %O ₂	.000 %O ₂
Cal.						
MIE PDR 1000	Conc. .0011 Mg/m ³	Conc. .0014 Mg/m ³	Conc. .0015 Mg/m ³	Conc. .0020 Mg/m ³	Conc. .0015 Mg/m ³	Conc. .0009 Mg/m ³
Comments	Southeast winds at 13 mph.					



Westgate Air Monitoring Air Filtration System

Date: 07-03-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.00 ppm	PID 1.69 ppm	PID	PID 0.06 ppm	PID 1.73 ppm
	FID 0.00 ppm	FID 10.01 ppm	FID	FID 0.00 ppm	FID 5.58 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 3.4 ppm	PID	PID 0.0 ppm	PID 2.6 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 3.09 ppm
	FID 12.40 ppm
Cal.	
Mini RAE 2000	PID 4.2 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.005 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.275 Mg/m ³

[illegible]



Westgate Air Monitoring Westgate Neighborhood

Date: 7-8-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Foxboro TVA 1000	PID 0.00 ppm FID 0.00 ppm	PID 0.00 ppm FID 0.00 ppm	PID 0.00 ppm FID 0.00 ppm	PID 0.01 ppm FID 0.00 ppm	PID 0.01 ppm FID 0.00 ppm	PID 0.12 ppm FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³

Comments



Westgate Air Monitoring Air Filtration System

Date: 7-8-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:36	4:38		4:40	4:44
Foxboro TVA 1000	PID 0.17 ppm	PID 1.59 ppm		PID 0.45 ppm	PID 0.30 ppm
	FID 0.00 ppm	FID 6.13 ppm		FID 1.87 ppm	FID 1.11 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 1.4 ppm		PID 0.4 ppm	PID 0.2 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	5:00
Foxboro TVA 1000	PID 1.33 ppm
	FID 2.70 ppm
Cal.	
Mini RAE 2000	PID 1.6 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	209 %O ₂
Cal.	
MIE PDR 1000	Conc 0.015 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 7-9-92

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	10:20	10:25	10:30	10:36	10:40	10:45
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	4:50	4:55	5:00	5:06	5:09	5:15
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.0000 Mg/m ³	Conc. 0.0000 Mg/m ³	Conc. 0.0000 Mg/m ³	Conc. 0.0000 Mg/m ³	Conc. 0.0000 Mg/m ³

Comments



Westgate Air Monitoring Air Filtration System

Date: 7-9-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	5:20	5:28		5:26	5:28
Foxboro TVA 1000	PID 0.00 ppm	PID 0.30 ppm		PID 0.00 ppm	PID 0.00 ppm
	FID 0.90 ppm	FID 0.10 ppm		FID 0.00 ppm	FID 0.00 ppm
Cal.					
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm		PID 0.1 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:40
Foxboro TVA 1000	PID 0.30 ppm
	FID 0.00 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	0.006 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.003 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 7-10-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	9:35	9:38	9:44	9:48	9:52	9:55
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	2:30	2:33	2:37	2:41	2:44	2:48
Foxboro TVA 1000	PID 0.00 ppm	PID 0.06 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc 0.000 Mg/m ³	Conc 0.000 Mg/m ³	Conc 0.000 Mg/m ³	Conc 0.000 Mg/m ³	Conc 0.000 Mg/m ³	Conc 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 7-10-02

	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	2:55	2:57		2:59	3:02
Foxboro TVA 1000	PID 0.00 ppm	PID 0.07 ppm		PID 0.06 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.48 ppm		FID 0.00 ppm	FID 0.00 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 0.00 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	3:10
Foxboro TVA 1000	PID 1.60 ppm
	FID 1.35 ppm
Cal.	
Mini RAE 2000	PID 1.9 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm
Gastech GT 201	
	0.06 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.00 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 7-17-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	10:14	10:17	10:21	10:24	10:27	10:30
Foxboro TVA 1000	PID 0.09 ppm	PID 0.17 ppm	PID 0.30 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.47 ppm	FID 0.88 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.21 ppm	FID 0.67 ppm
Cal.						
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.002 H ₂ S ppm	0.001 H ₂ S ppm	0.002 H ₂ S ppm	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.00/ H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.102 Mg/m ³	Conc. 0.102 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 7-17-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	3:50	3:52		3:54	3:56
Foxboro TVA 1000	PID 0.16 ppm	PID 0.54 ppm		PID 0.17 ppm	PID 0.26 ppm
	FID 0.07 ppm	FID 0.64 ppm		FID 1.21 ppm	FID 0.07 ppm
Cal.					
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm		PID 0.1 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:00
Foxboro TVA 1000	PID 0.91 ppm
	FID 0.87 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	0.000 Hg Mg/m ³
Jerome 631-X	0.002 H ₂ S ppm
Gastech GT 201	
	0.000 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000173 mg/m ³

0.173



Westgate Air Monitoring Westgate Neighborhood

Date: 7-18-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
	11:30	11:33	11:36	11:39	11:44	11:47
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂
Cal.						
MIE PDR 1000	Conc. 0.017 Mg/m ³	Conc. 0.12 Mg/m ³	Conc. 0.100 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 7-18-02

	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:15	4:17		4:18	4:20
Foxboro TVA 1000	PID 0.17 ppm	PID 0.10 ppm		PID 0.00 ppm	PID 0.71 ppm
	FID 0.00 ppm	FID 0.92 ppm		FID 0.13 ppm	FID 0.24 ppm
Cal.					
Mini RAE 2000	PID 0.1 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.17 ppm
	FID 0.43 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	0.000 Hg Mg/m ³
Jerome 631-X	0.002 H ₂ S ppm
Gastech GT 201	
	0.000 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.000 Mg/m ³

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 7-19-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.11 ppm	PID 0.07 ppm		PID 0.09 ppm	PID 0.00 ppm
	FID 0.27 ppm	FID 0.01 ppm		FID 1.23 ppm	FID 0.00 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.1 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
4:55	
Foxboro TVA 1000	PID 0.91 ppm
	FID 0.11 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	0.000 Hg Mg/m ³
Jerome 631-X	0.003 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.000Mg/m ³

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 7-22-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:20	4:22		4:23	4:25
Foxboro TVA 1000	PID 0.17 ppm	PID 0.91 ppm		PID 0.38 ppm	PID 0.00 ppm
	FID 0.36 ppm	FID 0.03 ppm		FID 1.12 ppm	FID 0.03 ppm
Cal.					
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm		PID 0.1 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:35
Foxboro TVA 1000	PID 0.00 ppm
	FID 0.76 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 % O ₂
Cal.	
MIE PDR 1000	Conc 0.00 MMg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 7-23-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	10:15	10:19	10:23	10:26	10:30	10:33
Foxboro TVA 1000	PID 0.13 ppm	PID 0.12 ppm	PID 0.16 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.76 ppm	FID 0.00 ppm	FID 0.04 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 7-23-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:50	4:52		4:53	4:55
Foxboro TVA 1000	PID 0.01 ppm	PID 0.00 ppm		PID 0.01 ppm	PID 0.00 ppm
	FID 0.16 ppm	FID 0.34 ppm		FID 0.00 ppm	FID 0.16 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.1 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:15
Foxboro TVA 1000	PID 0.47 ppm
	FID 1.06 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.00 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 7-24-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
	3:20	3:24	3:27	3:30	3:34	3:38
Foxboro TVA 1000	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.173 Mg/m ³	Conc. 0.200 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.215 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 7-24-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	3:50	3:53		3:54	3:57
Foxboro TVA 1000	PID 0.11 ppm	PID 0.00 ppm		PID 0.72 ppm	PID 0.33 ppm
	FID 0.34 ppm	FID 0.02 ppm		FID 1.20 ppm	FID 1.16 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:10
Foxboro TVA 1000	PID 0.11 ppm
	FID 0.29 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.02 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.00 Mg/m ³

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 7-25-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 4.40 ppm	PID 4.44 ppm	PID 0.05 ppm	PID 0.07 ppm	PID 0.00 ppm
Cal.	FID 0.00 ppm	FID 0.18 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 5.05 ppm
Cal.	FID 1.12 ppm
Mini RAE 2000	FID 1.09 ppm
Cal.	
Jerome 431-X	PID 0.0 ppm
Jerome 631-X	000 Hg Mg/m ³
Gastech GT 201	000 H ₂ S ppm
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.00 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-12-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	8:55	9:00	9:05	9:10	9:15	9:22
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.02 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.011 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.004 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.001 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 8-12-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:50	4:54	4:58	5:03	5:06	5:10
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.02 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.03 ppm	FID 0.00 ppm	FID 0.04 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.002 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂
Cal.						
MIE PDR 1000	Conc. 0.019 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.003 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 8-12-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	5:15	5:17		5:19	5:23
Foxboro TVA 1000	PID 0.02 ppm	PID 0.07 ppm		PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.02 ppm		FID 0.00 ppm	FID 0.00 ppm
Cal.					
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm		PID 0.1 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:40
Foxboro TVA 1000	PID 1.27 ppm
	FID 260 ppm
Cal.	
Mini RAE 2000	PID 1.9 ppm
Cal.	
Jerome 431-X	000 Hg Mg/m ³
Jerome 631-X	001 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.80Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-13-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
	9:45	9:50	9:55	10:00	10:04	10:09
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.006 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments	South east winds at 8mph					



Date: 8-13-02

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 8-13-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:05	4:08		4:11	4:15
Foxboro TVA 1000	PID 0.38 ppm	PID 1.13 ppm		PID 0.40 ppm	PID 1.10 ppm
	FID 1.31 ppm	FID 1.87 ppm		FID 1.63 ppm	FID 1.99 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.5 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:25
Foxboro TVA 1000	PID 1.12 ppm
	FID 2.00 ppm
Cal.	
Mini RAE 2000	PID 0.4 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	2.0.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.010 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-14-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	9:15	9:20	9:25	9:30	9:35	9:40
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.01 ppm	FID 0.01 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.00 ppm	FID 0.02 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 8-14-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Foxboro TVA 1000	3:45 PID 0.00 ppm FID 0.00 ppm	3:50 PID 0.00 ppm FID 0.00 ppm	3:55 PID 0.01 ppm FID 0.00 ppm	3:58 PID 0.00 ppm FID 0.00 ppm	4:00 PID 0.02 ppm FID 0.01 ppm	4:05 PID 0.00 ppm FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.02 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.004 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.010 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.015 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 8-14-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:15	4:18		4:21	4:25
Foxboro TVA 1000	PID 0.03 ppm	PID 1.07 ppm		PID 0.05 ppm	PID 1.23 ppm
	FID 0.00 ppm	FID 0.12 ppm		FID 0.00 ppm	FID 4.00 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 1.3 ppm		PID 0.0 ppm	PID 1.5 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:40
Foxboro TVA 1000	PID 1.31 ppm
	FID 0.60 ppm
Cal.	
Mini RAE 2000	PID 1.5 ppm
Cal.	
Jerome 431-X	0.000 Hg Mg/m ³
Jerome 631-X	0.002 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.000 Mg/m ³



Date: 8-15-02

[illegible]



Westgate Air Monitoring Westgate Neighborhood

Date: 8-15-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:20	4:25	4:30	4:35	4:40	4:45
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.011 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.008 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 8-15-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	5:00	5:03		5:07	5:11
Foxboro TVA 1000	PID 0.02 ppm	PID 1.10 ppm		PID 0.07 ppm	PID 1.13 ppm
	FID 0.00 ppm	FID 2.02 ppm		FID 0.0 ppm	FID 3.10 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 1.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:16
Foxboro TVA 1000	PID 1.42 ppm
	FID 4.47 ppm
Cal.	
Mini RAE 2000	PID 7.3 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.18 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-16-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
	9:18	9:22	9:26	9:32	9:37	9:43
Foxboro TVA 1000	PID 3.52 ppm	PID 2.43 ppm	PID 1.54 ppm	PID 1.41 ppm	PID 1.03 ppm	PID 1.22 ppm
	FID 0.33 ppm	FID 0.40 ppm	FID 0.39 ppm	FID 0.11 ppm	FID 0.07 ppm	FID 0.04 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.001 Hg Mg/m ³	0.001 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.002 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.012 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.002 Mg/m ³
Comments						



Date: 8-16-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	4:15	4:20	4:25	4:30	4:35	4:40
Foxboro TVA 1000	PID 4.21 ppm FID 0.49 ppm	PID 3.51 ppm FID 0.15 ppm	PID 2.20 ppm FID 0.36 ppm	PID 1.01 ppm FID 0.22 ppm	PID 1.09 ppm FID 0.19 ppm	PID 1.34 ppm FID 1.04 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.001 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.001 Hg Mg/m ³	.001 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	.000 % LEL .0000 ppm 20.9 %O ₂	.000 % LEL .0000 ppm 20.9 %O ₂	.000 % LEL .0000 ppm 20.9 %O ₂	.000 % LEL .0000 ppm 20.9 %O ₂	.000 % LEL .0000 ppm 20.9 %O ₂	.000 % LEL .0000 ppm 20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.012 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.004 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.003 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 8-16-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:45	4:48		4:54	4:59
Foxboro TVA 1000	PID 0.73 ppm	PID 6.34 ppm	PID	PID 0.55 ppm	PID 6.37 ppm
	FID 0.00 ppm	FID 18.11 ppm	FID	FID 0.03 ppm	FID 22.45 ppm
Cal.					
Mini RAE 2000	PID 0.5 ppm	PID 21.7 ppm	PID	PID 0.7 ppm	PID 18.3 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:05
Foxboro TVA 1000	PID 12.35 ppm
	FID 44.19 ppm
Cal.	
Mini RAE 2000	PID 27.3 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.014 H ₂ S ppm
Gastech GT 201	
	1000 % LEL
	20120 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.67 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-19-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	8:50	8:55	9:00	9:05	9:10	9:15
Foxboro TVA 1000	PID 0.00 ppm	PID 0.01 ppm	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.005 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.015 Mg/m ³	Conc. 0.010 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.015 Mg/m ³
Comments						

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 8-18-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:50	4:53		4:59	5:03
Foxboro TVA 1000	PID 0.04 ppm	PID 1.13 ppm		PID 0.05 ppm	PID 1.76 ppm
	FID 0.00 ppm	FID 6.27 ppm		FID 0.00 ppm	FID 5.97 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 2.9 ppm		PID 0.0 ppm	PID 2.7 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:15
Foxboro TVA 1000	PID 4.02 ppm
	FID 13.97 ppm
Cal.	
Mini RAE 2000	PID 6.3 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.007 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.798 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-20-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	9:30	9:34	9:39	9:42	9:45	9:50
Foxboro TVA 1000	PID 0.09 ppm	PID 0.05 ppm	PID 0.04 ppm	PID 0.00 ppm	PID 0.01 ppm	PID 0.02 ppm
	FID 0.22 ppm	FID 0.25 ppm	FID 0.20 ppm	FID 0.00 ppm	FID 0.14 ppm	FID 0.07 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³
Jerome 631-X	PID 0.01 H ₂ S ppm	PID 0.00 H ₂ S ppm	PID 0.02 H ₂ S ppm	PID 0.01 H ₂ S ppm	PID 0.01 H ₂ S ppm	PID 0.00 H ₂ S ppm
Gastech GT 201	PID 0.00 % LEL	PID 0.00 % LEL	PID 0.00 % LEL	PID 0.00 % LEL	PID 0.00 % LEL	PID 0.00 % LEL
	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	PID 20.9 %O ₂	PID 20.9 %O ₂	PID 20.9 %O ₂	PID 20.9 %O ₂	PID 20.9 %O ₂	PID 20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.018 Mg/m ³	Conc. 0.015 Mg/m ³	Conc. 0.027 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.028 Mg/m ³	Conc. 0.027 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 8-20-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	3:20	3:24	3:30	3:35	3:40	3:43
Foxboro TVA 1000	PID 1.09 ppm	PID 0.10 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.29 ppm	FID 0.24 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	001 Hg Mg/m ³	000 Hg Mg/m ³	001 Hg Mg/m ³	000 Hg Mg/m ³	001 Hg Mg/m ³	000 Hg Mg/m ³
Jerome 631-X	000 H ₂ S ppm	000 H ₂ S ppm	000 H ₂ S ppm	001 H ₂ S ppm	001 H ₂ S ppm	000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.016 Mg/m ³	Conc. 0.112 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.010 Mg/m ³	Conc. 0.110 Mg/m ³	Conc. 0.003 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 8-20-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:00	4:03		4:05	4:08
Foxboro TVA 1000	PID 0.03 ppm	PID 2.31 ppm		PID 0.07 ppm	PID 1.47 ppm
	FID 0.01 ppm	FID 5.14 ppm		FID 0.03 ppm	FID 6.23 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 2.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 5.03 ppm
	FID 11.26 ppm
Cal.	
Mini RAE 2000	PID 3.7 ppm
Cal.	
Jerome 431-X	0.01 Hg Mg/m ³
Jerome 631-X	0.04 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.4 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.316 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	9:30	9:35	9:39	9:43	9:47	9:50
Foxboro TVA 1000	PID 0.11 ppm	PID 0.13 ppm	PID 0.06 ppm	PID 0.03 ppm	PID 0.00 ppm	PID 0.06 ppm
	FID 0.18 ppm	FID 0.09 ppm	FID 0.21 ppm	FID 0.09 ppm	FID 0.00 ppm	FID 0.02 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.002 Hg Mg/m ³	.001 Hg Mg/m ³	.000 Hg Mg/m ³	.001 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.017 Mg/m ³	Conc. 0.021 Mg/m ³	Conc. 0.033 Mg/m ³	Conc. 0.027 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.090 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 8-21-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:05	4:08	4:12	4:17	4:23	4:30
Foxboro TVA 1000	PID 0.11 ppm	PID 0.05 ppm	PID 0.09 ppm	PID 0.02 ppm	PID 0.03 ppm	PID 0.01 ppm
	FID 0.15 ppm	FID 0.17 ppm	FID 0.20 ppm	FID 0.07 ppm	FID 0.09 ppm	FID 0.04 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.001 Hg Mg/m ³	0.000 Hg Mg/m ³	0.01 Hg Mg/m ³	0.00 Hg Mg/m ³	0.001 Hg Mg/m ³	0.01 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.002 H ₂ S ppm	0.02 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.01 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.017 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.027 Mg/m ³	Conc. 0.030 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.011 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 8-21-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:35	4:38		4:41	4:45
Foxboro TVA 1000	PID 0.05 ppm	PID 1.27 ppm		PID 0.67 ppm	PID 1.73 ppm
	FID 0.03 ppm	FID 5.07 ppm		FID 0.01 ppm	FID 5.63 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 2.3 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:50
Foxboro TVA 1000	PID 3.94 ppm
	FID 10.07 ppm
Cal.	
Mini RAE 2000	PID 3.6 ppm
Cal.	
Jerome 431-X	002 Hg Mg/m ³
Jerome 631-X	007 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.127 Mg/m ³

[illegible]



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	4:20	4:25	4:28	4:32	4:38	4:44
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.01 ppm	FID 0.00 ppm	FID 0.01 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.001 Hg Mg/m ³	.001 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.006 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc 0.017 Mg/m ³	Conc 0.019 Mg/m ³	Conc 0.012 Mg/m ³	Conc 0.014 Mg/m ³	Conc 0.016 Mg/m ³	Conc 0.011 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 8-22-08

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:50	4:58		4:59	5:02
Foxboro TVA 1000	PID 0.03 ppm	PID 1.19 ppm		PID 0.05 ppm	PID 1.32 ppm
	FID 0.0 ppm	FID 3.77 ppm		FID 0.00 ppm	FID 4.73 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 2.6 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:10
Foxboro TVA 1000	PID 4.23 ppm
	FID 12.11 ppm
Cal.	
Mini RAE 2000	PID 4.0 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.004 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc: 0.201 Mg/m ³

[illegible]



Westgate Air Monitoring Westgate Neighborhood

Date: 8-23-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:25	4:29	4:35	4:40	4:43	4:48
Foxboro TVA 1000	PID 0.022 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.01 ppm
	FID 0.04 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.01 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.02 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.010 Mg/m ³	Conc. 0.116 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.001 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 8-23-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:53	4:56		5:00	5:03
Foxboro TVA 1000	PID 0.01 ppm	PID 0.79 ppm		PID 0.03 ppm	PID 1.07 ppm
	FID 0.00 ppm	FID 0.27 ppm		FID 0.00 ppm	FID 3.02 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:08
Foxboro TVA 1000	PID 3.12 ppm
	FID 9.01 ppm
Cal.	
Mini RAE 2000	PID 1.6 ppm
Cal.	
Jerome 431-X	0.001 Hg Mg/m ³
Jerome 631-X	0.003 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.002 Mg/m ³



Date: 8-26-08

[illegible]



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	4:15	4:18	4:22	4:27	4:33	4:38
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.010 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.007 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 8-26-07

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:45	4:48		4:52	4:56
Foxboro TVA 1000	PID 0.00 ppm	PID 1.05 ppm		PID 0.00 ppm	PID 1.64 ppm
	FID 0.00 ppm	FID 5.47 ppm		FID 0.00 ppm	FID 4.71 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 3.1 ppm		PID 0.0 ppm	PID 2.2 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:03
Foxboro TVA 1000	PID 2.88 ppm
	FID 10.31 ppm
Cal.	
Mini RAE 2000	PID 3.7 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.005 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 223 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-27-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	9:50	9:53	10:00	10:04	10:08	10:13
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.16 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.014 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 8-27-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	2:40	2:45	2:48	2:53	2:58	3:03
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.10 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.06 ppm	FID 0.00 ppm	FID 0.20 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.019 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.014 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 8-27-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	3:08	3:12		3:17	3:20
Foxboro TVA 1000	PID 0.00 ppm	PID 1.36 ppm		PID 0.00 ppm	PID 1.97 ppm
	FID 0.07 ppm	FID 4.15 ppm		FID 0.26 ppm	FID 5.73 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 3.9 ppm		PID 0.0 ppm	PID 3.2 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	3:25
Foxboro TVA 1000	PID 2.13 ppm
	FID 1.85 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.00 Hg Mg/m ³
Jerome 631-X	.007 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.216 Mg/m ³



Date: 8-28-02

[illegible]

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 8-28-07

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	3:45	3:48		3:51	3:55
Foxboro TVA 1000	PID 0.09 ppm	PID 2.11 ppm		PID 0.13 ppm	PID 2.23 ppm
	FID 1.01 ppm	FID 6.27 ppm		FID 0.97 ppm	FID 4.63 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 2.3 ppm		PID 0.3 ppm	PID 1.7 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:00
Foxboro TVA 1000	PID 1.57 ppm
	FID 2.65 ppm
Cal.	
Mini RAE 2000	PID 1.3 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.057 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-29-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Foxboro TVA 1000	10:05 PID 0.00 ppm FID 0.16 ppm	10:08 PID 0.50 ppm FID 0.27 ppm	10:14 PID 0.00 ppm FID 0.03 ppm	10:20 PID 0.00 ppm FID 0.00 ppm	10:25 PID 0.00 ppm FID 0.00 ppm	10:28 PID 0.00 ppm FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MJE PDR 1000	Conc. 0.011 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.131 Mg/m ³	Conc. 0.071 Mg/m ³	Conc. 0.215 Mg/m ³	Conc. 0.008 Mg/m ³
Comments						



Date: 8-29-02

[illegible]



Westgate Air Monitoring Air Filtration System

Date: 8-29-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	5:00	5:03		5:07	5:10
Foxboro TVA 1000	PID 0.76 ppm	PID 0.34 ppm		PID 0.91 ppm	PID 0.17 ppm
	FID 1.11 ppm	FID 1.76 ppm		FID 0.03 ppm	FID 0.67 ppm
Cal.					
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm		PID 0.1 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:15
Foxboro TVA 1000	PID 0.19 ppm
	FID 1.23 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	000 Hg Mg/m ³
Jerome 631-X	002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.00 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 8-30-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	8:40	8:45	8:50	8:55	9:00	9:05
Foxboro TVA 1000	PID 0.16 ppm	PID 0.22 ppm	PID 0.13 ppm	PID 0.62 ppm	PID 0.01 ppm	PID 0.03 ppm
	FID 0.72 ppm	FID 0.45 ppm	FID 0.72 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.16 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.002 H ₂ S ppm	0.002 H ₂ S ppm	0.000 H ₂ S ppm	0.002 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.111 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.072 Mg/m ³	Conc. 0.176 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.009 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 8-30-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	3:15	3:20	3:25	3:30	3:35	3:40
Foxboro TVA 1000	PID 0.13 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.17 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 1.12 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.001 H ₂ S ppm	.002 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 8-30-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	3:45	3:48		3:51	3:55
Foxboro TVA 1000	PID 1.27 ppm	PID 1.00 ppm		PID 0.97 ppm	PID 1.00 ppm
	FID 0.76 ppm	FID 1.72 ppm		FID 1.23 ppm	FID 1.00 ppm
Cal.					
Mini RAE 2000	PID 0.1 ppm	PID 0.1 ppm		PID 0.1 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:05
Foxboro TVA 1000	PID 0.76 ppm
	FID 0.87 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.00 Mg/m ³



Date: 9-2-02

[illegible]



Westgate Air Monitoring Westgate Neighborhood

Date: 9-2-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Foxboro TVA 1000	3:45 pm PID 0.09 ppm FID 0.01 ppm	3:51 pm PID 0.02 ppm FID 0.00 ppm	3:57 pm PID 0.02 ppm FID 0.00 ppm	4:00 pm PID 0.00 ppm FID 0.00 ppm	4:05 pm PID 0.00 ppm FID 0.00 ppm	4:10 pm PID 0.00 ppm FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	1.000 Hg Mg/m ³	1.000 Hg Mg/m ³	1.000 Hg Mg/m ³	1.000 Hg Mg/m ³	1.000 Hg Mg/m ³	1.000 Hg Mg/m ³
Jerome 631-X	1.000 H ₂ S ppm	1.000 H ₂ S ppm	1.000 H ₂ S ppm	1.000 H ₂ S ppm	1.000 H ₂ S ppm	1.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 % O ₂	20.7 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂
Cal.						
MIE PDR 1000	Conc. 0.024 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.034 Mg/m ³	Conc. 0.019 Mg/m ³	Conc. 0.019 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-2-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:13 PM	4:14 PM		4:16 PM	4:18 PM
Foxboro TVA 1000	PID 0.03 ppm	PID 1.16 ppm		PID 0.06 ppm	PID 1.37 ppm
	FID 0.00 ppm	FID 5.47 ppm		FID 0.00 ppm	FID 5.89 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 3.4 ppm		PID 0.0 ppm	PID 3.4 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	4:24
Foxboro TVA 1000	PID 2.15 ppm
	FID 5.79 ppm
Cal.	
Mini RAE 2000	PID 3.10 ^u ppm
Cal.	
Jerome 431-X	1.000 Hg Mg/m ³
Jerome 631-X	1.008 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.002 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.186 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-3-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	10:15 AM	10:30 AM	10:25 AM	10:32 AM	10:30 AM	10:35 AM
Foxboro TVA 1000	PID 0.00 ppm	PID 5.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.004 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.007 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 9-3-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Foxboro TVA 1000	3:50 pm PID 0.03 ppm FID 0.00 ppm	3:55 pm PID 0.04 ppm FID 0.00 ppm	3:59 pm PID 0.02 ppm FID 0.00 ppm	4:04 pm PID 0.00 ppm FID 0.00 ppm	4:10 pm PID 0.00 ppm FID 0.00 ppm	4:14 pm PID 0.00 ppm FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.019 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.010 Mg/m ³	Conc. 0.008 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-30-2

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:19 PM	4:20 PM		4:22 PM	4:27 PM
Foxboro TVA 1000	PID 0.05 ppm	PID 1.25 ppm		PID 0.00 ppm	PID 1.39 ppm
	FID 0.01 ppm	FID 3.34 ppm		FID 0.00 ppm	FID 4.87 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 2.5 ppm		PID 0.0 ppm	PID 3.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:29 PM
Foxboro TVA 1000	PID 2.06 ppm
	FID 4.97 ppm
Cal.	
Mini RAE 2000	PID 3.1 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.09 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.34 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-4-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	9:15	9:18	9:22	9:25	9:30	9:35
Foxboro TVA 1000	PID 0.07 ppm	PID 0.13 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.23 ppm	FID 0.19 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.016 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.113 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.117 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 9-4-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:05	4:08	4:13	4:17	4:22	4:25
Foxboro TVA 1000	PID 0.07 ppm	PID 0.04 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.37 ppm	FID 0.11 ppm	FID 0.19 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.111 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.021 Mg/m ³	Conc. 0.061 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.130 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-4-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:30	4:33		4:35	4:37
Foxboro TVA 1000	PID 0.02 ppm	PID 1.17 ppm		PID 0.01 ppm	PID 1.42 ppm
	FID 0.07 ppm	FID 3.92 ppm		FID 0.04 ppm	FID 4.76 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 2.2 ppm		PID 0.1 ppm	PID 2.9 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:40
Foxboro TVA 1000	PID 1.97 ppm
	FID 2.33 ppm
Cal.	
Mini RAE 2000	PID 3.1 ppm
Cal.	
Jerome 431-X	0.001 Hg Mg/m ³
Jerome 631-X	0.002 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.22 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-5-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:30	4:33	4:37	4:42	4:45	4:48
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.13 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.001 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.016 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-5-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:52	4:55		5:00	5:03
Foxboro TVA 1000	PID 0.12 ppm	PID 1.37 ppm		PID 0.03 ppm	PID 1.21 ppm
	FID 0.27 ppm	FID 3.11 ppm		FID 0.09 ppm	FID 3.46 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 3.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:10
Foxboro TVA 1000	PID 3.23 ppm
	FID 7.40 ppm
Cal.	
Mini RAE 2000	PID 11.2 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.002 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.173 Mg/m ³



Date: 9-6-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
Time	9:20	9:23	9:26	9:29	9:33	9:37
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.01 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 9-6-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:10	4:15	4:20	4:23	4:28	4:32
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.04 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.03 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.03 ppm	FID 0.01 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.02 H ₂ S ppm	0.01 H ₂ S ppm	0.02 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.017 Mg/m ³	Conc. 0.111 Mg/m ³	Conc. 0.119 Mg/m ³	Conc. 0.127 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.003 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date:

9-6-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:38	4:46		4:41	4:43
Foxboro TVA 1000	PID 0.02 ppm	PID 1.11 ppm		PID 0.06 ppm	PID 1.24 ppm
	FID 0.01 ppm	FID 3.82 ppm		FID 0.00 ppm	FID 3.14 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 1.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:50
Foxboro TVA 1000	PID 3.75 ppm
	FID 11.62 ppm
Cal.	
Mini RAE 2000	PID 3.8 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.004 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.136 Mg/m ³



Date: 9-9-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	10:20	10:23	10:27	10:30	10:34	10:38
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.01 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Date: 9-9-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	4:40	4:43	4:47	4:50	4:54	4:57
Foxboro TVA 1000	PID 0.00 ppm	PID 0.06 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.01 ppm	FID 0.01 ppm	FID 0.00 ppm	FID 0.02 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.006 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.003 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-9-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	5:05	5:06		5:08	5:10
Foxboro TVA 1000	PID 0.01 ppm	PID 1.09 ppm		PID 0.04 ppm	PID 1.13 ppm
	FID 0.00 ppm	FID 2.59 ppm		FID 0.00 ppm	FID 3.17 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:20
Foxboro TVA 1000	PID 2.95 ppm
	FID 8.78 ppm
Cal.	
Mini RAE 2000	PID 12.3 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.03 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.00 ppm
	2.09 %O ₂
Cal.	
MIE PDR 1000	Conc 0.154 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
Time	9:40	9:43	9:46	9:49	9:52	9:56
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.06 ppm	FID 0.00 ppm	FID 0.16 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.01 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.01 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.007 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.012 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 9-10-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	3:55	4:00	4:03	4:07	4:10	4:14
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.29 ppm	FID 1.37 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	001 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³
Jerome 631-X	001 H ₂ S ppm	001 H ₂ S ppm	000 H ₂ S ppm	000 H ₂ S ppm	001 H ₂ S ppm	000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.013 Mg/m ³	Conc. 0.020 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.015 Mg/m ³	Conc. 0.007 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9.10.02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:20	4:23		4:26	4:30
Foxboro TVA 1000	PID 0.03 ppm	PID 1.47 ppm		PID 0.02 ppm	PID 1.88 ppm
	FID 0.00 ppm	FID 5.82 ppm		FID 0.01 ppm	FID 5.73 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 3.3 ppm		PID 0.0 ppm	PID 2.4 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:35
Foxboro TVA 1000	PID 2.96 ppm
	FID 12.03 ppm
Cal.	
Mini RAE 2000	PID 4.0 ppm
Cal.	
Jerome 431-X	001 Hg Mg/m ³
Jerome 631-X	004 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.313Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-13-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	11:15	11:18	11:23	11:28	11:32	11:36
Foxboro TVA 1000	PID 0.12 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.24 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.05 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.033 Mg/m ³	Conc. 0.027 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.052 Mg/m ³	Conc. 0.028 Mg/m ³	Conc. 0.008 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 9-13-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
	4:40	4:43	4:47	4:50	4:54	4:58
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.009 Mg/m ³	Conc. 0.112 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.120 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.004 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-13-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.05 ppm	PID 2.10 ppm		PID 0.02 ppm	PID 1.98 ppm
	FID 0.17 ppm	FID 6.37 ppm		FID 0.05 ppm	FID 3.87 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 1.7 ppm		PID 0.0 ppm	PID 1.5 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 2.17 ppm
	FID 5.82 ppm
Cal.	
Mini RAE 2000	PID 2.2 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.005 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.316 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-16-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	9:15	9:18	9:23	9:28	9:32	9:37
Foxboro TVA 1000	PID 0.13 ppm	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.31 ppm	FID 0.09 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.00 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.00 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.01 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.005 Mg/m ³	Conc. 0.018 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.036 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date:

9-16-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:05	4:08	4:12	4:15	4:20	4:25
Foxboro TVA 1000	PID 0.06 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.02 ppm	PID 0.00 ppm
	FID 0.13 ppm	FID 0.00 ppm	FID 0.07 ppm	FID 0.15 ppm	FID 0.18 ppm	FID 0.03 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂
Cal.						
MIE PDR 1000	Conc. 0.071 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.039 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.101 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-16-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:30	4:33		4:35	4:38
Foxboro TVA 1000	PID 0.02 ppm	PID 1.05 ppm		PID 0.00 ppm	PID 2.06 ppm
	FID 0.07 ppm	FID 4.97 ppm		FID 0.03 ppm	FID 4.30 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 0.3 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:45
Foxboro TVA 1000	PID 1.85 ppm
	FID 3.22 ppm
Cal.	
Mini RAE 2000	PID 1.2 ppm
Cal.	
Jerome 431-X	001 Hg Mg/m ³
Jerome 631-X	002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.118 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-18-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	9:05	9:08	9:12	9:15	9:18	9:22
Foxboro TVA 1000	PID 0.07 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.12 ppm	FID 0.09 ppm	FID 0.06 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.003 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.002 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-18-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:30	4:33		4:36	4:40
Foxboro TVA 1000	PID 0.07 ppm	PID 1.22 ppm		PID 0.04 ppm	PID 0.97 ppm
	FID 0.14 ppm	FID 2.39 ppm		FID 0.07 ppm	FID 1.33 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:45
Foxboro TVA 1000	PID 1.93 ppm
	FID 3.03 ppm
Cal.	
Mini RAE 2000	PID 0.4 ppm
Cal.	
Jerome 431-X	000 Hg Mg/m ³
Jerome 631-X	003 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.176 Mg/m ³



Date: 9-19-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	3:45	3:50	3:53	3:57	4:02	4:05
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm	.0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.004 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.008 Mg/m ³	Conc. 0.008 Mg/m ³	Conc. 0.007 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-19-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	4:10	4:13		4:16	4:20
Foxboro TVA 1000	PID 0.06 ppm	PID 2.16 ppm		PID 0.00 ppm	PID 0.85 ppm
	FID 0.09 ppm	FID 3.04 ppm		FID 0.07 ppm	FID 1.36 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.23 ppm
	FID 0.47 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.001 Hg Mg/m ³
Jerome 631-X	.003 H ₂ S ppm
Gastech GT 201	
	.000 % LEL
	.0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.04 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-20-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	3:40	3:43	3:48	3:52	3:56	4:00
Foxboro TVA 1000	PID 0.13 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.02 ppm	PID 0.00 ppm
	FID 0.26 ppm	FID 0.09 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.02 / Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.035 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.00 / Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-20-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:05	4:08		4:10	4:13
Foxboro TVA 1000	PID 0.03 ppm	PID 1.44 ppm		PID 0.00 ppm	PID 1.03 ppm
	FID 0.00 ppm	FID 2.66 ppm		FID 0.00 ppm	FID 3.11 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:20
Foxboro TVA 1000	PID 0.17 ppm
	FID 0.29 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.03 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-23-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Foxboro TVA 1000	8:50 PID 0.00 ppm FID 0.09 ppm	8:53 PID 0.00 ppm FID 0.00 ppm	8:56 PID 0.00 ppm FID 0.00 ppm	8:59 PID 0.00 ppm FID 0.00 ppm	9:04 PID 0.02 ppm FID 0.13 ppm	9:07 PID 0.00 ppm FID 0.01 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.017 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.010 Mg/m ³	Conc. 0.004 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.001 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-23-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:10	4:13		4:16	4:20
Foxboro TVA 1000	PID 0.16 ppm	PID 1.84 ppm		PID 0.01 ppm	PID 1.17 ppm
	FID 0.07 ppm	FID 3.01 ppm		FID 0.06 ppm	FID 2.85 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitor Inside Structure

	Sample Point Inside Structure
Time	4:25
Foxboro TVA 1000	PID 0.97 ppm
	FID 1.26 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	000 Hg Mg/m ³
Jerome 631-X	002 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc 0.14/Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date:

9-24-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Foxboro TVA 1000	PID 0.11 ppm FID 0.53 ppm	PID 0.09 ppm FID 0.16 ppm	PID 0.13 ppm FID 0.07 ppm	PID 0.01 ppm FID 0.10 ppm	PID 0.00 ppm FID 0.00 ppm	PID 0.07 ppm FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³	PID 0.00 Hg Mg/m ³
Jerome 631-X	PID 0.01 H ₂ S ppm % LEL	PID 0.01 H ₂ S ppm % LEL	PID 0.01 H ₂ S ppm % LEL	PID 0.01 H ₂ S ppm % LEL	PID 0.01 H ₂ S ppm % LEL	PID 0.01 H ₂ S ppm % LEL
Gastech GT 201	PID 0.00 ppm 20.9 %O ₂	PID 0.00 ppm 20.9 %O ₂	PID 0.00 ppm 20.9 %O ₂	PID 0.00 ppm 20.9 %O ₂	PID 0.00 ppm 20.9 %O ₂	PID 0.00 ppm 20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.022 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.027 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.003 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-24-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:50	4:53		4:56	4:58
Foxboro TVA 1000	PID 0.02 ppm	PID 0.16 ppm		PID 0.01 ppm	PID 0.27 ppm
	FID 0.07 ppm	FID 0.37 ppm		FID 0.00 ppm	FID 0.06 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:05
Foxboro TVA 1000	PID 0.39 ppm
	FID 1.07 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	.000 Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.101 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	4:20	4:25	4:28	4:33	4:37	4:40
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.01 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.16 ppm	FID 0.00 ppm	FID 0.19 ppm	FID 0.00 ppm	FID 0.07 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³	000 Hg Mg/m ³
Jerome 631-X	000 H ₂ S ppm	000 H ₂ S ppm	001 H ₂ S ppm	000 H ₂ S ppm	000 H ₂ S ppm	000 H ₂ S ppm
Gastech GT 201	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL	000 % LEL
	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm	0000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.008 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.037 Mg/m ³	Conc. 0.014 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.007 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date:

9-25-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	4:45	4:48		4:50	4:53
Foxboro TVA 1000	PID 0.06 ppm	PID 0.59 ppm		PID 0.04 ppm	PID 1.13 ppm
	FID 0.19 ppm	FID 1.35 ppm		FID 0.20 ppm	FID 1.93 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	4:58
Foxboro TVA 1000	PID 0.41 ppm
	FID 0.88 ppm
Cal.	
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	0.00 Hg Mg/m ³
Jerome 631-X	0.002 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.053 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-26-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	3:00	3:03	3:06	3:10	3:13	3:17
Foxboro TVA 1000	PID 0.00 ppm	PID 0.09 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.17 ppm	FID 0.05 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.001 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.027 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.008 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-26-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
	3:25	3:28		3:30	3:32
Foxboro TVA 1000	PID 0.01 ppm	PID 1.03 ppm		PID 0.02 ppm	PID 0.81 ppm
	FID 0.05 ppm	FID 0.16 ppm		FID 0.07 ppm	FID 0.88 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
	3:40
Foxboro TVA 1000	PID 1.14 ppm
	FID 3.01 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	0000 Hg Mg/m ³
Jerome 631-X	001 H ₂ S ppm
Gastech GT 201	
	000 % LEL
	0000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.031 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 9-27-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	4:40	4:43	4:46	4:50	4:53	4:56
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.01 ppm	PID 0.00 ppm	PID 0.03 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.00 Hg Mg/m ³	0.000 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.000 H ₂ S ppm	0.001 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.007 Mg/m ³	Conc. 0.016 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.412 Mg/m ³	Conc. 0.010 Mg/m ³

Comments



BBC INTERNATIONAL

Westgate Air Monitoring Air Filtration System

Date: 9-27-02

	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Time	5:03	5:06		5:09	5:12
Foxboro TVA 1000	PID 0.07 ppm	PID 1.84 ppm		PID 0.01 ppm	PID 0.42 ppm
	FID 0.02 ppm	FID 1.56 ppm		FID 0.00 ppm	FID 0.09 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm		PID 0.0 ppm	PID 0.1 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

	Sample Point Inside Structure
Time	5:15
Foxboro TVA 1000	PID 1.06 ppm
	FID 1.33 ppm
Cal.	
Mini RAE 2000	PID 1.0 ppm
Cal.	
Jerome 431-X	.000Hg Mg/m ³
Jerome 631-X	.001 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.018 Mg/m ³



	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
Time	4:05	4:08	4:13	4:15	4:18	4:23
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.005 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.103 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.004 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 9-30-02

Time	Sample Point Unit #1A (outlet)	Sample Point #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.06 ppm	PID 0.97 ppm	PID	PID 0.01 ppm	PID 1.02 ppm
Cal.	FID 0.10 ppm	FID 1.21 ppm	FID	FID 0.05 ppm	FID 0.86 ppm
Mini RAE 2000	PID 0.0 ppm	PID 0.1 ppm	PID	PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 0.93 ppm
Cal.	FID 1.30 ppm
Mini RAE 2000	PID 0.1 ppm
Cal.	
Jerome 431-X	0.000 Hg Mg/m ³
Jerome 631-X	0.001 H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.213 Mg/m ³



Westgate Air Monitoring Westgate Neighborhood

Date: 10-1-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
Time	3:35	3:40	3:43	3:47	3:52	3:55
Foxboro TVA 1000	PID 0.03 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.12 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.007 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.114 Mg/m ³	Conc. 0.006 Mg/m ³	Conc. 0.031 Mg/m ³
Comments						



Westgate Air Monitoring Air Filtration System

Date: 10-1-02

Time	Sample Point Unit #1A (outlet)	Sample Point Unit #1B (inlet)	Unit	Sample Point Unit #2A (outlet)	Sample Point Unit #2B (inlet)
Foxboro TVA 1000	PID 0.04 ppm	PID 0.57 ppm		PID 0.00 ppm	PID 0.38 ppm
	FID 0.09 ppm	FID 0.77 ppm		FID 0.00 ppm	FID 0.62 ppm
Cal.					
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm		PID 0.0 ppm	PID 0.0 ppm
Cal.					
Comment:					

Westgate Air Monitoring Inside Structure

Time	Sample Point Inside Structure
Foxboro TVA 1000	PID 1.31 ppm
	FID 2.01 ppm
Cal.	
Mini RAE 2000	PID 0.0 ppm
Cal.	
Jerome 431-X	0.000 Hg/m ³
Jerome 631-X	0.00 / H ₂ S ppm
Gastech GT 201	
	0.00 % LEL
	0.000 ppm
	20.9 %O ₂
Cal.	
MIE PDR 1000	Conc. 0.034 Mg/m ³



Date: 10-2-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Tum-a-round	Sample Point Background - GMW-7
Time	4:45	4:48	4:52	4:55	5:00	5:03
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.00 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.001 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL	.000 % LEL
	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm	.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.00/Mg/m ³	Conc. 0.017 Mg/m ³	Conc. 0.003Mg/m ³	Conc. 0.012Mg/m ³	Conc. 0.000Mg/m ³	Conc. 0.000Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

10-3-02
Date: 10-3-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	11:15	11:20	11:25	11:30	11:35	11:40
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.26 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Date: 10-4-02

	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Time	11:44	11:46	11:50	11:55	11:58	12:00
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.45 ppm	FID 0.00 ppm	FID 0.06 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.002 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.004 Mg/m ³
Comments						



Date: 10-7-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	3:20	3:21	3:25	3:30	3:33	3:39
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.06 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.29 ppm	FID 0.16 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.002 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.011 Mg/m ³	Conc. 0.007 Mg/m ³	Conc. 0.003 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 10-8-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-around	Sample Point Background - GMW-7
	2:55 pm	3:00 pm	3:02 pm	3:05 pm	3:10 pm	3:13 pm
Foxboro TVA 1000	PID 0.03 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.01 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.00 ppm	FID 0.07 ppm	FID 0.18 ppm	FID 0.20 ppm	FID 0.09 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.00 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³	.000 Hg Mg/m ³
Jerome 631-X	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm	.000 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.001 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.005 Mg/m ³	Conc. 0.001 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 10-9-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
Foxboro TVA 1000	1:55 PM PID 0.00 ppm FID 0.00 ppm	1:58 PM PID 0.06 ppm FID 0.00 ppm	2:03 PM PID 0.00 ppm FID 0.00 ppm	2:07 PM PID 0.00 ppm FID 0.00 ppm	2:11 PM PID 0.00 ppm FID 0.00 ppm	2:14 PM PID 0.09 ppm FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³	0.00 Hg Mg/m ³
Jerome 631-X	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm	0.00 H ₂ S ppm
Gastech GT 201	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL	0.00 % LEL
	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm	0.00 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.017 Mg/m ³	Conc. 0.013 Mg/m ³	Conc. 0.020 Mg/m ³	Conc. 0.009 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 10-10-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Tum-a-round	Sample Point Background - GMW-7
	2:30 PM	2:32 PM	2:36 PM	2:40	2:44 PM	2:50 PM
Foxboro TVA 1000	PID 0.40 ppm	PID 0.50 ppm	PID 0.42 ppm	PID 0.09 ppm	PID 0.15 ppm	PID 0.14 ppm
	FID 0.51 ppm	FID 0.56 ppm	FID 0.57 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂	20.9 % O ₂
Cal.						
MIE PDR 1000	Conc. 0.007 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						



Westgate Air Monitoring Westgate Neighborhood

Date: 12-11-02

Time	Sample Point #1 1701 San Andres	Sample Point #2 1412 Berry	Sample Point #3 1401 Tasker	Sample Point #4 GMW-10	Sample Point #5 Bus Turn-a-round	Sample Point Background - GMW-7
	3:00 PM	3:05 PM	3:08 PM	3:12 PM	3:15 PM	3:20 PM
Foxboro TVA 1000	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm	PID 0.00 ppm
	FID 0.00 ppm	FID 0.07 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm	FID 0.00 ppm
Cal.						
Mini RAE 2000	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.0 ppm	PID 0.00 ppm	PID 0.0 ppm
Cal.						
Jerome 431-X	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³	0.000 Hg Mg/m ³
Jerome 631-X	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm	0.000 H ₂ S ppm
Gastech GT 201	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL	0.000 % LEL
	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm	0.000 ppm
	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂	20.9 %O ₂
Cal.						
MIE PDR 1000	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³	Conc. 0.000 Mg/m ³
Comments						