Form 3160-5 (June 2015)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018

SUNDRY NOTICES AND REPORTS ON WELLS

Lease Serial No. NMNM13276

abandoned well. Use form 3160-3 (APD) for such proposals.				6. If Indian, Allottee or	Tribe Name
SUBMIT IN TRIPLICATE - Other instructions on page 2					
1. Type of Well ☐ Oil Well ☐ Gas Well ☐ Other 2. Name of Operator Contact: MATT DICKSON				8. Well Name and No. HAMON FED COM A 12H 9. API Well No.	
LEGACY RESERVES OPERATING LPE-Mail: mdickson@legacylp.com				30-025-43253	
3a. Address 303 W WALL ST STE 1800 MIDLAND, TX 79701	one No. (include area code) 32-689-5200 Ext: 5204	1	10. Field and Pool or Exploratory Area TEAS; BONE SPRING, EAST		
4. Location of Well (Footage, Sec., T.			11. County or Parish, State		
Sec 18 T20S R34E NWNW 32			LEA CO COUNTY, NM		
12. CHECK THE AF	PPROPRIATE BOX(ES) TO INI	DICATE NATURE O	F NOTICE, I	REPORT, OR OTH	ER DATA
TYPE OF SUBMISSION	TYPE OF ACTION				
Notice of Intent	☐ Acidize ☐	Deepen	☐ Production	on (Start/Resume)	■ Water Shut-Off
	☐ Alter Casing	Hydraulic Fracturing	□ Reclamat	tion	■ Well Integrity
☐ Subsequent Report	☐ Casing Repair	New Construction	☐ Recompl	ete	Other
☐ Final Abandonment Notice		Plug and Abandon	□ Tempora	rily Abandon	
	☐ Convert to Injection	Plug Back	☐ Water Di	sposal	
If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection. Legacy Reserves Operating respectfully request approval to add an additional option for the intermediate casing cement procedures. This option would allow for a three-stage cement job utilizing two DV tools. Both DV tools shall be set a minimum of 50 feet below the previous casing shoe and a minimum of 200 feet above the current shoe and adjust cement proportionately based on placement. Please see the following update to the cementing details for a three-stage cement job. 14. I hereby certify that the foregoing is true and correct.					
Electronic Submission #379707 verified by the BLM Well Information System For LEGACY RESERVES OPERATING LP, sent to the Hobbs					
Name (Printed/Typed) MATT DIC	Title DRILLIN	Title DRILLING ENGINEER			
Signature (Electronic S	Date 06/23/20)17			
THIS SPACE FOR FEDERAL OR STATE OFFICE USE					
_Approved_By	Title			Date	
Conditions of approval, if any, are attached certify that the applicant holds legal or equivalent would entitle the applicant to condu-					

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

Hamon #12H

Intermediate Casing

In the event that circulation is lost (> 50%) while drilling the 12-1/4" intermediate hole in the Capitan Reef at +/-4000', we will plan to install a DV tool and external casing packer within 200' of the top depth where lost circulation occurred and will pump a two-stage cement job with the potential to add an additional DV tool for a three-stage cement job. If there is no lost circulation a single stage cementing procedure will be followed. Legacy plans to cement to surface regardless of whether a single stage, 2-stage or 3-stage procedure is implemented.

No DV tool (80% excess on lead & 80% excess on tail to design for cement top at surface)

<u>Lead:</u> 1400 sx (35:65) poz (fly ash) class C cement+ 4% bwoc bentonite II + 5% bwoc MPA-5 + 0.25% bwoc FL- 52 + 5 lbs/sack LCM-1 + 0.125 lbs/sk cello flake+ 0.005 lbs/sk defoamer + 0.005 gps FP-6L + 1.2% bwoc Sodium Metasilicate + 5% bwow Sodium Chloride (12.5 ppg, 2.13 cfps, 8.81 gps wtr)

<u>Tail:</u> 200 sx class C cement (14.80 ppg, 1.33 cfps, 6.35 gps wtr)

With (1) DV Tool (100% excess on lead & 100% excess on tail to design for cement top at surface)

Assuming DV tool set at 3950' but if the setting depth changes, cement volumes will be adjusted proportionately.

Stage 1

<u>Lead:</u> 400 sx (35:65) paz (fly ash) class C cement+ 4% bwoc Bentonite II+ 5% bwoc MPA-5 + 0,25% bwoc FL-52 + 5 lbs/sack LCM-1 + 0.125 lbs/sk cello flake+ 0.005 lbs/sk defoamer + 0.005 gps FP-6L + 1.2% bwoc Sodium Metasilicate + 5% bwow Sodium Chloride (12.5 ppg, 2.13 cfps, 8.81 gps wtr)

Tail: 200 sx class C cement (14.80 ppg, 1.33 cfps, 6.35 gps wtr)

Stage 2

<u>Lead</u>: 1100 sx (35:65) paz (fly ash) class C cement+ 4% bwoc bentonite II + 5% bwoc MPA-5 + 0,25% bwoc FL-52 + 5 lbs/sack LCM-1 + 0.125 lbs/sk Cello Flake+ 0.005 lbs/sk Static Free+ 0.005 gps FP-6L + 1.2% bwoc Sodium Metasilicate + 5% bwow Sodium Chloride (12.5 ppg, 2.13 cfps, 8.81 gps wtr)

Tail: 200 sx class C cement (14.80 ppg, 1.33 cfps, 6.35 gps wtr)

With (2) DV Tools (100% excess on lead & 100% excess on tail to design for cement top at surface)

Assuming one DV tool set at 3950' and one DV tool set at 1800' but if the setting depths change, cement volumes will be adjusted proportionately.

Stage 1

<u>Lead:</u> 400 sx (35:65) paz (fly ash) class C cement+ 4% bwoc Bentonite II+ 5% bwoc MPA-5 + 0,25% bwoc FL-52 + 5 lbs/sack LCM-1 + 0.125 lbs/sk cello flake+ 0.005 lbs/sk defoamer + 0.005 gps FP-6L + 1.2% bwoc Sodium Metasilicate + 5% bwow Sodium Chloride (12.5 ppg, 2.13 cfps, 8.81 gps wtr)

<u>Tail:</u> 200 sx class C cement (14.80 ppg, 1.33 cfps, 6.35 gps wtr)

Stage 2

<u>Lead</u>: 600 sx (35:65) paz (fly ash) class C cement+ 4% bwoc bentonite II + 5% bwoc MPA-5 + 0,25% bwoc FL-52 + 5 lbs/sack LCM-1 + 0.125 lbs/sk Cello Flake+ 0.005 lbs/sk Static Free+ 0.005 gps FP-6L + 1.2% bwoc Sodium Metasilicate + 5% bwow Sodium Chloride (12.5 ppg, 2.13 cfps, 8.81 gps wtr)

Tail: 200 sx class C cement (14.80 ppg, 1.33 cfps, 6.35 gps wtr)

Stage 3

<u>Lead</u>: 600 sx (35:65) paz (fly ash) class C cement+ 4% bwoc bentonite II + 5% bwoc MPA-5 + 0,25% bwoc FL-52 + 5 lbs/sack LCM-1 + 0.125 lbs/sk Cello Flake+ 0.005 lbs/sk Static Free+ 0.005 gps FP-6L + 1.2% bwoc Sodium Metasilicate + 5% bwow Sodium Chloride (12.5 ppg, 2.13 cfps, 8.81 gps wtr)

Tail: 200 sx class C cement (14.80 ppg, 1.33 cfps, 6.35 gps wtr)

Matt Dickson Drilling Engineer (432)689-5204 mdickson@legacylp.com