Submit 1 Copy To Appropriate District	State of New Mexico	Form C-103
Office District I	Energy, Minerals and Natural Res	ources October 13, 2009
1625 N. French Dr., Hobbs, NM 88240		WELL API NO.
<u>District II</u> 1301 W. Grand Ave., Artesia, NM 88210	OIL CONSERVATION DIVI	SION 30-025-05642
District III	1220 South St. Francis Dr	5. Indicate Type of Lease STATE FEE
1000 Rio Brazos Rd., Aztec, NM 87410	Santa Fe, NM 87505	6. State Oil & Gas Lease No.
<u>District IV</u> 1220 S. St. Francis Dr., Santa Fe, NM 87505		o. State on & Gas Lease No.
	ES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
1 '	ALS TO DRILL OR TO DEEPEN OR PLUG BAC	•
PROPOSALS.)	ATION FOR PERMIT" (FORM C-101) FOR SUCH	North Monument G/SA Unit Blk. 5
	Gas Well 🔲 Other Injection well. 🧥	8. Well Number 5
2. Name of Operator	Sas Well Other Injection well.  Sas Well Other Injection well.	9. OGRID Number 873
Apache Corp.	HODE	8 10 5 1 10 10 10 10 10 10 10 10 10 10 10 10 1
3. Address of Operator  PO box Drawer D Monument NM 8	30 20	10. Pool name or Wildcat North Monument G/SA
·	30203 JUL	North Wollument G/SA
4. Well Location	LICEN CENT	
Unit LetterE_:_	1980feet from the	_ line and660feet from the
Wline		
Section 19	Township 19S Ran	ge 37E NMPM Lea County
	11. Elevation (Show whether DR, RKB, I	PT, GR, etc.)
10 (1 1 4	t a December 11 to NI to	CM d' D d Od D d
12. Check A	opropriate Box to Indicate Nature	of Notice, Report or Other Data
NOTICE OF INT	ENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK	I	DIAL WORK ALTERING CASING
TEMPORARILY ABANDON	<del>-</del> I	MENCE DRILLING OPNS. P AND A
PULL OR ALTER CASING	MULTIPLE COMPL   CASI	IG/CEMENT JOB
DOWNHOLE COMMINGLE	_	
	_	,
OTHER:		R: 5 year pressure test /
13 Describe proposed or comple	ted operations. (Clearly state all pertinen	t details, and give pertinent dates, including estimated date
13. Describe proposed or complete of starting any proposed wor	ted operations. (Clearly state all pertinents). SEE RULE 19.15.7.14 NMAC. For I	t details, and give pertinent dates, including estimated date fultiple Completions: Attach wellbore diagram of
of starting any proposed wor	k). SEE RULE 19.15.7.14 NMAC. For I	t details, and give pertinent dates, including estimated date fulltiple Completions: Attach wellbore diagram of
13. Describe proposed or complete of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For I	t details, and give pertinent dates, including estimated date fultiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion.	Multiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion.	t details, and give pertinent dates, including estimated date fultiple Completions: Attach wellbore diagram of the casing to 450 psi & recorded the test on a chart for 33
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion.	Multiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion.	Multiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion.	Multiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion.	Multiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion.	Multiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion.	Multiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion.	Multiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion.	Multiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion.	Multiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion. erform pressure test on casing. Pressured	Multiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion.	Multiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco	k). SEE RULE 19.15.7.14 NMAC. For Impletion. erform pressure test on casing. Pressured	Multiple Completions: Attach wellbore diagram of
of starting any proposed wor proposed completion or reco  Moved in Maclaskey pump truck to p minutes with a 20 lb. loss to 430 psi.  Spud Date:	k). SEE RULE 19.15.7.14 NMAC. For Impletion.  erform pressure test on casing. Pressured  Rig Release Date:	Multiple Completions: Attach wellbore diagram of the casing to 450 psi & recorded the test on a chart for 33
of starting any proposed wor proposed completion or reco  Moved in Maclaskey pump truck to p minutes with a 20 lb. loss to 430 psi.  Spud Date:	k). SEE RULE 19.15.7.14 NMAC. For Impletion. erform pressure test on casing. Pressured	Multiple Completions: Attach wellbore diagram of the casing to 450 psi & recorded the test on a chart for 33
of starting any proposed wor proposed completion or reco  Moved in Maclaskey pump truck to p minutes with a 20 lb. loss to 430 psi.  Spud Date:	k). SEE RULE 19.15.7.14 NMAC. For Impletion.  erform pressure test on casing. Pressured  Rig Release Date:	Multiple Completions: Attach wellbore diagram of the casing to 450 psi & recorded the test on a chart for 33 y knowledge and belief.
of starting any proposed wor proposed completion or reco  Moved in Maclaskey pump truck to p minutes with a 20 lb. loss to 430 psi.  Spud Date:	k). SEE RULE 19.15.7.14 NMAC. For Impletion.  erform pressure test on casing. Pressured  Rig Release Date:	Multiple Completions: Attach wellbore diagram of the casing to 450 psi & recorded the test on a chart for 33
of starting any proposed wor proposed completion or reco  Moved in Maclaskey pump truck to p minutes with a 20 lb. loss to 430 psi.  Spud Date:  I hereby certify that the information a SIGNATURE	Rig Release Date:  TITLEInstrumen	Aultiple Completions: Attach wellbore diagram of the casing to 450 psi & recorded the test on a chart for 33 y knowledge and belief.
of starting any proposed wor proposed completion or reco  Moved in Maclaskey pump truck to p minutes with a 20 lb. loss to 430 psi.  Spud Date:  I hereby certify that the information a SIGNATURE  Type or print nameJim Ellison	Rig Release Date:  TITLEInstrumen	Multiple Completions: Attach wellbore diagram of the casing to 450 psi & recorded the test on a chart for 33 y knowledge and belief.
of starting any proposed wor proposed completion or reco  Moved in Maclaskey pump truck to p minutes with a 20 lb. loss to 430 psi.  Spud Date:  I hereby certify that the information a SIGNATURE	Rig Release Date:    Doye is true and complete to the best of mail address: _JD.	Aultiple Completions: Attach wellbore diagram of the casing to 450 psi & recorded the test on a chart for 33 by knowledge and belief.  Tech
of starting any proposed wor proposed completion or reco  Moved in Maclaskey pump truck to p minutes with a 20 lb. loss to 430 psi.  Spud Date:  I hereby certify that the information a SIGNATURE  Type or print name Jim Ellison For State Use Only	Rig Release Date:    Doye is true and complete to the best of mail address: _JD.	Aultiple Completions: Attach wellbore diagram of the casing to 450 psi & recorded the test on a chart for 33 by knowledge and belief.  Tech
of starting any proposed wor proposed completion or reco  Moved in Maclaskey pump truck to p minutes with a 20 lb. loss to 430 psi.  Spud Date:  I hereby certify that the information a SIGNATURE  Type or print nameJim Ellison	Rig Release Date:    Doye is true and complete to the best of mail address: _JD.	Aultiple Completions: Attach wellbore diagram of the casing to 450 psi & recorded the test on a chart for 33 y knowledge and belief.

