Submit 1 Copy To Appropriate District Office	State of New Me Energy, Minerals and Natu		Form C-103 Revised July 18, 2013	
<u>District 1</u> – (575) 393-6161 Energy, Minerals and Natural Resources 1625 N. French Dr., Hobbs, NM 88240		WELL API NO.	٦	
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVISION		<u>30-025-23460</u>	4
District 111 - (505) 334-6178	1220 South St. Francis Dr.		5. Indicate Type of Lease STATE X FEE	
1000 Rio Brazos Rd., Aztec, NM 87410 District IV - (505) 476-3460			6. State Oil & Gas Lease No.	1
1220 S. St. Francis Dr., Santa Fe, NM 87505			312479	
SUNDRY NOTICES AND REPORTS ON WELLS		7. Lease Name or Unit Agreement Name	1	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH				
PROPOSALS.)		NORTH VAC ABO UNIT 8. Well Number	-	
1. Type of Well: Oil Well Gas Well Other INI		135	4	
2. Name of Operator CROSS TIMBERS ENERGY, LLC		9. OGRID Number 298299		
3. Address of Operator		10. Pool name or Wildcat		
400 W 7TH STREET, FORT WORTH, TX 76109		VACUUM: ABO, NORTH		
4. Well Location				٦
Unit Letter <u>L</u> : <u>1980</u> feet from the <u>S</u> line and <u>860</u> feet from the <u>W</u> line				
Section 11 Township 17-S Range 34-E NMPM County LEA				
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 4040 GR				
<u>n an an</u>			·····	
12. Check	Appropriate Box to Indicate N	ature of Notice,	Report or Other Data	
NOTICE OF INTENTION TO: SUB			SEQUENT REPORT OF:	
PERFORM REMEDIAL WORK 🖾 PLUG AND ABANDON 🔲 🔰 REMEDIAL WOR			— — —	
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DR				
PULL OR ALTER CASING		Т ЈОВ		
CLOSED-LOOP SYSTEM				
OTHER:		OTHER:		_
 Describe proposed or comp of starting any proposed w proposed completion or re- 	ork). SEE RULE 19.15.7.14 NMAC	C. For Multiple Co	d give pertinent dates, including estimated date mpletions: Attach wellbore diagram of Condition of Approval: notily	te
Plan to MIRU 7/8/19		OCD Hobbs office 24 hours		
			rior of running MIT Test & Chart	
 D BB, GB, RB tog. Replace w/ 2-3/8 YB or better RBIH w/ Tbg String and redressed packer (or new packer, if needed). Test in the hole. 				
 3) Set packer at previous depth of 8511'. Pressure test backside to 350 psi. 				
4) Release from on/off tool. Circulate backside with packer fluid. Latch back in to packer. Contact				
	test per OCD representative's of	-		
			· · · · · · · · · · · · · · · · · · ·	
Spud Date: 05/19/1970 Rig Release Date: 06/16/1970				
I hereby certify that the information	above is true and complete to the b	est of my knowledg	ze and helief	-
SIGNATURE	a Anila_ TITLE Regul	atory Technicia	nDATE06/11/2019	
Type or print name Samanntha A		•	partners.com PHONE: <u>817-334-7747</u>	
For State Use Only				
APPROVED BY: Kenny Fut TITLE Compliance Office Addate 6-17-19 Conditions of Approval (if any)				
Conditions of Approval (if any)				