Submit 3 Copies To Appropriate District Office	State of New M			Form C-103
District I	Energy, Minerals and Nat	ural Resources	WELL API NO.	May 27, 2004
1625 N. French Dr., Hobbs, NM 88240 District II			30-025-08974	
District II 1301 W. Grand Ave., Artesia, NM 88210 District III 1301 W. Grand Ave., Artesia, NM 88210 1220 South St. Francis Dr.		5. Indicate Type of Le	ase	
1000 Rio Brazos Rd., Aztec, NM 87410		STATE	FEE	
<u>District IV</u> 1220 S. St. Francis Dr., Santa Fe, NM 87505	S. St. Francis Dr., Santa Fe, NM		6. State Oil & Gas Lea 025432	ase No.
SUNDRY NOTICES AND REPORTS ON WELLS			7. Lease Name or Uni	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		SOUTH EUNICE UNI	T	
1. Type of Well: Oil Well Gas Well Other (Injection)			8. Well Number 32	
2. Name of Operator BRECK OPERATING CORP.			9. OGRID Number 002799	
3. Address of Operator		10. Pool name or Wildcat		
P.O. BOX 911, BRECKENRIDGE, TEXAS 76424		EUNICE 7 RIVERS QUEEN, SO		
4. Well Location				
Unit Letter M:	660 feet from the SOUT			EST line
Section 21	Township 22S	Range 36E		County
	11. Elevation (Show whether DI	R, RKB, RT, GR, etc.)	2 (San 1)	
Pit or Below-grade Tank Application	or Closure 🔲		i value accessor	
Pit type Depth to Groundw	vaterDistance from nearest fresh	water well Dista	ance from nearest surface wa	iter
Pit Liner Thickness: mil	Below-Grade Tank: Volume	bbls; Con	nstruction Material	
12. Check	Appropriate Box to Indicate N	Nature of Notice.	Report or Other Data	a
	• •		•	
<u> </u>	ITENTION TO:		SEQUENT REPOR	
PERFORM REMEDIAL WORK TEMPORARILY ABANDON	PLUG AND ABANDON ☐ CHANGE PLANS ☐	REMEDIAL WORK		ERING CASING, ☐ ND A 🛣
 -		CASING/CEMENT		
PULL OR ALTER CASING 1-1	MULTIPLE COMPL 1 1	I CASING/CEMENT	JUD II	
PULL OR ALTER CASING	MULTIPLE COMPL		JOB []	_
OTHER:		OTHER:		aluding actimated data
OTHER: 13. Describe proposed or comp	oleted operations. (Clearly state all ork). SEE RULE 1103. For Multip	OTHER: pertinent details, and	give pertinent dates, inc	
OTHER: 13. Describe proposed or compof starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we	oleted operations. (Clearly state all ork). SEE RULE 1103. For Multip WL to 3532'. Called NMOCD. Tal 1/80 B/W + 20 sxs mud. Mixed 25:	OTHER: pertinent details, and ple Completions: Att	give pertinent dates, incach wellbore diagram of z, he said to spot 25 sx (f proposed completion Class "C" cement
OTHER: 13. Describe proposed or compof starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021'	oleted operations. (Clearly state all ork). SEE RULE 1103. For Multiple WL to 3532'. Called NMOCD. Tally/80 B/W + 20 sxs mud. Mixed 25 st.	OTHER: pertinent details, and ple Completions: Att	give pertinent dates, incach wellbore diagram of z, he said to spot 25 sx 0 well well with the said to spot 25 sx 0 well well with the said to spot 25 sx 0 well well well well well well well we	f proposed completion Class "C" cement 12'. Spot 25 sxs
OTHER: 13. Describe proposed or compost of starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021' 9-06-06 Spot 25 sxs Class "C" cement	oleted operations. (Clearly state all ork). SEE RULE 1103. For Multipular WL to 3532'. Called NMOCD. Tally/80 B/W + 20 sxs mud. Mixed 25 cent @ 1418'. Perforate @ 562'. Raforate @ 312'. Pressure 500#, relea	OTHER: pertinent details, and ple Completions: Att k to Speedy Gonzales sxs Class "C" cement n packer 400'. Pressu	z, he said to spot 25 sx 0 welloor. Tag plug @ 34 are to 500#, release press	f proposed completion Class "C" cement 12'. Spot 25 sxs sure. Spot 25 sx
OTHER: 13. Describe proposed or compost of starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021' 9-06-06 Spot 25 sxs Class "C" cement @ 616'. WOC @ 450'. Per	oleted operations. (Clearly state all ork). SEE RULE 1103. For Multipular WL to 3532'. Called NMOCD. Tally/80 B/W + 20 sxs mud. Mixed 25 cent @ 1418'. Perforate @ 562'. Raforate @ 312'. Pressure 500#, relea	OTHER: pertinent details, and ple Completions: Att k to Speedy Gonzales sxs Class "C" cement n packer 400'. Pressu	z, he said to spot 25 sx 0 welloor. Tag plug @ 34 are to 500#, release press	f proposed completion Class "C" cement 12'. Spot 25 sxs sure. Spot 25 sx
OTHER: 13. Describe proposed or compost of starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021' 9-06-06 Spot 25 sxs Class "C" cement @ 616'. WOC @ 450'. Per	oleted operations. (Clearly state all ork). SEE RULE 1103. For Multipular WL to 3532'. Called NMOCD. Tally/80 B/W + 20 sxs mud. Mixed 25 cent @ 1418'. Perforate @ 562'. Raforate @ 312'. Pressure 500#, relea	OTHER: pertinent details, and ple Completions: Att k to Speedy Gonzales sxs Class "C" cement n packer 400'. Pressu	z, he said to spot 25 sx 0 welloor. Tag plug @ 34 are to 500#, release press	f proposed completion Class "C" cement 12'. Spot 25 sxs sure. Spot 25 sx
OTHER: 13. Describe proposed or compof starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021' 9-06-06 Spot 25 sxs Class "C" cement @ 616'. WOC @ 450'. Per 9-27-06 Cut off wellhead 3' below	oleted operations. (Clearly state all ork). SEE RULE 1103. For Multiply WL to 3532'. Called NMOCD. Tally 1/80 B/W + 20 sxs mud. Mixed 25 states. ent @ 1418'. Perforate @ 562'. Raforate @ 312'. Pressure 500#, releaseurface. Install Dry Hole Marker.	OTHER: pertinent details, and ple Completions: Att k to Speedy Gonzales sxs Class "C" cement n packer 400'. Pressu	z, he said to spot 25 sx 0 welloor. Tag plug @ 34 are to 500#, release press	f proposed completion Class "C" cement 12'. Spot 25 sxs sure. Spot 25 sx
OTHER: 13. Describe proposed or compof starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021' 9-06-06 Spot 25 sxs Class "C" cemer @ 616'. WOC @ 450'. Per 9-27-06 Cut off wellhead 3' below	pleted operations. (Clearly state all ork). SEE RULE 1103. For Multiple WL to 3532'. Called NMOCD. Tally 1/80 B/W + 20 sxs mud. Mixed 25 state of the well and the surface. Install Dry Hole Marker.	OTHER: pertinent details, and ple Completions: Att k to Speedy Gonzales sxs Class "C" cement n packer 400'. Pressu	z, he said to spot 25 sx 0 welloor. Tag plug @ 34 are to 500#, release press	f proposed completion Class "C" cement 12'. Spot 25 sxs sure. Spot 25 sx
OTHER: 13. Describe proposed or compost of starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021'. 9-06-06 Spot 25 sxs Class "C" cement @ 616'. WOC @ 450'. Per 9-27-06 Cut off wellhead 3' below.	oleted operations. (Clearly state all ork). SEE RULE 1103. For Multiply WL to 3532'. Called NMOCD. Tally 1/80 B/W + 20 sxs mud. Mixed 25 states. ent @ 1418'. Perforate @ 562'. Raforate @ 312'. Pressure 500#, releaseurface. Install Dry Hole Marker.	OTHER: pertinent details, and ple Completions: Att k to Speedy Gonzales sxs Class "C" cement n packer 400'. Pressu	z, he said to spot 25 sx 0 welloor. Tag plug @ 34 are to 500#, release press	f proposed completion Class "C" cement 12'. Spot 25 sxs sure. Spot 25 sx
OTHER: 13. Describe proposed or compost of starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021'. 9-06-06 Spot 25 sxs Class "C" cement @ 616'. WOC @ 450'. Per 9-27-06 Cut off wellhead 3' below.	bleted operations. (Clearly state all ork). SEE RULE 1103. For Multiple WL to 3532'. Called NMOCD. Tally 80 B/W + 20 sxs mud. Mixed 25 states. ent @ 1418'. Perforate @ 562'. Rafforate @ 312'. Pressure 500#, releasurface. Install Dry Hole Marker. as to plugging of the Well Bore. der bond is retained until	OTHER: pertinent details, and ple Completions: Att k to Speedy Gonzales sxs Class "C" cement n packer 400'. Pressu	z, he said to spot 25 sx 0 welloor. Tag plug @ 34 are to 500#, release press	f proposed completion Class "C" cement 12'. Spot 25 sxs sure. Spot 25 sx
OTHER: 13. Describe proposed or compost of starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021'. 9-06-06 Spot 25 sxs Class "C" cement @ 616'. WOC @ 450'. Per 9-27-06 Cut off wellhead 3' below.	bleted operations. (Clearly state all ork). SEE RULE 1103. For Multiple WL to 3532'. Called NMOCD. Tally 80 B/W + 20 sxs mud. Mixed 25 states. ent @ 1418'. Perforate @ 562'. Rafforate @ 312'. Pressure 500#, releasurface. Install Dry Hole Marker. as to plugging of the Well Bore. der bond is retained until	OTHER: pertinent details, and ple Completions: Att k to Speedy Gonzales sxs Class "C" cement n packer 400'. Pressu	z, he said to spot 25 sx 0 welloor. Tag plug @ 34 are to 500#, release press	f proposed completion Class "C" cement 12'. Spot 25 sxs sure. Spot 25 sx
OTHER: 13. Describe proposed or compostarting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021' 9-06-06 Spot 25 sxs Class "C" ceme @ 616'. WOC @ 450'. Per 9-27-06 Cut off wellhead 3' below	pleted operations. (Clearly state all ork). SEE RULE 1103. For Multiple WL to 3532'. Called NMOCD. Tally 180 B/W + 20 sxs mud. Mixed 25 states. ent @ 1418'. Perforate @ 562'. Rafforate @ 312'. Pressure 500#, releasurface. Install Dry Hole Marker. as to plugging of the Well Bore. der bond is retained until coration is completed.	other: pertinent details, and ple Completions: Attack to Speedy Gonzales sxs Class "C" cement on packer 400'. Pressuase. Circulate 45 sx C	give pertinent dates, incach wellbore diagram of z, he said to spot 25 sx 0 woC. Tag plug @ 34 ure to 500#, release pressulass "C" cement to surface in the surface of the	Class "C" cement 12'. Spot 25 sxs sure. Spot 25 sx ace.
OTHER: 13. Describe proposed or compost of starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021'. 9-06-06 Spot 25 sxs Class "C" cement @ 616'. WOC @ 450'. Per 9-27-06 Cut off wellhead 3' below.	pleted operations. (Clearly state all ork). SEE RULE 1103. For Multiple WL to 3532'. Called NMOCD. Tally 80 B/W + 20 sxs mud. Mixed 25 st. ent @ 1418'. Perforate @ 562'. Raforate @ 312'. Pressure 500#, releasurface. Install Dry Hole Marker. as to plugging of the Well Bore. der bond is retained until coration is completed.	oTHER: pertinent details, and ple Completions: Att k to Speedy Gonzales sxs Class "C" cement n packer 400'. Pressu ase. Circulate 45 sx C	give pertinent dates, incach wellbore diagram of z, he said to spot 25 sx 0 woC. Tag plug @ 34 are to 500#, release pressulass "C" cement to surface in the surface of the	Class "C" cement 12'. Spot 25 sxs sure. Spot 25 sx ace.
OTHER: 13. Describe proposed or compof starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021' 9-06-06 Spot 25 sxs Class "C" cement @ 616'. WOC @ 450'. Per 9-27-06 Cut off wellhead 3' below the surface rest. I hereby certify that the information	pleted operations. (Clearly state all ork). SEE RULE 1103. For Multiple WL to 3532'. Called NMOCD. Tally 80 B/W + 20 sxs mud. Mixed 25 st. ent @ 1418'. Perforate @ 562'. Raforate @ 312'. Pressure 500#, releasurface. Install Dry Hole Marker. as to plugging of the Well Bore. der bond is retained until coration is completed.	oTHER: pertinent details, and ple Completions: Att k to Speedy Gonzales sxs Class "C" cement n packer 400'. Pressu ase. Circulate 45 sx C	give pertinent dates, incach wellbore diagram of z, he said to spot 25 sx 0 z. WOC. Tag plug @ 34 are to 500#, release pressulass "C" cement to surface of the surface of t	Class "C" cement 12'. Spot 25 sxs sure. Spot 25 sx ace.
OTHER: 13. Describe proposed or compof starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021' 9-06-06 Spot 25 sxs Class "C" cement @ 616'. WOC @ 450'. Per @ 616'. WOC @ 450'. Per @ 616'. Wold @ 450'. Per @ 9-27-06 Cut off wellhead 3' below the surface rest. I hereby certify that the information grade tank has been/will be constructed or @ 100 for the starting of the surface rest.	pleted operations. (Clearly state all ork). SEE RULE 1103. For Multiple WL to 3532'. Called NMOCD. Tally 1/80 B/W + 20 sxs mud. Mixed 25 states. Lent @ 1418'. Perforate @ 562'. Raforate @ 312'. Pressure 500#, releasurface. Install Dry Hole Marker. Lest to plugging of the Well Bore. der bond is retained until coration is completed. Lead to the bore of the complete to the bore of the closed according to NMOCD guidelines. TITLE	other: pertinent details, and ple Completions: Att k to Speedy Gonzales sxs Class "C" cement n packer 400'. Pressu ase. Circulate 45 sx Co considered to the pressure of my knowledge notes of my knowledge	give pertinent dates, incach wellbore diagram of z, he said to spot 25 sx (2). WOC. Tag plug @ 34 are to 500#, release pressure to surface and belief. Thurner to surface or an (attached) alternative (ER DATE Octo	Elass "C" cement 12'. Spot 25 sxs sure. Spot 25 sx ace. The state of
OTHER: 13. Describe proposed or comp of starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021' 9-06-06 Spot 25 sxs Class "C" cemem @ 616'. WOC @ 450'. Per 9-27-06 Cut off wellhead 3' below the surface rest. Approved a stability unsurface rest. I hereby certify that the information grade tank has been/will be constructed or SIGNATURE DONALD R. Type or print name DONALD R. For State Use Only	pleted operations. (Clearly state all ork). SEE RULE 1103. For Multiple WL to 3532'. Called NMOCD. Tally 1/80 B/W + 20 sxs mud. Mixed 25 state all or 1/80 B	OTHER: pertinent details, and ple Completions: Att k to Speedy Gonzale: sxs Class "C" cement on packer 400'. Pressures. Circulate 45 sx Completions of my knowledge of the page of the pressure of my knowledge of the pressure of the press	give pertinent dates, incach wellbore diagram of ach wellbore diagram of ach wellbore diagram of ach well as a side to spot 25 sx (c). WOC. Tag plug @ 34 are to 500#, release pressure to surface and belief. The first and belief. The first and alternative of a many distribution of a side of a sid	Elass "C" cement 12'. Spot 25 sxs sure. Spot 25 sx ace. If that any pit or below-DCD-approved plan September 18, 2006
OTHER: 13. Describe proposed or compof starting any proposed we or recompletion. 9-05-06 MIRU. Ran gauge ring on @ 3515'. Circulated hole we Class "C" cement @ 3021' 9-06-06 Spot 25 sxs Class "C" cement @ 616'. WOC @ 450'. Per 9-27-06 Cut off wellhead 3' below the surface rest. Approved a stability unsurface rest. I hereby certify that the information grade tank has been/will be constructed or SIGNATURE.	pleted operations. (Clearly state all ork). SEE RULE 1103. For Multiple WL to 3532'. Called NMOCD. Tally 1/80 B/W + 20 sxs mud. Mixed 25 states. Lent @ 1418'. Perforate @ 562'. Raforate @ 312'. Pressure 500#, releasurface. Install Dry Hole Marker. Lest to plugging of the Well Bore. der bond is retained until coration is completed. Lead to the bore of the complete to the bore of the closed according to NMOCD guidelines. TITLE	OTHER: pertinent details, and ple Completions: Att k to Speedy Gonzale: sxs Class "C" cement on packer 400'. Pressures. Circulate 45 sx Completions of my knowledge of the page of the pressure of my knowledge of the pressure of the press	give pertinent dates, incach wellbore diagram of ach wellbore diagram of ach wellbore diagram of ach well as a side to spot 25 sx (c). WOC. Tag plug @ 34 are to 500#, release pressure to surface and belief. The first and belief. The first and alternative of a many distribution of a side of a sid	Elass "C" cement 12'. Spot 25 sxs sure. Spot 25 sx ace. Type that any pit or below-occopy proved plan Spot 25 sx ace. Spot 25 sx ace.