

COPIES RECEIVED	
TRIBUTION	
FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee   
5. State Oil & Gas Lease No.  
**K-1276**

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>Braden-Deem, Inc.</b>	8. Farm or Lease Name <b>State DB</b>
3. Address of Operator <b>200 E. First, Wichita, Kansas 67202</b>	9. Well No. <b>4</b>
4. Location of Well UNIT LETTER <b>L</b> , <b>1980</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>25</b> TOWNSHIP <b>7S</b> RANGE <b>33E</b> NMPM.	10. Field and Pool, or Wildcat <b>Chaveroo (San Andres)</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4338 RDB</b>	12. County

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe ~~XXXXXX~~ or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.
- Spotted 50 sx cement plug over perfs. 4208-4263 11/30/74  
Top of plug @ 4000'.
  - Loaded hole with brine water and pressured up on plug @ 4000' - plug OK 12-2-74.
  - Shot off pipe @ 1074' and worked loose. Loaded hole w/ brine water. Spotted 50 sx. cement plug @ 1074'. Pulled casing to 450' and spotted 50 sx cement plug. Finished pulling casing. Filled hole with brine water. Put 10 sx cement plug at surface and installed dry hole marker. Plugging complete 12-3-74.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Vice-President DATE 12/13/74

APPROVED BY [Signature] TITLE [Signature] DATE FEB 22

CONDITIONS OF APPROVAL, IF ANY: