NO. CF TOFIES RECEIVED			Form C-103
DISTRIBUTION			Supersedes Old C•102 and C-103
SANTAFE	NEW ME)	XICO OIL CONSERVATION COMMISSION	Effective 1-1-65
FILE			
U.S.G.S.			5a. Indicate Type of Lease
LAND OFFICE			State X Fee
OPERATOR	_		5. State Oil & Gas Lease No.
312111111111111111111111111111111111111			B-1520
			vinniñinin k
SUND (00 NOT USE THIS FORM FOR P USE "APPLICA	PRY NOTICES AND ROPOSALS TO DRILL OR TO ATION FOR PERMIT - 11 (FOI	REPORTS ON WELLS DEEPEN OF PLUG BACK TO A DIFFERENT RESERVOIR. RM C-1011 FOR SUCH PROPOSALS.)	
GIL GAS WELL WELL	OTHER- WIL	ω	7. Unit Agreement Name
2. Name of Operator	Out with	in Julas 19701	8. Farm or Lease Name
3. Address of Cherator	Cogeracia	76701	9. Well No.
1) Location of Well	Milland,	Julas 19101	10, Field and Paol, or Wildcat
UNIT LETTER	660 FEET FROM	THE South LINE AND 1920 F	EET FROM Vac (4- AA)
THE LOAST LINE, SEC	TION 12 TO	OWNSHIP 174 RANGE 34-E	_ NMPM.
	15. Elevat	ion (Show whether DF, RT, GR, etc.)	12. Çounty
		4024 CR	Lea
Check	Appropriate Box	To Indicate Nature of Notice, Report	or Other Data
	INTENTION TO:		QUENT REPORT OF:
PERFORM REMEDIAL WORK	PLUG	AND ABANDON REMEDIAL WORK	ALTERING CASING
=	7206	'	H H
TEMPORARILY ABANDON		COMMENCE DRILLING OPNS. GE PLANS CASING TEST AND CEMENT JOB	PLUG AND ABANDONMENT
PULL OR ALTER CASING	CHANG	<u> </u>	·
		OTHER	
OTHER			
17. Describe Procosed or Completed	Operations (Clearly stat	e all pertinent details, and give pertinent dates.	including estimated date of starting any proposed
work) SEE RULE 1103.		, , , , , , , , , , , , , , , , , , , ,	, , , , ,
Λ	<i>(</i> :	- 1 attalling	commendation
Plus	abandon	as per attached re	
/ lug			
\mathcal{O}			
18. I hereby certify that the informati	ion above is true and cor	mplete to the best of my knowledge and belief.	··· ·
01 +	1,	\mathcal{L}	4
Christine O.	. Lucker	Mr. Frankien Cler	L DATE 1-11-73
STORES			
	ig. Signed 😸		JAN 15 1979
_	e D. Ramey isr I Suse		DATE
APPROVED BY	IST I SHE	て(でしる)	. DATE

CONDITIONS OF APPROVAL, IF ANY:

MIDLAND E & P DIVISION

WELL WORK RECOMMENDATIONS Proposals for Well Reconditioning and Subsurface Maintenance Workovers, Expense DD's, PB's, and Conversions

Lease:	Bridges State		Well No.	WIW #83
Field:	Vacuum-San Andres Flood			
County:	Lea	State:	New Mexico	
		_		

RECOMMENDED PROCEDURE:

- 1. M.I.P.U. Pull cement lined tubing and pkr.
- 2. Run 2" tubing w/ cement retainer. Set retainer at 4600' and squeeze the open hole.
- 3. Circulate hole to mud laden fluid.
- 4. Determine free point of 5-1/2" casing. Cut and pull.
- 5. Spot 25 sx cement plug 50' above and 50' below cut.
- 6. Spot 30 sx cement plug from 1670' to 1770' if cut is below same. Spot 20 sx cement plug from 1670' to 1770' if cut is above 1500'.
- 7. Spot 10 sx of cement plug at surface.
- 8. Cut off well head and install marker.

DIAGI MMATIC WELL SKETCHI
BRIDGES STATE WELL Nº 83 W.I.W
VACUUM- SAN ANDRES FLOOD
LEA COUNTY- NEW MEXICO

