

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE  
(Other instruction  
verse side)

Budget Bureau No. 1004-0135  
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Robert N. Enfield

3. ADDRESS OF OPERATOR

P. O. Box 2431, Santa Fe, NM 87504-2431

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)

At surface 660' FNL & 1980' FEL Sec. 29

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3799'

5. LEASE DESIGNATION AND SERIAL NO  
LC 069276

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Hudson "29" Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Corbin, S., ~~Wagon~~ *Bone Spring*

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

29, T-18-S, R-33-E

12. COUNTY OR PARISH

Lea

13. STATE

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other) X TA @ 4200'

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any  
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-  
nent to this work.)

1. Move-in and rig-up plugging equipment.
2. Run and set a CIBP @ 8600' KB; dump 35 feet of cement on top of plug.
3. Pick up on 5.5" casing; determine free point (est. @ 8350' KB).
4. Cut and pull casing.
5. Spot plugs with mud as required as follows:

Bottom	Top	Sacks	Comments
8450'	8300'	50	75' into and out of stub, WOC, tag plug
5575'	5475'	40	Must tag plug if hole takes fluid
5100'	4800'	100	WOC, tag plug
4350'	4200'	50	WOC, tag plug.
6. Install companion flange with a nipple and valve at surface pending final plugging or completion attempt in shallow zones.

PRESSURE TEST CASING.

18. I hereby certify that the foregoing is true and correct

SIGNED

*Robert N. Enfield*  
Robert N. Enfield

TITLE Operator

DATE 2/19/91

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE 3-7-91

NOTIFY BLM AT (505)393-3612 PRIOR TO COMMENCING PLUGGING OPERATION.

\*See Instructions on Reverse Side