

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

3a. Indicate Type of Lease
State Fee
5. State Oil & Gas Lease No.
B-1576-3

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name East Vacuum Gb/SA Unit
2. Name of Operator Phillips Petroleum Company	8. Farm or Lease Name East Vacuum Gb/SA Unit, Tract 3229
3. Address of Operator Room 401, 4001 Penbrook, Odessa, Texas 79762	9. Well No. 001
4. Location of Well UNIT LETTER <u>L</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>32</u> TOWNSHIP <u>17-S</u> RANGE <u>35-E</u> NMPM.	10. Field and Pool, or Wildcat Vacuum Gb/SA
15. Elevation (Show whether DF, RT, GR, etc.) 4005' RKB, 3984' GL	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Deepen 129' w/in existing producing formation.</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1105.

Deepen well as follows:

1. MI DDU and BOP. Pull rods and tubing.
2. GIH w/6-1/4" bit and drill out to 4654'.
3. Circulate hole clean; spot fresh water in open hole.
4. Run GR-CNL log from TD to 3800'.
5. Acidize and test.
6. Rerun pumping equipment and return to production from OH 4100 to approximately 4654.

BOP equipment series 900, 3000# WP, double w/one set pipe rams and one set blind rams manually operated.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W. J. Mueller TITLE Senior Engineering Specialist DATE August 20, 1980

APPROVED BY Jerry Seaman TITLE _____ DATE AUG 22 1980