

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator AZTEC OIL & GAS COMPANY		5. State Oil & Gas Lease No. E-5221
3. Address of Operator P. O. Box 837, Hobbs, New Mexico 88240		7. Unit Agreement Name
4. Location of Well J 1980 South 1980 East LINE, SECTION 31 TOWNSHIP 17-S RANGE 36-E N.M.P.M.		8. Farm or Lease Name State VE
10. Elevation (Show whether DF, RT, GR, etc.) 3881 KB		9. Well No. 2
		10. Field and Pool, or Wildcat Vacuum (G-SA)
		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to Plug & Abandon this well in the following manner:

1. Set 100' (25 sxs) cement plug over perforations at 5000' - 5100'. (Grayburg)
2. Set 100' (25 sxs) cement plug at 4300' - 4400'. (Queen)
3. Set 100' (25 sxs) cement plug at 3350' - 3450'. (Yates)
4. Load hole with 10# Salt Base Mud.
5. Set 100' (25 sxs) cement plug at 1950' - 2050'. (Top Salt)
6. Set 100' (25 sxs) cement plug at 275' - 375'. (Base Surface Casing)
7. Set 10 sxs cement plug at surface with Marker, level and clear location.
8. If casing is pulled, set 100' (25 sxs) cement plug in and out of Stub.

24 hr no flow

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Orlando J. [Signature] TITLE District Superintendent DATE March 8, 1973

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: