

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
**E-1587**

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name <b>West Pearl Queen Unit - 29</b>
2. Name of Operator <b>Gulf Oil Corporation</b>	8. Farm or Lease Name
3. Address of Operator <b>Box 670, Hobbs, New Mexico</b>	9. Well No. <b>29-160</b>
4. Location of Well UNIT LETTER <b>P</b> <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM THE <b>East</b> LINE, SECTION <b>29</b> TOWNSHIP <b>19-S</b> RANGE <b>35-E</b> NMPM.	10. Field and Pool, or Wildcat <b>Pearl Queen</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3754.0L</b>	12. County <b>Lee</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <b>Clean out &amp; Convert to water injection</b> <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plans have been made to clean out to **FD** at **4962'**. Install dual strings of **2-1/16"** plastic coated tubing and 1 Guberson Type "A" Drillable packer set at approximately **4786'** and 1 Guberson "HLO-2" dual packer set at approximately **4721'**. Land both strings in compression with **9,000 to 10,000%**. Start injecting water.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

ORIGINAL SIGNED BY  
SIGNED C. D. BORLAND TITLE Area Production Manager DATE April 8, 1965

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: