

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
 Oil Well Gas Well Other *Inject*

2. Name of Operator
 Lynx Petroleum

3. Address and Telephone No.
 P.O. Box 1708, Hobbs, NM 88241

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
 1980' FNL & 660' FWL
 Sec. 10, T-20-S, R-36-E

5. Lease Designation and Serial No.

6. If Indian, Allottee or Tribe Name
Fee

7. If Unit or CA, Agreement Designation
 8910088220

8. Well Name and No.
 Reed Sanderson Unit #22

9. API Well No.
 30-025-04201

10. Field and Pool, or Exploratory Area
 Eumont Yates-SR-Qn

11. County or Parish, State
 Lea, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input type="checkbox"/> Notice of Intent <input type="checkbox"/> Subsequent Report <input checked="" type="checkbox"/> Final Abandonment Notice	<input checked="" type="checkbox"/> Abandonment <input type="checkbox"/> Recompletion <input type="checkbox"/> Plugging Back <input type="checkbox"/> Casing Repair <input type="checkbox"/> Altering Casing <input type="checkbox"/> Other _____
	<input type="checkbox"/> Change of Plans <input type="checkbox"/> New Construction <input type="checkbox"/> Non-Routine Fracturing <input type="checkbox"/> Water Shut-Off <input type="checkbox"/> Conversion to Injection <input type="checkbox"/> Dispose Water <small>(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)</small>

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

5-04-01 Set 5-1/2" CIBP @3750', spot 25 sx cmt. on top CIBP, tag @ 3490'.
 5-04-01 Mix mud & circ. hole.
 5-04-01 Spot 25 sx cmt. @ 2900' to 2650'.
 5-04-01 25 sx cmt. @ 1600' to 1350'.
 5-05-01 Cut 5-1/2" csg. @ 360'.
 5-05-01 Pump 110 sx cmt. from 410' to Surface.
 5-05-01 Install dry hole marker.

14. I hereby certify that the foregoing is true and correct

Signed [Signature] Title Agent Date 05/11/01
(This space for Federal or State office use)

Approved by _____ Title _____ Date _____
 Conditions of approval, if any:

JRC GWW