

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO CEMENT OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - M (FORM C-101) FOR SUCH PROPOSALS.

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. Unit Agreement Name
2. Name of Operator	8. Farm or Lease Name
TEXACO Inc.	J.R. Phillips
3. Address of Operator	9. Well No.
P.O. Box 728 Hobbs, New Mexico 88240	6
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER <u>E</u> <u>660</u> FEET FROM THE <u>West</u> LINE AND <u>1897</u> FEET FROM THE <u>North</u> LINE, SECTION <u>6</u> TOWNSHIP <u>20-S</u> RANGE <u>37-E</u> NMPM.	Monument Abo
11. Elevation (Show whether DF, RT, GR, etc.)	12. County
3576' (DF)	Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	☐
TEMPORARILY ABANDON	☐
PULL OR ALTER CASING	☐
OTHER	☐

PLUG AND ABANDON	☐
CHANGE PLANS	☐
OTHER	☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK	☐
COMMENCE DRILLING OPS.	☐
CASING TEST AND CEMENT JOB	☐
OTHER	☒
Squeeze Paddock-Reperforate Abandoned Abo Zone	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rigged Up. Install BOP. Pull production equipment.
2. Clean out to 7760'.
3. Perforate 5-1/2" OD csg w/1-JSPF @ 7108', 26', 60', 68', 80', 7208', 74', 7300', 14', & 7326'.
4. Set Packer @ 7235'. Acidize 5-1/2" csg perforations 7274'-7326' w/1000 gal 15% NE Acid & 8-Ball sealers. Flush w/45 Bbls treated water.
5. Reset packer @ 7052'. Acidize 5-1/2" OD csg perfs 7108'-7208' w/1000 gal 15% NE Acid & 10 Ball Sealers. Flush w/46 bbls treated water. Swab.
6. Set RBP @ 6950' & Dump 4 sx sand on plug. Set cement retainer @ 5143'.
7. Squeeze 5-1/2" OD Paddock perforations 5205'-5225' w/150 sx Class H cement.
8. Test 5-1/2" csg w/500# for 30 minutes 9:00-9:30 AM Tested O.K. Pull RBP.
9. Install production equipment. Test and place on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Asst. Dist. Supt. DATE 4-18-77

APPROVED BY [Signature] TITLE Geologist DATE APR 20 1977

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

APR 21 1972

OIL COMPANY COMM.
BOSTON, MASS.