

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
A-166

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name	
2. Name of Operator	8. Farm or Lease Name	
Atlantic Richfield Company	O. O. Bradley	
3. Address of Operator	9. Well No.	
P. O. Box 1710, Hobbs, New Mexico 88240	2	
4. Location of Well	10. Field and Pool, or Wildcat	
UNIT LETTER <u>A</u> , <u>330</u> FEET FROM THE <u>North</u> LINE AND <u>480</u> FEET FROM	Bowers Seven Rivers	
THE <u>East</u> LINE, SECTION <u>6</u> TOWNSHIP <u>19S</u> RANGE <u>38E</u> NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)	12. County	
	Lea	

<p align="center">16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data</p>			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input checked="" type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to change plug & abandon procedures as approved by your office on C-103 dated 6/4/75 as follows: (will leave 5½" OD casing in hole)

1. Rig up, install BOP & POH w/completion assy.
2. Run & set CIBP @ 3126'. Spot 35' ~~sk~~ cmt plug on top.
3. Fill hole w/heavy gelled mud between all plugs.
4. Spot 100' cmt plug inside 5½" OD csg across top of salt @ 1600'.
5. Spot 10 sk cmt plug @ surface, install regulation dry hole marker, clean & level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>[Signature]</u>	TITLE <u>Dist. Drlg. Supv.</u>	DATE <u>9/10/75</u>
<p>Orig. Signed by John R. Ryan Geologist</p>		
APPROVED BY _____	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		