

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-77

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

34. Indicate Type of Lease	State ☒ Fee ☐
35. State Oil & Gas Lease No.	A-1646

SUNDARY NOTICES AND REPORTS ON WELLS
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG SALS TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PERMIT - 1704M C-1031 FOR SUCH PROPOSALS.

1. OIL WELL ☐ GAS WELL ☐ OTHER: Injection	7. Unit Agreement Name
2. Name of Operator Amoco Production Company	8. Farm or Lease Name South Hobbs(GSA)Unit
3. Address of Operator P. O. Box 68, Hobbs, New Mexico 88240	9. Unit No. 113
4. Location of well UNIT LETTER G 1650 FEET FROM THE North LINE AND 1650 FEET FROM THE East LINE, SECTION 6 TOWNSHIP 19-S RANGE 38-E N.M.P.M.	10. Field and Pool, or annual Hobbs GSA
11. Elevation (Show whether DF, RT, CR, etc.) 3625' GL	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☐
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to cement squeeze as follows:

Rig up service unit, release injection packer and pull. Plug back from 4229' to 4180' with 20/40 mesh sand. Tag top of sand and cap with 5' of Calseal. Run in hole with packer and set at 4106'. Check for communication. Pull workstring and packer. Run in hole with cement retainer and wireline, set at 4106'. Pull wireline. Run in hole with workstring and sting into cement retainer. Pump the following cement program:

- Pump 50 sacks class C neat cement.
- Pump 100 sacks class C cement with 4#/sack Tuf-plug.
- Pump 100 sacks class C cement with 1/2#/sack Cellophane flakes.
- Pump 200 sacks class C neat cement.
- Sting out of cement retainer, reverse out excess cement and pull out of hole with workstring.

Drill out cement retainer and cement to 4170'. Run in hole with packer and set at 4106'. Pressure test to 800 psi. Release packer and pull. Drill out remaining cement, Calseal and sand to 4243'. Pull workstring, drill collars and bit. Run in hole with injection packer and set at 3890'. Return to injection.

0+4-NMOCD, H 1-HOU R.E.Ogden Rm. 21.150 1-F.J. Nash, HOU Rm. 4.206 1-SUSP 1-PJS 1-Petro Lew

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Patty Sena TITLE Assist. Admin. Analyst DATE 9-1-83

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE SEP 6 1983

CONDITIONS OF APPROVAL, IF ANY: