

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator SHELL OIL COMPANY		8. Farm or Lease Name STATE "D"
3. Address of Operator P. O. BOX 991, HOUSTON, TX. 77001		9. Well No. 1
4. Location of Well UNIT LETTER J 1980' FEET FROM THE SOUTH LINE AND 1980' FEET FROM THE EAST LINE, SECTION 19 TOWNSHIP 19S RANGE 37E N.M.P.M.		10. Field and Pool, or Wildcat MONUMENT
11. Elevation (Show whether DF, RT, GR, etc.) 3698' DF		12. County LEA

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPERATIONS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER Plug back total depth to shut off water <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. RU pulling unit. Pull pump & rods. Install BOP.
2. Circulate hole clean w/2% KCl water. Pull tbgs. assembly & tally out.
3. Run GR/CNL.
4. Dump bail approximate 11 sx. Cal-Seal from TD to 4' below PBTD.
5. Dump bail 100# Hydromite w/5 oz. Catalyst A from top of Cal-Seal.
6. Re-run production tbgs assembly & hang close to PBTD.
7. Remove BOP. Run pump & rods. Put well back on production.

14. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>A. J. Fore</u>	A. J. Fore	TITLE <u>Supervisor, Reg./Perm.</u>	DATE <u>4/13/81</u>
APPROVED BY <u>[Signature]</u>		TITLE <u></u>	DATE <u></u>
CONDITIONS OF APPROVAL, IF ANY:			