

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☒ Fee ☐
5. State Oil & Gas Lease No.
LG-3605

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
Name of Operator Lynx Petroleum Consultants, Inc.	8. Farm or Lease Name Humble A0 State
Address of Operator P.O. Box 1666 - Hobbs, NM 88240	9. Well No. 2
Location of Well UNIT LETTER <u>N</u> <u>660'</u> FEET FROM THE <u>South</u> LINE AND <u>1920'</u> FEET FROM THE <u>West</u> LINE, SECTION <u>11</u> TOWNSHIP <u>19S</u> RANGE <u>36E</u> NMPM.	10. Field and Pool, or Wildcat Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 3748' GR	12. County Lea

6. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Moved rig on location, rigged unit up, pulled packer and tubing.
- Set 5 1/2" cast iron Bridge Plug @ 6255', dumped 4 sacks cement on top
- Set 25 sacks cement plug at 5000'-4900'.
- Set 35 sacks cement plug at 4200'-3900'.
- Set 40 sacks cement plug at 3477'-3150'.
- Set 25 sacks cement plug at 1700'-1500'.
- Set 10 sacks cement plug at surface.
- Set dry hole marker, clean location, move off.
- Location ready for inspection.

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mike S. Shultz TITLE Vice President DATE 10/5/83

APPROVED BY David Catanzos TITLE OIL & GAS INSPECTOR DATE JAN 4 1984

CONDITIONS OF APPROVAL, IF ANY:

883 1100

OCT 7 1983

O.C.D.
HOBBS OFFICE