Energy, Minerals and Natural Resources Beautifus 25, 1 30-025-31112 5. Indicate Type of Lease STATE
DISTRICT DIS
SILT South First, Artesia, AM 87210 District III DOO RIG Brances Rd., Aziec, NM 87410 District IV 2040 South Pacheco Santa Fe, NM 87505 Santa Fe, NM 87505 SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM POR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE 'APPLICATION FOR PERMIT' (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well: Oil Well Gas Well Other 2. Name of Operator Cherycan U.S.A. Tac. 3. Address of Operator P.O. Box 1150 Midland. TX 79702 4. Well Location Unit Letter X: 2080 feet from the SOUTH line and 1880 feet from the Existice Manuement's Gray Experiment Name: 10. Elevation (Show whether DR, RKB, RT, GR, etc.) 11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ABANDONMENT TEMPORARILY ABANDON CHANGE PLANS COMPLETION OTHER: TA'TD 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. PCH W/TBG. RAN CSG SCRAPER TO 3700'. SET CIEP @ 3680'. CIRC PKR FIJIID. RAN MTT. TA'D 9/6/01
STATE FEE
District. Y 2040 South Pacheco, Santa Pe, NM 87305 SUNDRY NOTICES AND REPORTS ON WELLS (10 NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DEEPEN
IDO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well:
1. Type of Well: Oil Well Gas Well Gas Well Other 2. Name of Operator Chevron U.S.A. Inc. 3. Address of Operator P.O. Box 1150 Milland, TX 79702 4. Well Location Unit Letter K : 2080 feet from the SOUTH line and 1880 feet from the WEST li Section 13 Township 20s Range 36s NMPM County LEA 10. Elevation (Show whether DR, RKB, RT, GR, etc.) 11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ABANDON ABANDON ABANDON ABANDON ABANDON ABANDON ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDON CEMENT JOB DITHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. POR W/TBG. RAN CSG SCRAPER TO 3700'. SET CIEP @ 3680'. CIRC FKR FLUID. RAN MIT. TA'D 9/6/01
Chevron U.S.A. Inc. 3. Address of Operator P.O. Box 1150 Midland, TX 79702 4. Well Location Unit Letter K : 2080 feet from the SOUTH line and 1880 feet from the WEST line Section 13 Township 20S Range 36S NMPM County LEA 10. Elevation (Show whether DR, RKB, RT, GR, etc.) 11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT COMPLETION CEMENT JOB OTHER: TAYD 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. POH W/TBG. RAN CSG SCRAPER TO 3700'. SET CIBP @ 3680'. CIRC FER FLUID. RAN MIT. TAYD 9/6/01
3. Address of Operator P.O. Box 1150 Midland, TX 79702 4. Well Location Unit Letter K : 2080 feet from the SOUTH line and 1880 feet from the WEST line and 10. Elevation (Show whether DR, RKB, RT, GR, etc.) 11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDON ABANDON ABANDONMENT COMPLETION CEMENT JOB OTHER: OTHER: OTHER TAYD 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. POH W/TBG. RAN CSG SCRAFER TO 3700'. SET CIBP @ 3680'. CIRC FKR FLUID. RAN MIT. TA'D 9/6/01
P.O. BOX 1150 Midland, TX 79702 4. Well Location Unit Letter K : 2080 feet from the SOUTH line and 1880 feet from the WEST line and 10. Elevation (Show whether DR, RKB, RT, GR, etc.) 10. Elevation (Show whether DR, RKB, RT, GR, etc.) 11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: REMEDIAL WORK PLUG AND ABANDON COMMENCE DRILLING OPNS. ABANDONMENT COMPLETION CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT COMPLETION CHANGE TOTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.
Unit Letter K : 2080 feet from the SOUTH line and 1880 feet from the WEST line and Section 13 Township 208 Range 368 NMPM County LEA 10. Elevation (Show whether DR, RKB, RT, GR, etc.) 11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE DRILLING OPNS. ALTERING CASING EMPORABILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT CASING TEST AND COMPLETION CHANGE PLANS COMPLETION CHANGE PLANS COMPLETION CHANGE PLANS COMPLETION CHANGE PLANS COMPLETION CHANGE PLOY ABANDONMENT CASING TEST AND COMPLETION CHANGE PLOY STATE TAY'D 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. POH W/TEG. RAN CSG SCRAFER TO 3700'. SET CIBP @ 3680'. CIRC FKR FLUID. RAN MIT. TAY'D 9/6/01
10. Elevation (Show whether DR, RKB, RT, GR, etc.) 11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMPORABILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT CASING TEST AND CEMENT JOB DITHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. POH W/TBG. RAN CSG SCRAPER TO 3700'. SET CIBP @ 3680'. CIRC FKR FIJIID. RAN MIT. TA'D 9/6/01
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB OTHER: TA'D 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. POH W/TEG. RAN CSG SCRAPER TO 3700'. SET CIEP @ 3680'. CIRC FKR FIJID. RAN MIT. TA'D 9/6/01
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT COMPLETION COMPLETION CEMENT JOB OTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. POH W/TBG. RAN CSG SCRAPER TO 3700'. SET CIBP @ 3680'. CIRC FKR FIJID. RAN MIT. TA'D 9/6/01
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT CASING COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT CASING TEST AND CEMENT JOB OTHER: TA'D 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. POH W/TBG. RAN CSG SCRAPER TO 3700'. SET CIBP @ 3680'. CIRC FKR FLUID. RAN MIT. TA'D 9/6/01
COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT OTHER: OTHER: TA'D 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. POH W/TBG. RAN CSG SCRAPER TO 3700'. SET CIBP @ 3680'. CIRC FER FLUID. RAN MIT. TA'D 9/6/01
ABANDONMENT CASING TEST AND CEMENT JOB OTHER: OTHER: TA'D 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. POH W/TEG. RAN CSG SCRAPER TO 3700'. SET CIBP @ 3680'. CIRC FKR FLUID. RAN MIT. TA'D 9/6/01
PULL OR ALTER CASING MULTIPLE COMPLETION CEMENT JOB OTHER: TA'D 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. POH W/TEG. RAN CSG SCRAPER TO 3700'. SET CIEP @ 3680'. CIRC FER FLUID. RAN MIT. TA'D 9/6/01
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. POH W/TEG. RAN CSG SCRAPER TO 3700'. SET CIEP @ 3680'. CIRC FKR FLUID. RAN MIT. TA'D 9/6/01
of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. POH W/TBG. RAN CSG SCRAPER TO 3700'. SET CIBP @ 3680'. CIRC FKR FLUID. RAN MIT. TA'D 9/6/01
(Tarcoraty of or 1007
Abandonment Salzi 07
hereby certify that the information above is true and complete to the best of my knowledge and belief.
IGNATURE O. K. RUPLLY TITLE REGULATORY O.A. DATE 9/25/01
THE INCH DATE TIES
ype or print name J. K. RIPLEY Telephone No. (915) 687-714
ype or print name J. K. RIPLEY This space for State use) MAR 2 1 2002
ype or print name J. K. RIPLEY Telephone No. (915) 687-714 This space for State use)



