

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

<p>SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REPER OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - ** (FORM C-101) FOR SUCH PROPOSALS.)</p>		<p>5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/></p>
<p>1. OIL <input type="checkbox"/> GAS <input checked="" type="checkbox"/> OTHER <input type="checkbox"/></p>		<p>5. State Oil & Gas Lease No. E-1923</p>
<p>2. Name of Operator Brunson & McKnight</p>		<p>7. Unit Agreement Name</p>
<p>3. Address of Operator P. O. Box 297, Hobbs, New Mexico 88240</p>		<p>8. Farm or Lease Name Berry</p>
<p>4. Location of Well UNIT LETTER N 554 FEET FROM THE South 1821 FEET FROM THE West 7 LINE, SECTION 21S RANGE 34E NMPM.</p>		<p>9. Well No. #1</p>
<p>15. Elevation (Show whether DF, RT, GR, etc.) 3758 GR</p>		<p>10. Field and Pool, or Wildcat Berry - Morrow</p>
<p>12. County Lea</p>		

<p>16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data</p>	
<p>NOTICE OF INTENTION TO:</p> <p>PERFORM REMEDIAL WORK <input type="checkbox"/></p> <p>TEMPORARILY ABANDON <input type="checkbox"/></p> <p>PULL OR ALTER CASING <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p>	<p>SUBSEQUENT REPORT OF:</p> <p>PLUG AND ABANDON <input checked="" type="checkbox"/></p> <p>CHANGE PLANS <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Kill Well
- Remove tree, install BOP and unseat packer.
- Pull and lay down 2 3/8 tubing.
- Set BP on wireline @ 13,000'±, cap with three sacks of cement, 35'.
- Free point, shoot off and pull one joint of 4 1/2 casing.
- Set 30 sacks plug across 4 1/2" stub in 7" casing.
- Pull 4 1/2" casing to 5590' and set a 40 sack plug across 7" stub @ 5578'± in 9 5/8 casing.
- Pull 4 1/2" casing to 1950', set 40 sack plug 100' across top of salt 1950'-1850' in 9 5/8 casing.
- Pull remainder of 4 1/2" casing, set a 10 sack plug at surface.
- Install dry hole marker.
- Clean location.

Estimated starting date December 22, 1975.

* Add - 15 SX PER PLUG - TO ALLOW FOR CONTAMINATION GOING
THRU 4 1/2"

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jane T. Jernica TITLE Agent DATE 12-5-75

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: