

FORM 9-331

(Continued)

8. Set pkr. @ 2900'. Acidize perfs. 3007' - 3061' w/1200 Gals. Mud Acid & 14 Ball Sealers.
9. Frac w/15,000 Gals. x-linked gelled water & 15,000 Gals. CO<sub>2</sub> containing 28,000# 20/40 Sand & 28,000# 10/20 Sand.
10. Pull pkr. Clean Out & pull RBP.
11. Run production equipment. Test & place on production.