Form 3160-5 (June 1990)

UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

FEB 06 2013

FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993

5. Lease Designation and Serial No. 073240 6. If Indian, Allottee or Tribe Name

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to do Use "APPLICATION FO		
SUBMIT IN TRIPLICATE		7. If Unit or CA, Agreement Designation
I. Type of Well Oil Well Well Other	/	8. Well Name and No.
2. Name of Operator Robinson DIL Inc.		Tonto # 12 9. API Well No.
3. Address and Telephone No. Box 1829 Fusice NM 8 4. Location of Well (Footage, Sec., T., R., M., or Survey D	(8231 - 432 - 238 - 5470)	30 - 02 5 - 3159 16 10. Field and Pool, or Exploratory Area
T^{n}		11. County or Parish, State
SEC. 30-T. 18-195-	R. 33E 460 S 1980 W	LEA, NEW MEXICO
A Mark and a second	s) TO INDICATE NATURE OF NOTICE, REPOR	RI, OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF ACTION	Change of Plans
Notice of Intent Subsequent Report	Abandonment Recompletion Plugging Back	New Construction Non-Routine Fracturing
Final Abandonment Notice	Casing Repair Altering Casing	Water Shut-Off Conversion to Injection
	Other	Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)
SEE BACK	ECLAMATION UE 4-4-12 BURZAU OF CARLSB.	as to plugging of the well bore. Inder bond is retained until storation is completed. B 3 2013 LAND MANAGEMENT AD FIELD OFFICE
Signed Signed	Title VICE - PRESIDENT	Date 12-10-2012
Approved by	Title	Date
Approved by Approval, if any:	•	Date

Title 18 U.S.C. Section 1601, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

Tonto #12 Plugging Report

11-30-2011 – Move pulling unit and plugging equipment to location, rig up pulling unit and TIH to tag CIBP @ 3060', circulate plugging mud, spot 25 sacks class C cement @ 3060', TOH with tubing.

12-01-2011 - TIH with tubing to tag plug at 2730, okayed by BLM, TOH to 2450' to spot 106 sacks class C cement, TOH and WOC, TIH to tag cement @ 1299', TOH with tubing. SDFN.

12-07-2011 - Rig down BOP, NU wellhead, weld on pull nipple, TIH and cut casing off @ 1260' TOH laying down casing with lay down machine, ND wellhead, NU BOP. SDFN.

12-08-2011 – TIH with tubing to spot 45 sacks class C cement @ 1260', TOH with tubing and WOC, TIH with tubing to tag cement @ 1087', TOH to 535' to spot 40 sacks class C cement, TOH with tubing. SDFN.

12-09-2011 – TIH with tubing to tag cement @ 371', TOH with tubing to 62' to circulate 17 sacks class C cement to surface, ND BOP cut off and install marker. RDPU, move all Equipment off location.