State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 5-27-2004

FILE IN TRIPLICATE OIL CONSERVATION DIVISION			
DISTRICT I 1625 N. French Dr., Hobbs, NM 88240		St. Francis Dr. NM 87505	WELL API NO. 30-025-36046
DISTRICT II	,		5. Indicate Type of Lease
1301 W. Grand Ave, Artesia, NM 88210		HOE3S OCD	STATE FEE X
DISTRICT III		-	6. State Oil & Gas Lease No.
1000 Rio Brazos Rd, Aztec, NM 87410		<u> </u>	
SUNDRY NOTICES AND REPORTS ON WELLS		7. Lease Name or Unit Agreement Name	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A		Hobbs Deep A	
	PLICATION FOR PERMIT" (Form C-I	01) for such proposals.)	
1. Type of Well: Oil Well X	Gas Well Other		8. Well No. 1
2. Name of Operator			9. OGRID No. 157984
Occidental Permian Ltd.			10 P. L William
3. Address of Operator	70222		10. Pool name or Wildcat Wildcatt Tubby Dripkords Abo
HCR 1 Box 90 Denver City, TX	19323		Wildcat; Tubb; Drinkard; Abo
Unit Letter P : 990 Feet From The South 660 Feet From The East Line			
Section 13 Township 18-S Range 37-E NMPM Lea County			
	11. Elevation (Show whether DF, RK 3671'	KB, RT GR, etc.)	
Pit or Below-grade Tank Application or Closure			
Pit or Below-grade Tank Application or Closure Distance from pearest fresh water well Distance from pearest surface water			
Pit Type Depth of Ground Water Distance from nearest fresh water well Distance from nearest surface water			
Pit Liner Thickness mil Below-Grade Tank: Volume bbls; Construction Material			
12. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:			
PERFORM REMEDIAL WORK	PLUG AND ABANDON	REMEDIAL WORK	ALTERING CASING
PERFORM REMEDIAL WORK TEMPORARILY ABANDON J	PLUG AND ABANDON CHANGE PLANS	REMEDIAL WORK COMMENCE DRILLING OPI	
		COMMENCE DRILLING OPI	NS. PLUG & ABANDONMENT
TEMPORARILY ABANDON [] PULL OR ALTER CASING	CHANGE PLANS	COMMENCE DRILLING OPI CASING TEST AND CEMEN	NS. PLUG & ABANDONMENT
TEMPORARILY ABANDON [] PULL OR ALTER CASING [] OTHER:	CHANGE PLANS Multiple Completion	COMMENCE DRILLING OPI CASING TEST AND CEMEN OTHER:	NS. PLUG & ABANDONMENT TJOB TX PLYG & ABANDONMENT X PLYG & ABANDONMENT X
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent de	COMMENCE DRILLING OPI CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates	NS. PLUG & ABANDONMENT IT JOB E/TA status request It including estimated date of starting any
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F.	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent de	COMMENCE DRILLING OPI CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates	NS. PLUG & ABANDONMENT IT JOB E/TA status request It including estimated date of starting any
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F 1. RUPU & RU.	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent de	COMMENCE DRILLING OPICASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, rellbore diagram of proposed controls.	PLUG & ABANDONMENT IT JOB E/TA status request x including estimated date of starting any completion or recompletion.
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F. 1. RUPU & RU. 2. NU BOP/ND wellhead.	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent de	COMMENCE DRILLING OPICASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, rellbore diagram of proposed controls.	PLUG & ABANDONMENT IT JOB E/TA status request x including estimated date of starting any completion or recompletion.
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F. 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach was appeared to the completion of the completion	COMMENCE DRILLING OPICASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, rellbore diagram of proposed controls.	PLUG & ABANDONMENT IT JOB E/TA status request x including estimated date of starting any completion or recompletion.
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F. 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum 5. RIH w/CIBP set @3185'. Test case.	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach was appeared to the completion of the completion	COMMENCE DRILLING OPICASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, rellbore diagram of proposed controls.	NS. PLUG & ABANDONMENT IT JOB E/TA status request It including estimated date of starting any
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F. 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum 5. RIH w/CIBP set @3185'. Test case. 6. POOH and lay down tubing.	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach with the completion of the comp	COMMENCE DRILLING OPI CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, rellbore diagram of proposed of the company	PLUG & ABANDONMENT IT JOB E/TA status request It including estimated date of starting any completion or recompletion. If JOB Expires 4-5-2018
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F. 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum 5. RIH w/CIBP set @3185'. Test cas 6. POOH and lay down tubing. 7. Dump bail 35' (7 sacks) of cement	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach with the completion of the comp	COMMENCE DRILLING OPI CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, rellbore diagram of proposed of the company	PLUG & ABANDONMENT IT JOB E/TA status request It including estimated date of starting any completion or recompletion. If JOB Expires 4-5-2018
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F. 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum 5. RIH w/CIBP set @3185'. Test cas 6. POOH and lay down tubing. 7. Dump bail 35' (7 sacks) of cement 8. ND BOP/NU wellhead.	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach with the completion of CIBP. RU wire line and the completion of CIBP.	COMMENCE DRILLING OPI CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, rellbore diagram of proposed of the company	PLUG & ABANDONMENT IT JOB E/TA status request It including estimated date of starting any completion or recompletion. If JOB Expires 4-5-2018
PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F. 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum 5. RIH w/CIBP set @3185'. Test cas 6. POOH and lay down tubing. 7. Dump bail 35' (7 sacks) of cement 8. ND BOP/NU wellhead. 9. Test casing to 550 PSI for 30 minut 10. RDPU & RU. Clean location.	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach with the completion of CIBP. RU wire line and the completion of CIBP.	COMMENCE DRILLING OPI CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, rellbore diagram of proposed of the company	PLUG & ABANDONMENT IT JOB E/TA status request It including estimated date of starting any completion or recompletion. If JOB Expires 4-5-2018
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F. 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum 5. RIH w/CIBP set @3185'. Test cas 6. POOH and lay down tubing. 7. Dump bail 35' (7 sacks) of cement 8. ND BOP/NU wellhead. 9. Test casing to 550 PSI for 30 minutes.	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach with the Attach wit	COMMENCE DRILLING OPI CASING TEST AND CEMEN OTHER: TA well bore retails, and give pertinent dates rellbore diagram of proposed of This Approval Abandonment and tag top of cement @3113*	PLUG & ABANDONMENT IT JOB E/TA status request Including estimated date of starting any completion or recompletion. IT JOB E/TA status request X X X X X X X X X X X X X
PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F. 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum 5. RIH w/CIBP set @3185'. Test cas: 6. POOH and lay down tubing. 7. Dump bail 35' (7 sacks) of cement 8. ND BOP/NU wellhead. 9. Test casing to 550 PSI for 30 minut 10. RDPU & RU. Clean location. 11. Well is TA'd.	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach with the Attach wit	COMMENCE DRILLING OPI CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, rellbore diagram of proposed of This Approval Abandonment and tag top of cement @31137	PLUG & ABANDONMENT IT JOB E/TA status request including estimated date of starting any completion or recompletion. Of Temporary 5 - Zo18 Expires 4-5-2018 RD wire line.
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum f 5. RIH w/CIBP set @3185'. Test cast f 6. POOH and lay down tubing. 7. Dump bail 35' (7 sacks) of cement f 8. ND BOP/NU wellhead. 9. Test casing to 550 PSI for 30 minuted for the same part of the same point for the same point f	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach with the Attach wit	COMMENCE DRILLING OPI CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, rellbore diagram of proposed of This Approval Abandonment and tag top of cement @31137	PLUG & ABANDONMENT IT JOB E/TA status request Including estimated date of starting any completion or recompletion. IT JOB E/TA status request X X X X X X X X X X X X X
PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F. 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum 5. RIH w/CIBP set @3185'. Test cas: 6. POOH and lay down tubing. 7. Dump bail 35' (7 sacks) of cement 8. ND BOP/NU wellhead. 9. Test casing to 550 PSI for 30 minut 10. RDPU & RU. Clean location. 11. Well is TA'd.	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach with the Attach wit	COMMENCE DRILLING OPI CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, rellbore diagram of proposed of This Approval Abandonment and tag top of cement @31137	PLUG & ABANDONMENT IT JOB E/TA status request including estimated date of starting any completion or recompletion. Of Temporary 5 - Zo18 Expires 4-5-2018 RD wire line.
PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F. 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum 5. RIH w/CIBP set @3185'. Test cas: 6. POOH and lay down tubing. 7. Dump bail 35' (7 sacks) of cement 8. ND BOP/NU wellhead. 9. Test casing to 550 PSI for 30 minut 10. RDPU & RU. Clean location. 11. Well is TA'd.	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach with the Attach wit	COMMENCE DRILLING OPT CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, rellbore diagram of proposed of This Approval of Abandonment and tag top of cement @3113* RUPU 03/28/2013 RDPU (redge and belief. I further certify to or an (attached) alternative	PLUG & ABANDONMENT IT JOB E/TA status request It including estimated date of starting any completion or recompletion. It is including estimated date of starting any completion or recompletion. It is including estimated date of starting any completion or recompletion. It is including estimated date of starting any completion or recompletion. It is including estimated date of starting any completion or recompletion. It is including estimated date of starting any completion or recompletion. It is including estimated date of starting any completion or recompletion. It is including estimated date of starting any completion or recompletion.
PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F. 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum 5. RIH w/CIBP set @3185'. Test cas 6. POOH and lay down tubing. 7. Dump bail 35' (7 sacks) of cement 8. ND BOP/NU wellhead. 9. Test casing to 550 PSI for 30 minut 10. RDPU & RU. Clean location. 11. Well is TA'd. I hereby certify that the information above is truconstructed or closed according to NMOCD guidelines	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach with the Attach wit	COMMENCE DRILLING OPPORT CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates wellbore diagram of proposed of This Approval Abandonment and tag top of cement @3113** RUPU 03/28/2013 RDPU (dedge and belief. I further certify to plan)	PLUG & ABANDONMENT IT JOB E/TA status request In including estimated date of starting any completion or recompletion. It just the status request It just the status request reque
PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F. 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum 5. RIH w/CIBP set @3185'. Test cas 6. POOH and lay down tubing. 7. Dump bail 35' (7 sacks) of cement 8. ND BOP/NU wellhead. 9. Test casing to 550 PSI for 30 minut 10. RDPU & RU. Clean location. 11. Well is TA'd. I hereby certify that the information above is truconstructed or closed according to NMOCD guidelines	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach with the Attach wit	COMMENCE DRILLING OPPORTS CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, wellbore diagram of proposed of the composition of the composit	PLUG & ABANDONMENT IT JOB PLUG & ABANDONMENT X A including estimated date of starting any completion or recompletion. Of Temporary 5 - Zo18 Expires 4-5 - Zo18 RD wire line. O4/08/2013 that any pit or below-grade tank has been/will be OCD-approved Associate DATE 06/27/2013 TELEPHONE NO. 806-592-6280
PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum 5. RIH w/CIBP set @3185'. Test cas 6. POOH and lay down tubing. 7. Dump bail 35' (7 sacks) of cement 8. ND BOP/NU wellhead. 9. Test casing to 550 PSI for 30 minut 10. RDPU & RU. Clean location. 11. Well is TA'd. I hereby certify that the information above is truconstructed or closed according to NMOCD guidelines SIGNATURE TYPE OR PRINT NAME Mendy A. John	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach with the Attach wit	COMMENCE DRILLING OPPORTS CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, wellbore diagram of proposed of the composition of the composit	PLUG & ABANDONMENT IT JOB PLUG & ABANDONMENT X A including estimated date of starting any completion or recompletion. Of Temporary 5 - Zo18 Expires 4-5 - Zo18 RD wire line. O4/08/2013 that any pit or below-grade tank has been/will be OCD-approved Associate DATE 06/27/2013 TELEPHONE NO. 806-592-6280
PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oper proposed work) SEE RULE 1103. F 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. Unhang pumping unit. 4. POOH and lay down rods and pum 5. RIH w/CIBP set @3185'. Test cas 6. POOH and lay down tubing. 7. Dump bail 35' (7 sacks) of cement 8. ND BOP/NU wellhead. 9. Test casing to 550 PSI for 30 minut 10. RDPU & RU. Clean location. 11. Well is TA'd. I hereby certify that the information above is true constructed or closed according to NMOCD guidelines SIGNATURE TYPE OR PRINT NAME Mendy A. Joh	CHANGE PLANS Multiple Completion rations (Clearly state all pertinent defor Multiple Completions: Attach with the Attach wit	COMMENCE DRILLING OPPORTS CASING TEST AND CEMEN OTHER: TA well bore etails, and give pertinent dates, wellbore diagram of proposed of the composition of the composit	PLUG & ABANDONMENT IT JOB PLTA status request In including estimated date of starting any completion or recompletion. If Tob It is including estimated date of starting any completion or recompletion. If Tob It is including estimated date of starting any completion or recompletion. If Job It is including estimated date of starting any completion or recompletion. If Job



