## State of New Mexico Energy, Minerals and Natural Resources Department


Form C-103 Revised 5-27-2004

FILE IN TRIPLICATE	OIL CONSI	ERVATION DIVISION	
DISTRICT I 1625 N. French Dr. , Hobbs, NM 88240	1220	South St. Francis Dr. nta Fe, NM 87505	WELL API NO. 30-025-05498
DISTRICT II	OCT 1 0 2013		5. Indicate Type of Lease
1301 W. Grand Ave, Artesia, NM 88210	00. 10.20.0		STATE X FEE
DISTRICT III			6. State Oil & Gas Lease No.
1000 Rio Brazos Rd, Aztec, NM 87410	RECEIVED		
SUNDRY N	OTICES AND REPORTS O	N WELLS	7. Lease Name or Unit Agreement Name
`	PROPOSALS TO DRILL OR TO D "APPLICATION FOR PERMIT" (F		North Hobbs (G/SA) Unit Section 25
1. Type of Well:			8. Well No. 231
Oil Well X	Gas Well Oth	er	/
2. Name of Operator			9. OGRID No. 157984
Occidental Permian Ltd.  3. Address of Operator			10. Pool name or Wildcat Hobbs (G/SA)
HCR 1 Box 90 Denver City, 7	X 79323		
4. Well Location		***************************************	
Unit Letter K : 2310	Feet From The South	Line and 2310 Fee	et From The West Line
Section 25	Township 18-	+S Range 37-F	E NMPM Lea County
Section 23	11. Elevation (Show whether		
	3666' DF	, ,	
Dit an Dalam and Tonk Ambiection	Clasura C	1	
Pit or Below-grade Tank Application	or Closure		Distance for an array to suffer a section
Pit Type Depth of Ground Water Distance from nearest fresh water well Distance from nearest surface water			
Pit Liner Thickness mil Below-Grade Tank: Volume bbls; Construction Material			
12. Cho	eck Appropriate Box to Indic	cate Nature of Notice, Report, or (	Other Data
NOTICE OF IN			SEQUENT REPORT OF:
PERFORM REMEDIAL WORK	PLUG AND ABANDON	REMEDIAL WORK	ALTERING CASING
	CHANGE PLANS	COMMENCE DRILLING OP	NS. PLUG & ABANDONMENT
TEMPORARII Y ABANDON I I			INS. I I FLOG & ADAIDONIVILINI I
TEMPORARILY ABANDON	<u> </u>		
PULL OR ALTER CASING	Multiple Completion	CASING TEST AND CEMEN	NT JOB
PULL OR ALTER CASING  OTHER:	Multiple Completion	CASING TEST AND CEMEN OTHER: Convert to p	oroducer X
PULL OR ALTER CASING OTHER:  13. Describe Proposed or Completed 0	Multiple Completion  Departions (Clearly state all pert	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates	oroducer X s, including estimated date of starting any
PULL OR ALTER CASING OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110	Multiple Completion  Departions (Clearly state all pert	CASING TEST AND CEMEN OTHER: Convert to p	oroducer X s, including estimated date of starting any
PULL OR ALTER CASING OTHER:  13. Describe Proposed or Completed 0	Multiple Completion  Departions (Clearly state all pert	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates	oroducer X s, including estimated date of starting any
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110  1. RUPU & RU.  2. ND wellhead/NU BOP.  3. POOH and lay down tubin	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A and and injection packer.	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates	oroducer X s, including estimated date of starting any
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110  1. RUPU & RU.  2. ND wellhead/NU BOP.  3. POOH and lay down tubin 4. RIH w/bit & tag liner top	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit.	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates	oroducer X s, including estimated date of starting any
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110  1. RUPU & RU.  2. ND wellhead/NU BOP.  3. POOH and lay down tubin 4. RIH w/bit & tag liner top 5. RIH w/bit & tag TD @43-	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit.  48'. POOH w/bit.	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of	oroducer X s, including estimated date of starting any completion or recompletion.
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110  1. RUPU & RU.  2. ND wellhead/NU BOP.  3. POOH and lay down tubin 4. RIH w/bit & tag liner top 5. RIH w/bit & tag TD @43- 6. RU wire line & perforate of the property of the proposed with the property of th	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit. 48'. POOH w/bit. casing at 4 JSPF @4253-61', 4	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of	oroducer X s, including estimated date of starting any completion or recompletion.
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110  1. RUPU & RU.  2. ND wellhead/NU BOP.  3. POOH and lay down tubin  4. RIH w/bit & tag liner top  5. RIH w/bit & tag TD @43  6. RU wire line & perforate of RIH w/PPI packer set @4  bbl scale squeeze. Flush of the proposed or Completed or Complete	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit. 48'. POOH w/bit. casing at 4 JSPF @4253-61', 4027'. RU HES & perform PPI w/200 bbl fresh water. RD pur	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of 4266-72', 4282-4304'. RD wire lin I acid job with 2400 gal of 15% PA mp truck. POOH w/PPI packer.	oroducer X s, including estimated date of starting any completion or recompletion.
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110  1. RUPU & RU. 2. ND wellhead/NU BOP. 3. POOH and lay down tubin 4. RIH w/bit & tag liner top 5. RIH w/bit & tag TD @43 6. RU wire line & perforate of RIH w/PPI packer set @4 bbl scale squeeze. Flush of RIH w/ESP equipment set	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit. 48'. POOH w/bit. casing at 4 JSPF @4253-61', 4027'. RU HES & perform PPI	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of 4266-72', 4282-4304'. RD wire lin I acid job with 2400 gal of 15% PA mp truck. POOH w/PPI packer.	oroducer X s, including estimated date of starting any completion or recompletion.
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110  1. RUPU & RU.  2. ND wellhead/NU BOP.  3. POOH and lay down tubin  4. RIH w/bit & tag liner top  5. RIH w/bit & tag TD @43  6. RU wire line & perforate of the proposed work in the proposed with the proposed work in the proposed with the proposed work in the proposed or Completed of the proposed work) SEE RULE 110  1. RUPU & RU.  2. ND wellhead/NU BOP.  3. POOH and lay down tubin to proposed work in the proposed work) SEE RULE 110  4. RIH w/bit & tag Inner top  5. RIH w/bit & tag TD @43  6. RU wire line & perforate of the proposed work in the proposed work) SEE RULE 110  9. RIH w/bit & tag Inner top  1. RIH w/bit & tag Inner top  5. RIH w/bit & tag TD @43  6. RU wire line & perforate of the proposed work in the proposed work	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit. 48'. POOH w/bit. casing at 4 JSPF @4253-61', 4027'. RU HES & perform PPI w/200 bbl fresh water. RD pur ton 116 jts of 2-3/8" tubing.	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of 4266-72', 4282-4304'. RD wire lin I acid job with 2400 gal of 15% PA mp truck. POOH w/PPI packer. Intake set @3766'	oroducer X s, including estimated date of starting any completion or recompletion.
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110  1. RUPU & RU. 2. ND wellhead/NU BOP. 3. POOH and lay down tubin 4. RIH w/bit & tag liner top 5. RIH w/bit & tag TD @43 6. RU wire line & perforate of RIH w/PPI packer set @4 bbl scale squeeze. Flush of RIH w/ESP equipment set	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit. 48'. POOH w/bit. casing at 4 JSPF @4253-61', 4027'. RU HES & perform PPI w/200 bbl fresh water. RD pur ton 116 jts of 2-3/8" tubing.	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of 4266-72', 4282-4304'. RD wire lin I acid job with 2400 gal of 15% PA mp truck. POOH w/PPI packer. Intake set @3766'	oroducer X s, including estimated date of starting any completion or recompletion.  The starting any completion or recompletion.  The starting any completion or recompletion.
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110  1. RUPU & RU. 2. ND wellhead/NU BOP. 3. POOH and lay down tubin 4. RIH w/bit & tag liner top 5. RIH w/bit & tag TD @43 6. RU wire line & perforate of the complete of the com	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A and and injection packer.  @3853'. POOH w/bit.  dasing at 4 JSPF @4253-61', 40027'. RU HES & perform PPI w/200 bbl fresh water. RD purt on 116 jts of 2-3/8" tubing.	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates attach wellbore diagram of proposed of 4266-72', 4282-4304'. RD wire lin I acid job with 2400 gal of 15% PA mp truck. POOH w/PPI packer. Intake set @3766' tion.  RUPU 09/12/2013	oroducer X s, including estimated date of starting any completion or recompletion.  The starting any completion or recompletion.  The starting any completion or recompletion.
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110  1. RUPU & RU. 2. ND wellhead/NU BOP. 3. POOH and lay down tubin 4. RIH w/bit & tag liner top 5. RIH w/bit & tag TD @43. 6. RU wire line & perforate of the complete of the co	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853' POOH w/bit.  48' POOH w/bit.  casing at 4 JSPF @4253-61', 4027'. RU HES & perform PPI w/200 bbl fresh water. RD purt on 116 jts of 2-3/8" tubing.  tion and return well to product is true and complete to the best of meaning and complet	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of trace with the convert of proposed of the convert of the c	oroducer  x, including estimated date of starting any completion or recompletion.  The area of the completion of the com
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110  1. RUPU & RU.  2. ND wellhead/NU BOP.  3. POOH and lay down tubin  4. RIH w/bit & tag liner top  5. RIH w/bit & tag TD @43  6. RU wire line & perforate of the proposed work of the proposed with the proposed work with the proposed work with the proposed work with the proposed work with the proposed or Completed of the proposed work with the proposed or Completed of the proposed work with the proposed or Completed or Proposed	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853' POOH w/bit.  48' POOH w/bit.  casing at 4 JSPF @4253-61', 4027'. RU HES & perform PPI w/200 bbl fresh water. RD purt on 116 jts of 2-3/8" tubing.  tion and return well to product is true and complete to the best of meaning and complet	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of tacid job with 2400 gal of 15% PA mp truck. POOH w/PPI packer. Intake set @3766' tion.  RUPU 09/12/2013  my knowledge and belief. I further certify  or an (attached) alternative	oroducer  x, including estimated date of starting any completion or recompletion.  The area of the completion of the com
PULL OR ALTER CASING OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110 1. RUPU & RU. 2. ND wellhead/NU BOP. 3. POOH and lay down tubin 4. RIH w/bit & tag liner top 5. RIH w/bit & tag TD @43-6. RU wire line & perforate 7. RIH w/PPI packer set @4 bbl scale squeeze. Flush v 8. RIH w/ESP equipment set 9. ND BOP/NU wellhead. 10. RDPU & RU. Clean local lines of the property of	Multiple Completion  Operations (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit. 48'. POOH w/bit. casing at 4 JSPF @4253-61', 4027'. RU HES & perform PPI w/200 bbl fresh water. RD pur on 116 jts of 2-3/8" tubing.  tion and return well to product is true and complete to the best of mes , a general permit	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of tacid job with 2400 gal of 15% PA mp truck. POOH w/PPI packer. Intake set @3766' tion.  RUPU 09/12/2013  my knowledge and belief. I further certify  or an (attached) alternative plan	producer  Is, including estimated date of starting any completion or recompletion.  Ide.  ID acid. RD HES. RU pump truck and pump 100  RD 09/20/2013  That any pit or below-grade tank has been/will be  the OCD-approved
PULL OR ALTER CASING OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110 1. RUPU & RU. 2. ND wellhead/NU BOP. 3. POOH and lay down tubin 4. RIH w/bit & tag liner top 5. RIH w/bit & tag TD @43 6. RU wire line & perforate 7. RIH w/PPI packer set @4 bbl scale squeeze. Flush v 8. RIH w/ESP equipment set 9. ND BOP/NU wellhead. 10. RDPU & RU. Clean local I hereby certify that the information above constructed or closed according to NMOCD guidelin	Multiple Completion  Operations (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit. 48'. POOH w/bit. casing at 4 JSPF @4253-61', 4027'. RU HES & perform PPI w/200 bbl fresh water. RD purt on 116 jts of 2-3/8" tubing.  tion and return well to product is true and complete to the best of mes , a general permit	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of tacid job with 2400 gal of 15% PA mp truck. POOH w/PPI packer. Intake set @3766' tion.  RUPU 09/12/2013  my knowledge and belief. I further certify or an (attached) alternative plan  TITLE Administrative	roducer  x, including estimated date of starting any completion or recompletion.  a.e.  D.D. acid. RD HES. RU pump truck and pump 100  RD 09/20/2013  that any pit or below-grade tank has been/will be  e OCD-approved  Associate  DATE
PULL OR ALTER CASING OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110 1. RUPU & RU. 2. ND wellhead/NU BOP. 3. POOH and lay down tubin 4. RIH w/bit & tag liner top 5. RIH w/bit & tag TD @43 6. RU wire line & perforate of the completed of the constructed or closed according to NMOCD guidelin  I hereby certify that the information above constructed or closed according to NMOCD guidelin  SIGNATURE  TYPE OR PRINT NAME Mendy A	Multiple Completion  Operations (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit. 48'. POOH w/bit. casing at 4 JSPF @4253-61', 4 027'. RU HES & perform PPI w/200 bbl fresh water. RD pur con 116 jts of 2-3/8" tubing.  tion and return well to product is true and complete to the best of mes , a general permit	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of tacid job with 2400 gal of 15% PA mp truck. POOH w/PPI packer. Intake set @3766' tion.  RUPU 09/12/2013  my knowledge and belief. I further certify or an (attached) alternative plan  TITLE Administrative	roducer  x, including estimated date of starting any completion or recompletion.  a.e.  D.D. acid. RD HES. RU pump truck and pump 100  RD 09/20/2013  that any pit or below-grade tank has been/will be  e OCD-approved  Associate  DATE
PULL OR ALTER CASING OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110 1. RUPU & RU. 2. ND wellhead/NU BOP. 3. POOH and lay down tubin 4. RIH w/bit & tag liner top 5. RIH w/bit & tag TD @43. 6. RU wire line & perforate of 7. RIH w/PPI packer set @4 bbl scale squeeze. Flush of 8. RIH w/ESP equipment set 9. ND BOP/NU wellhead. 10. RDPU & RU. Clean local liner top 10. RDPU & RU. RDPU	Multiple Completion  Deparations (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit. 48'. POOH w/bit. casing at 4 JSPF @4253-61', 4027'. RU HES & perform PPI w/200 bbl fresh water. RD purt on 116 jts of 2-3/8" tubing.  tion and return well to product is true and complete to the best of mes , a general permit  Johnson E-mail addr	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of tacid job with 2400 gal of 15% PA mp truck. POOH w/PPI packer. Intake set @3766' tion.  RUPU 09/12/2013  my knowledge and belief. I further certify  or an (attached) alternative plan  TITLE Administrative ress: mendy johnson@oxy.com	roducer  x, including estimated date of starting any completion or recompletion.  a.e.  AD acid. RD HES. RU pump truck and pump 100  RD 09/20/2013  that any pit or below-grade tank has been/will be  e OCD-approved  Associate  DATE  TELEPHONE NO. 806-592-6280
PULL OR ALTER CASING OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110 1. RUPU & RU. 2. ND wellhead/NU BOP. 3. POOH and lay down tubin 4. RIH w/bit & tag liner top 5. RIH w/bit & tag TD @43 6. RU wire line & perforate of the proposed set and the proposed set of	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit.  ### 18853'. POOH w/bit.  ### 200 House and Form PPI ### 200 bbl fresh water. RD pur ### 100 116 jts of 2-3/8" tubing.  #### 1990 tion and return well to product is true and complete to the best of many part of the perturbation of the best of many part of the perturbation of the best of many part of the best of the bes	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of trace well and trace wellbore diagram of proposed of trace wellbore diagram of proposed of trace wellbore diagram of proposed of trace wel	roducer  x, including estimated date of starting any completion or recompletion.  Associate  X  X  X  X  X  X  X  X  X  X  X  X  X
PULL OR ALTER CASING OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110 1. RUPU & RU. 2. ND wellhead/NU BOP. 3. POOH and lay down tubin 4. RIH w/bit & tag liner top 5. RIH w/bit & tag TD @43. 6. RU wire line & perforate of 7. RIH w/PPI packer set @4 bbl scale squeeze. Flush of 8. RIH w/ESP equipment set 9. ND BOP/NU wellhead. 10. RDPU & RU. Clean local liner top 10. RDPU & RU. RDPU	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit.  ### 1888 POOH w/bit.  ### 200 bbl fresh water. RD pur is on 116 jts of 2-3/8" tubing.  #### 1989 The product is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes and complete to the best of	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of tacid job with 2400 gal of 15% PA mp truck. POOH w/PPI packer. Intake set @3766' tion.  RUPU 09/12/2013  my knowledge and belief. I further certify  or an (attached) alternative plan  TITLE Administrative ress: mendy johnson@oxy.com	roducer  x, including estimated date of starting any completion or recompletion.  Re. AD acid. RD HES. RU pump truck and pump 100  RD 09/20/2013  that any pit or below-grade tank has been/will be  e OCD-approved  Associate  DATE  DATE  DATE
PULL OR ALTER CASING OTHER:  13. Describe Proposed or Completed of proposed work) SEE RULE 110 1. RUPU & RU. 2. ND wellhead/NU BOP. 3. POOH and lay down tubin 4. RIH w/bit & tag liner top 5. RIH w/bit & tag TD @43 6. RU wire line & perforate of the proposed set and the proposed set of	Multiple Completion  Departions (Clearly state all pert 3. For Multiple Completions: A ng and injection packer.  @3853'. POOH w/bit.  ### 1888 POOH w/bit.  ### 200 bbl fresh water. RD pur is on 116 jts of 2-3/8" tubing.  #### 1989 The product is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes a general permit is true and complete to the best of mes and complete to the best of	CASING TEST AND CEMEN OTHER: Convert to p tinent details, and give pertinent dates Attach wellbore diagram of proposed of tacid job with 2400 gal of 15% PA mp truck. POOH w/PPI packer. Intake set @3766' tion.  RUPU 09/12/2013  my knowledge and belief. I further certify  or an (attached) alternative plan  TITLE Administrative ress: mendy johnson@oxy.com  TITLE Derwork to put this II on production.  tion Report	roducer  x, including estimated date of starting any completion or recompletion.  a.e.  AD acid. RD HES. RU pump truck and pump 100  RD 09/20/2013  that any pit or below-grade tank has been/will be  e OCD-approved  Associate  DATE  TELEPHONE NO. 806-592-6280

Form C-102 Dedicated Acreage Form C-104 Request for Allowable &

Authorization to Transport

## Work Plan Report for Well: NHSAU 231-25



## **Survey Viewer**