

Submit 1 Copy To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
October 13, 2009

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-041-20940
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator Armstrong Energy Corporation		6. State Oil & Gas Lease No. VB-1609
3. Address of Operator P.O. Box 1973, Roswell, NM 88202-1973		7. Lease Name or Unit Agreement Name PEP 36 STATE
4. Well Location Unit Letter <u>M</u> : <u>330</u> feet from the <u>South</u> line and <u>330</u> feet from the <u>West</u> line Section <u>36</u> Township <u>05S</u> Range <u>33E</u> NMPM <u>Roosevelt</u> County		8. Well Number 2
11. Elevation (Show whether DR, RKB, RT, GR, etc.)		9. OGRID Number 1092
		10. Pool name or Wildcat Wildcat

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

OTHER: ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

- 1) TIH w/ tubing, circulate hole w/ 2% KCL water, spot 200 gals 15% NEFE acid @ 7264'.
- 2) Perf 7247'-7250', 7254'-7258', 7260'-7264', 2 JSPF, 120° phasing.
- 3) TIH w/ packer and tubing, break down, displace acid and swab test.
- 4) If test has sufficient oil cut, acidize w/ 2000 gals 15% NEFE acid and ball sealers. Swab to recover load and test.

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief:

SIGNATURE B. Stubbs TITLE VICE PRESIDENT DATE 02-19-2015

Type or print name Bruce A. Stubbs E-mail address: bastubbs@armstrongenergycorp.com PHONE: (575) 625-2222

For State Use Only

APPROVED BY: [Signature] TITLE Petroleum Engineer DATE 02/23/15

Conditions of Approval (if any):

FEB 23 2015