NO. OF COPIES RECEIVED	7	
DISTRIBUTION	· ·	Form C-103 Supersedes Old
SANTA FE	NEW MEXICO OIL CONSERVATION COMMISSION	C-102 and C-103
FILE		Effective 1-1-65
U.S.G.S.	$1 \qquad \qquad 0 \approx 7 \cdot 3 \cdot 5 \cdot 5$	State X Fee
LAND OFFICE	1 0 0 14	State X Fee
OPERATOR		5. State Oil & Gas Lease No.
		E-6927
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)		
oil GAS WELL OTHER. Water Injection		7. Unit Agreement Name Northeast Caprock Queen Unit
2. Name of Operator		8. Farm or Lease Name
TEXACO Inc.		Northeast Caprock
3. Address of Operator		9. Well No.
4. Location of Well	P.O. Box 728 - Hobbs, N.M.	3
	000	10. Field and Pool, or Wildcat
UNIT LETTER	980 FEET FROM THE South LINE AND 1980 FEET FI	Caprock Queen
THE East LINE, SECTION	16 12-S 32-E	PM.
mmmmm		
	15. Elevation (Show whether DF, RT, GR, etc.)	12. County
	4371' (D. F.)	Lea
Check A	Appropriate Box To Indicate Nature of Notice, Report or	Other Data
NOTICE OF IN	SUBSEQUE	ENT REPORT OF:
NOTICE OF IN	SUBSEQUE	ENT REPORT OF:
NOTICE OF IN	SUBSEQUE	ENT REPORT OF:
PERFORM REMEDIAL WORK	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CHANGE PLANS CASING TEST AND CEMENT JQB	ENT REPORT OF: ALTERING CASING PLUG AND ABANDONMENT
PERFORM REMEDIAL WORK	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CHANGE PLANS CASING TEST AND CEMENT JQB	ENT REPORT OF: ALTERING CASING PLUG AND ABANDONMENT
PERFORM REMEDIAL WORK	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CHANGE PLANS CASING TEST AND CEMENT JQB	ENT REPORT OF:
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CHANGE PLANS CASING TEST AND CEMENT JQB	ALTERING CASING PLUG AND ABANDONMENT ter Injection Well
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 17. Describe Proposed or Completed Opwork) SEE RULE 1103.	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CHANGE PLANS CASING TEST AND CEMENT JOB OTHER Change to Was erations (Clearly state all pertinent details, and give pertinent dates, included)	ALTERING CASING PLUG AND ABANDONMENT ter Injection Well
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 17. Describe Proposed or Completed Op work) SEE RULE 1103. The following	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CHANGE PLANS CASING TEST AND CEMENT JQB OTHER Change to Wa	ALTERING CASING PLUG AND ABANDONMENT ter Injection Well
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 17. Describe Proposed or Completed Opwork) SEE RULE 1703. The following 1. Pull rods	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CASING TEST AND CEMENT JQB OTHER Change to Wa erations (Clearly state all pertinent details, and give pertinent dates, includ Work has been completed on subject well: and tubing.	ALTERING CASING PLUG AND ABANDONMENT ter Injection Well
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 17. Describe Proposed or Completed Opwork) SEE RULE 1703. The following 1. Pull rods 2. Run 2-3/8	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CHANGE PLANS CASING TEST AND CEMENT JQB OTHER Change to Was erations (Clearly state all pertinent details, and give pertinent dates, includ Work has been completed on subject well: and tubing. "plastic coated tubing, and set at 2971".	ALTERING CASING PLUG AND ABANDONMENT ter Injection Well
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 17. Describe Proposed or Completed Opwork) SEE RULE 1703. The following 1. Pull rods 2. Run 2-3/8	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CASING TEST AND CEMENT JQB OTHER Change to Wa erations (Clearly state all pertinent details, and give pertinent dates, includ Work has been completed on subject well: and tubing.	ALTERING CASING PLUG AND ABANDONMENT ter Injection Well
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 17. Describe Proposed or Completed Opwork) SEE RULE 1703. The following 1. Pull rods 2. Run 2-3/8	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CHANGE PLANS CASING TEST AND CEMENT JQB OTHER Change to Was erations (Clearly state all pertinent details, and give pertinent dates, includ Work has been completed on subject well: and tubing. "plastic coated tubing, and set at 2971".	ALTERING CASING PLUG AND ABANDONMENT [ter Injection Well
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 17. Describe Proposed or Completed Opwork) SEE RULE 1703. The following 1. Pull rods 2. Run 2-3/8	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CHANGE PLANS CASING TEST AND CEMENT JQB OTHER Change to Was erations (Clearly state all pertinent details, and give pertinent dates, includ Work has been completed on subject well: and tubing. "plastic coated tubing, and set at 2971".	ALTERING CASING PLUG AND ABANDONMENT ter Injection Well
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 17. Describe Proposed or Completed Opwork) SEE RULE 1703. The following 1. Pull rods 2. Run 2-3/8	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CHANGE PLANS CASING TEST AND CEMENT JQB OTHER Change to Was erations (Clearly state all pertinent details, and give pertinent dates, includ Work has been completed on subject well: and tubing. "plastic coated tubing, and set at 2971".	ALTERING CASING PLUG AND ABANDONMENT [ter Injection Well
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 17. Describe Proposed or Completed Opwork) SEE RULE 1703. The following 1. Pull rods 2. Run 2-3/8	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CHANGE PLANS CASING TEST AND CEMENT JQB OTHER Change to Was erations (Clearly state all pertinent details, and give pertinent dates, includ Work has been completed on subject well: and tubing. "plastic coated tubing, and set at 2971".	ALTERING CASING PLUG AND ABANDONMENT [ter Injection Well
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 17. Describe Proposed or Completed Opwork) SEE RULE 1703. The following 1. Pull rods 2. Run 2-3/8	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CHANGE PLANS CASING TEST AND CEMENT JQB OTHER Change to Was erations (Clearly state all pertinent details, and give pertinent dates, includ Work has been completed on subject well: and tubing. "plastic coated tubing, and set at 2971".	ALTERING CASING PLUG AND ABANDONMENT ter Injection Well
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 17. Describe Proposed or Completed Opwork) SEE RULE 1703. The following 1. Pull rods 2. Run 2-3/8	PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. CHANGE PLANS CASING TEST AND CEMENT JQB OTHER Change to Was erations (Clearly state all pertinent details, and give pertinent dates, includ Work has been completed on subject well: and tubing. "plastic coated tubing, and set at 2971".	ALTERING CASING PLUG AND ABANDONMENT ter Injection Well

Assistant District

Superintendent

CONDITIONS OF APPROVAL, IF ANY

October 7, 1965