

8. Spot 10 sack cement plug at surface. Install marker. Clean up location. Notify New Mexico Energy & Minerals Dept. when ready for inspection.

9. 9.8# drilling mud will be spotted between cement plugs.

Top 5½" liner has been tested to 2000#. Held 30 min.