

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.O.S.		
LAND OFFICE		
OPERATOR		

5a. Indicate Type of Lease
State Fee

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>Injection</u>	7. Unit Agreement Name
2. Name of Operator <u>Lewis B. Burleson, Inc.</u>	8. Farm or Lease Name <u>State D</u>
3. Address of Operator <u>P. O. Box 2479, Midland, Texas 79702</u>	9. Well No. <u>3</u>
4. Location of Well UNIT LETTER <u>E</u> <u>2310</u> FEET FROM THE <u>North</u> LINE AND <u>990</u> FEET FROM THE <u>West</u> LINE, SECTION <u>27</u> TOWNSHIP <u>14-S</u> RANGE <u>31-E</u> NMPM.	10. Field and Pool, or Wildcat <u>East Caprock Queen</u>
15. Elevation (Show whether DF, RT, GR, etc.)	12. County <u>Chaves</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

5/15/86

1. Set CIBP @ 3010'. Dump 35' cement on CIBP
2. Casing would not test.
3. Set CIBP @ 280'. Test casing
4. Perf 4½" casing @ 268'
5. Set 55 sk. cement plug to establish circ between 4½ & 8-5/8" surface pipe.
6. Pump 95 sks cement to fill 4½ & 8-5/8" from 268' to surface.
7. Install Marker

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Wayne Jones TITLE Superintendent DATE 5/20/86

APPROVED BY Jack Griffin TITLE OIL & GAS INSPECTOR DATE JUN 1986

CONDITIONS OF APPROVAL, IF ANY:

PA 00101 5