

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
R-1326-1

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name --
2. Name of Operator Texaco Inc.	8. Farm or Lease Name N. W. "R" St. NCT-1
3. Address of Operator P. O. Box 720, Hobbs, New Mexico 88240	9. Well No. 6
4. Location of Well UNIT LETTER <u>I</u> <u>760</u> FEET FROM THE <u>East</u> LINE AND <u>2210</u> FEET FROM THE <u>North</u> LINE, SECTION <u>6</u> TOWNSHIP <u>19-S</u> RANGE <u>25-E</u> NMPM.	10. Field and Pool, or Wildcat Vacuum AFG Reef
15. Elevation (Show whether DF, RT, GR, etc.) 3000' (DF)	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

<p>NOTICE OF INTENTION TO:</p> <p>PERFORM REMEDIAL WORK <input type="checkbox"/></p> <p>TEMPORARILY ABANDON <input type="checkbox"/></p> <p>PULL OR ALTER CASING <input type="checkbox"/></p> <p>OTHER <u>Repair Water Flow</u> <input checked="" type="checkbox"/></p>	<p>SUBSEQUENT REPORT OF:</p> <p>PLUG AND ABANDON <input type="checkbox"/></p> <p>CHANGE PLANS <input type="checkbox"/></p> <p>REMEDIAL WORK <input type="checkbox"/></p> <p>COMMENCE DRILLING OPNS. <input type="checkbox"/></p> <p>CASING TEST AND CEMENT JOBS <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p> <p>ALTERING CASING <input type="checkbox"/></p> <p>PLUG AND ABANDONMENT <input type="checkbox"/></p>
---	---

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Install BOP. Full production equipment.
2. Set RBF @ 4900'. Dump 20' sand on plug.
3. Perforate 2 7/8" csg. w/2-JS @ 3100'. Set cement retainer.
4. Cement perms @ 3100' w/500 sx. class III cement. Circulate or run Temperature Survey. WOC. JOC. Test. Pull RBF
5. Run production equipment. Test & return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Assistant District Manager DATE 7/16/01

APPROVED BY [Signature] TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: