


Tom Closson #7
1980' FNL & 990' FEL, Sec. 6-T22S-R36E
Lea County, New Mexico

Procedure to Test Well for Casing Integrity

1. Contact BLM in Carlsbad at 505-887-6544 48 hours before beginning procedure.
2. MI RU WU. POH with rods and pump if present. ND WH and NU BOP. POH with tubing and production equipment.
3. RIH with RBP on tubing and set at 3050'. Close rams and pressure test casing to 500 psi for 30 minutes utilizing a chart. Maximum pressure bleed off is 10%. Send chart to Midland office.
4. Latch RBP and POH with RBP. RIH with tubing open ended. ND BOP and NU wellhead.


Doug Keathley
Area Supervisor

