Received by QCD to Appropriate Bistrict 4	State of New	Mexico		Form C-103 of 9		
Office <u>District I</u> – (575) 393-6161 1625 N. French Dr. Habba NM 88240	Energy, Minerals and N	Vatural Resources	WELL API NO.	Revised August 1, 2011		
1625 N. French Dr., Hobbs, NM 88240 <u>District II</u> – (575) 748-1283	OIL CONSERVATI	ON DIVISION	30-005-00342			
811 S. First St., Artesia, NM 88210 District III – (505) 334-6178	1220 South St. I		5. Indicate Type of 1			
1000 Rio Brazos Rd., Aztec, NM 87410	Santa Fe, NN		STATE FEE 6. State Oil & Gas Lease No.			
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM	OG4681 (Re-entry)	cease No.				
87505 SUNDRY NO (DO NOT USE THIS FORM FOR PROP DIFFERENT RESERVOIR. USE "APPI	7. Lease Name or U TWIN LAKES SAN					
PROPOSALS.) 1. Type of Well: Oil Well	8. Well Number: 45					
Name of Operator Last produced by Petrolia Energy	9. OGRID Number 269864					
3. Address of Operator	10. Pool name or W	ildcat				
6301 DEAUVILLE BLVD.,	6301 DEAUVILLE BLVD., MIDLAND, TX 79706					
4. Well Location	f4 f4 COLUTII	1: 1000	for the wife of	Г. 1:		
Unit Letter <u>N</u> : <u>660</u> Section 36	feet from the <u>SOUTH</u> Township 8S	line and1980 Range 28E	_feet from theWEST	Γline County Chaves		
Section 30	11. Elevation (Show whether			County Chaves		
	3941' GL		,			
12 (11-	۸	Natura of Nation I	Danant an Othan Dat	_		
	Appropriate Box to Indicate	1	•			
PERFORM REMEDIAL WORK TEMPORARILY ABANDON	CHANGE PLANS	REMEDIAL WOR	ILLING OPNS.□ P	OR FOF: LTERING CASING ☐ AND A ☐		
PULL OR ALTER CASING DOWNHOLE COMMINGLE		CASING/CEMEN	T JOB 📙			
OTHER:	П	OTHER:	Notify OCD 24 hrs. pr	ior to any work		
	oleted operations. (Clearly state a ork). SEE RULE 19.15.7.14 NM completion.					
Please see attached abandor	nment procedure					
Well was most recently tran U.S.A. Inc. was approached additional background). For 005-00342 incorrectly refer states the correct reference	by NMOCD regarding portion of the control of the co	lugging liability (a y 8/3/2021- Sundr	attached plan of ac y ID 39766] for W	etion highlights Vell API No. 30-		
I hereby certify that the information	above is true and complete to the	e best of my knowledge	and belief.			
	9/24/2021					
X Hayes Thibod	eaux					
SIGNATURE Signed by: Hayes Thibod	leaux TITLE	Well Abandonment Eng	gineerDATE_	9/24/2021		
Type or print name <u>Hayes Thibode</u> <u>For State Use Only</u>	aux PHONE: 281-726-9683					
APPROVED BY:Conditions of Approval (if any):	TITLE_	Staff Man	agerDATE_	11/29/2021		
****SEE ATTACHE	D COA's****	Must be plugge	d by 11/29/2022			

CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
 operations are conducted. A cement evaluation tool is required in order to ensure isolation of
 producing formations, protection of water and correlative rights. A cement bond log or other
 accepted cement evaluation tool is to be provided to the division for evaluation if one has not
 been previously run or if the well did not have cement circulated to surface during the original
 casing cementing job or subsequent cementing jobs. Insure all bradenheads have been
 exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E)Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K)Potash---(In the R-111-P Area (Page 3 & 4), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

R-111-P Area

T 18S - R 30E

Sec 10 Unit P. Sec 11 Unit M,N. Sec 13 Unit L,M,N. Sec 14 Unit C -P. Sec 15 Unit A G,H,I,J,K,N,O,P. Sec 22 Unit All except for M. Sec 23, Sec 24 Unit C,D,E,L, Sec 26 Unit A-G, Sec 27 Unit A,B,C

T 19S - R 29E

Sec 11 Unit P. Sec 12 Unit H-P. Sec 13. Sec 14 Unit A,B,F-P. Sec 15 Unit P. Sec 22 Unit A,B,C,F,G,H,I,J K,N,O,P. Sec 23. Sec 24. Sec 25 Unit D. Sec 26 Unit A-F. Sec 27 Unit A,B,C,F,G,H.

T 19S - R 30E

Sec 2 Unit K,L,M,N. Sec 3 Unit I,L,M,N,O,P. Sec 4 Unit C,D,E,F,G,I-P. Sec 5 Unit A,B,C,E-P. Sec 6 Unit I,O,P. Sec 7 – Sec 10. Sec 11 Unit D, G—P. Sec 12 Unit A,B,E-P. Sec 13 Unit A-O. Sec 14-Sec 18. Sec 19 Unit A-L, P. Sec 20 – Sec 23. Sec 24 Unit C,D,E,F,L,M,N. Sec 25 Unit D. Sec 26 Unit A-G, I-P. Sec 27, Sec 28, Sec 29 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 32 Unit A,B,G,H,I,J,N,O,P. Sec 33. Sec 34. Sec 35. Sec 36 Unit D,E,F,I-P.

T 19S - R 31E

Sec 7 Unit C,D,E,F,L. Sec 18 Unit C,D,E,F,G,K,L. Sec 31 Unit M. Sec 34 Unit P. Sec 35 Unit M,N,O. Sec 36 Unit O,P.

T 20S - R 29E

Sec 1 Unit H,I,P. Sec 13 Unit E,L,M,N. Sec 14 Unit B-P. Sec 15 Unit A,H,I,J,N,O,P. Sec 22 Unit A,B,C,F,G,H,I,J,O,P. Sec 23. Sec 24 Unit C,D,E,F,G,J-P. Sec 25 Unit A-O. Sec 26. Sec 27 Unit A,B,G,H,I,J,O,P. Sec 34 Unit A,B,G,H. Sec 35 Unit A-H. Sec 36 Unit B-G.

T 20S - R 30E

Sec 1 – Sec 4. Sec 5 Unit A,B,C,E-P. Sec 6 Unit E,G-P. Sec 7 Unit A-H,I,J,O,P. Sec 8 – 17. Sec 18 Unit A,B,G,H,I,J,O,P. Sec 19 Unit A,B,G,H,I,J,O,P. Sec 30 Unit A-L,N,O,P. Sec 31 Unit A,B,G,H,I,P. Sec 32 – Sec 36.

T 20S - R 31E

Sec 1 Unit A,B,C,E-P. Sec 2. Sec 3 Unit A,B,G,H,I,J,O,P. Sec 6 Unit D,E,F,J-P. Sec 7. Sec 8 Unit E-P. Sec 9 Unit E,F,J-P. Sec 10 Unit A,B,G-P. Sec 11 – Sec 36.

T 21S - R 29E

Sec 1 – Sec 3. Sec 4 Unit L1 – L16,I,J,K,O,P. Sec 5 Unit L1. Sec 10 Unit A,B,H,P. Sec 11 – Sec 14. Sec 15 Unit A,H,I. Sec 23 Unit A,B. Sec 24 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 25 Unit A,O,P. Sec 35 Unit G,H,I,J,K,N,O,P. Sec 36 A,B,C,F – P.

T 21S - R 30E

Sec 1 – Sec 36

T 21S - R 31E

Sec 1 – Sec 36

T 22S - R 28E

Sec 36 Unit A,H,I,P.

T 22S - R 29E

Sec 1. Sec2. Sec 3 Unit I,J,N,O,P. Sec 9 Unit G – P. Sec 10 – Sec 16. Sec 19 Unit H,I,J. Sec 20 – Sec 28. Sec 29 Unit A,B,C,D,G,H,I,J,O,P. Sec 30 Unit A. Section 31 Unit C – P. Sec 32 – Sec 36

T 22S - R 30E

Sec 1 – Sec 36

T 22S - R 31E

Sec 1 – Sec 11. Sec 12 Unit B,C,D,E,F,L. Sec 13 Unit E,F,K,L,M,N. Sec 14 – Sec 23. Sec 24 Unit C,D,E,F,K,L,M,N. Sec 25 Unit A,B,C,D. Sec 26 Unit A,BC,D,G,H. Sec 27 – Sec 34.

T 23S - R 28E

Sec 1 Unit A

T 23S - R 29E

Sec 1 – Sec 5. Sec 6 Unit A – I, N,O,P. Sec 7 Unit A,B,C,G,H,I,P. Sec 8 Unit A – L, N,O,P. Sec 9 – Sec 16. Sec 17 Unit A,B,G,H,I,P. Sec 21 – Sec 23. Sec 24 Unit A – N. Sec 25 Unit D,E,L. Sec 26. Sec 27. Sec 28 Unit A – J, N,O,P. Sec 33 Unit A,B,C. Sec 34 Unit A,B,C,D,F,G,H. Sec 35. Sec 36 Unit B,C,D,E,F,G,K,L.

T 23S - R 30E

Sec 1 – Sec 18. Sec 19 Unit A – I,N,O,P. Sec 20, Sec 21. Sec 22 Unit A – N, P. Sec 23, Sec 24, Sec 25. Sec 26 Unit A,B,F-P. Sec 27 Unit C,D,E,I,N,O,P. Sec 28 Unit A – H, K,L,M,N. Sec 29 Unit A – J, O,P. Sec 30 Unit A,B. Sec 32 A,B. Sec 33 Unit C,D,H,I,O,P. Sec 34, Sec 35, Sec 36.

T 23S - R 31E

Sec 2 Unit D,E,J,O. Sec 3 – Sec 7. Sec 8 Unit A – G, K – N. Sec 9 Unit A,B,C,D. Sec 10 Unit D,P. Sec 11 Unit G,H,I,J,M,N,O,P. Sec 12 Unit E,L,K,M,N. Sec 13 Unit C,D,E,F,G,J,K,L,M,N,O. Sec 14. Sec 15 Unit A,B,E – P. Sec 16 Unit I, K – P. Sec 17 Unit B,C,D,E, I – P. Sec 18 – Sec 23. Sec 24 Unit B – G, K,L,M,N. Sec 25 Unit B – G, J,K,L. Sec 26 – Sec 34. Sec 35 Unit C,D,E.

T 24S – R 29E

Sec 2 Unit A, B, C, D. Sec 3 Unit A

T 24S - R 30E

Sec 1 Unit A – H, J – N. Sec 2, Sec 3. Sec 4 Unit A,B,F – K, M,N,O,P. Sec 9 Unit A – L. Sec 10 Unit A – L, O,P. Sec 11. Sec 12 Unit D,E,L. Sec 14 Unit B – G. Sec 15 Unit A,B,G,H.

T 24S - R 31E

Sec 3 Unit B – G, J – O. Sec 4. Sec 5 Unit A – L, P. Sec 6 Unit A – L. Sec 9 Unit A – J, O,P. Sec 10 Unit B – G, K – N. Sec 35 Unit E – P. Sec 36 Unit E,K,L,M,N.

T 25S - R 31E

Sec 1 Unit C,D,E,F. Sec 2 Unit A – H.


Critical Well Notes


- Limited well files found on NMOCD database.
- Well type: OIL (ACTIVE)
- Latest records indicate that rods & pump in wellbore; no details available on size and depths
- OH interval was drilled from 3415' to 7418', but was plugged back after testing reservoir.
 - Series of cement plugs was pumped in open hole and across the 9-5/8" shoe
- Was was plugged for a period of time; cut & pulled 9-5/8" casing from 741'
- Well was re-entered at a later date, 5-1/2" casing was run into 9-5/8" casing stub down to 1001' and cemented to surface. Current zone was perforated for production.

Procedure - Rig Only

- 1 Contact NMOCD at least 24 hrs prior to performing any work
- 2 MIRU pulling service rig
- 3 Check pressure on all casing strings. Verify no pressure and observe well for 15 minutes to verify no flow. Kill well with brine or mud as necessary.
 - 1 Bubble test all annuli for 30 minutes each and capture results in WellView under daily pressures tab.
- 4 N/U rod BOP's and begin L/D rod string & pump.
 - 1 Unknown size of rods. Plan to have equipment for various OD's.
- 5 N/U stump-tested BOPE.
 - 5k 7-1/16" Class II BOP and pressure test 250 psi low and 1000 psi, MASP, or max anticipated pressure (whichever is larger) high for 5 min each.
- 6 TOH with tubing string and L/D same.
 - 1 Unkown if packer or TAC is currently installed in wellbore
 - 2 If unable to pull tubing free, plan to MIRU wireline to run guage ring, CCL to confirm depth of TAC or packer
 - 3 Request variance from NMOCD to cut tubing above TAC/packer depth and L/D same
- 7 MIRU wireline and lubricator. Run gauge ring to planned set depth for CIBP per proposed schematic
- 8 POOH with gauge ring run. RIH with CIBP and set at proposed set depth. POOH with W/L.
- 9 TIH with pressure tested workstring and tag mechanical barrier
- 10 Pressure test CIBP, casing to 500 psi for 15 minutes
- 11 Proceed to pump cement per the cementing table below. Additional notes/considerations:
 - 1 If bubble test on prod csg annulus fails, discuss option to pump contingency cement prior to final plug to ensure leak is isolated. Discuss depths and volumes with engineer.
 - 2 Reports show cement was circulated to surface on primary 5-1/2" cement job. If bubble test is failing, plan to run CBL to identify any gaps in cement that would allow for cement squeeze, bio squeeze, etc.
- 12 Discuss with engineer any changes to proposed plan forward during execution

		Plug				
Sum	mary Table	Base	Тор	Volume	Perf & Squeeze	Notes
	Plug #1	2605	2000	199	NO	WOC, tag, test
	Plug #2	1920	1770	50	NO	
Plug #3	1050	1000	17	NO	Plug #3 inside 9-5/8"	
	1000	630	38	NO	Plug #3 inside 5-1/2"	
	Plug #4	250	0	26	NO	
	Total Sacks	330				
Total Perf	& Squeeze		0			
	Total Spot		5			





District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone: (575) 748-1283 Fax: (575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. **Santa Fe, NM 87505**

CONDITIONS

Action 51968

CONDITIONS

Operator:	OGRID:
CHEVRON U S A INC	4323
6301 Deauville Blvd	Action Number:
Midland, TX 79706	51968
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

CONDITIONS

Created By	Condition	Condition Date
gcordero	None	11/29/2021