Office *	State of New Me		Form CP-11031
<u>District I</u> – (575) 393-6161	Energy, Minerals and Natu		Revised July 18, 2013
1625 N. French Dr., Hobbs, NM 88240 District II – (575) 748-1283		20	ELL API NO.
811 S. First St., Artesia, NM 88210	OIL CONSERVATION		015-00281 Indicate Type of Lease
District III - (505) 334-6178	1220 South St. Fran	icis Dr.	STATE STATE STATE
1000 Rio Brazos Rd., Aztec, NM 87410 District IV - (505) 476-3460	Santa Fe, NM 87	505 6	State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505		· · ·	5440 511 & 543 L6436 145.
SUNDRY NO	OTICES AND REPORTS ON WELLS OPOSALS TO DRILL OR TO DEEPEN OR PLU	1	Lease Name or Unit Agreement Name
DIFFERENT RESERVOIR. USE "AP	PLICATION FOR PERMIT" (FORM C-101) FO	R SUCH	npson 15 B
PROPOSALS.) 1. Type of Well: Oil Well		8.	Well Number #134
2. Name of Operator		9.	OGRID Number
Redwood Operating, LLC			)211
3. Address of Operator	3111380		Pool name or Wildcat
PO Box 1370, Artesia, NM 88 4. Well Location	2111370	Ate	oka; Glorieta-Yeso
Unit Letter B :	330 feet from the <u>N</u>	line and 1650	_feet from theE line
Section 15	Township 18S Ra	nge 26E N	MPM County Eddy
	11. Elevation (Show whether DR,		
	334	3	
12. Chec	k Appropriate Box to Indicate N	ature of Notice Ren	ort or Other Data
		1	
PERFORM REMEDIAL WORK	INTENTION TO:		QUENT REPORT OF:
TEMPORARILY ABANDON	PLUG AND ABANDON     CHANGE PLANS	REMEDIAL WORK	
		CASING/CEMENT JOI	
			Notify OCD 24 hrs. prior to any work
		OTHER:	lone T
OTHER:			
13. Describe proposed or co	pmpleted operations. (Clearly state all p l work). SEE RULE 19 15 7 14 NMAC	pertinent details, and give	e pertinent dates, including estimated date
13. Describe proposed or co	work). SEE RULE 19.15.7.14 NMAC	pertinent details, and give C. For Multiple Complet	ions: Attach wellbore diagram of
<ol> <li>Describe proposed or co of starting any proposed</li> </ol>	work). SEE RULE 19.15.7.14 NMAC	ertinent details, and give 2. For Multiple Complet H - 3240'-1700' - WC	ions: Attach wellbore diagram of
<ol> <li>Describe proposed or co of starting any proposed proposed completion or</li> <li>Set 5 ½" CIBP @ 1446</li> </ol>	recompletion. Cement 1540' of C Set CIBP @ 1650' Dump bail 35 Circ hole w/ MLF. Pressure test cs	ertinent details, and give C. For Multiple Complet H - 3240'-1700' - WC cmt. WOC & Tag	ions: Attach wellbore diagram of DC & tag Run CBL to surface.
<ol> <li>Describe proposed or co of starting any proposed proposed completion or</li> <li>Set 5 ½" CIBP @ 1446</li> <li>Spot 25 sx cmt @ 1000</li> </ol>	recompletion. Cement 1540' of C Set CIBP @ 1650' Dump bail 35 '. Circ hole w/ MLF. Pressure test cs -610'. (San Andres & Grbg)	ertinent details, and give C. For Multiple Complet H - 3240'-1700' - WC cmt. WOC & Tag	ions: Attach wellbore diagram of C & tag
<ol> <li>Describe proposed or co of starting any proposed proposed completion or</li> <li>Set 5 ½" CIBP @ 1446</li> <li>Spot 25 sx cmt @ 1000</li> <li>Perf &amp; Sqz 50 sx cmt @</li> </ol>	<ul> <li>Work). SEE RULE 19.15.7.14 NMAC recompletion. Cement 1540' of C Set CIBP @ 1650' Dump bail 35</li> <li>For chole w/ MLF. Pressure test cs 6-610'. (San Andres &amp; Grbg)</li> <li>200' to surface.</li> </ul>	ertinent details, and give C. For Multiple Complet H - 3240'-1700' - WC C. Cont. WOC & Tag g. Perf & Sqz 70 sx @ 1	ions: Attach wellbore diagram of DC & tag Run CBL to surface.
<ol> <li>Describe proposed or co of starting any proposed proposed completion or</li> <li>Set 5 ½" CIBP @ 1446</li> <li>Spot 25 sx cmt @ 1000</li> <li>Perf &amp; Sqz 50 sx cmt @</li> </ol>	recompletion. Cement 1540' of C Set CIBP @ 1650' Dump bail 35 '. Circ hole w/ MLF. Pressure test cs -610'. (San Andres & Grbg)	ertinent details, and give C. For Multiple Complet H - 3240'-1700' - WC C. Cont. WOC & Tag g. Perf & Sqz 70 sx @ 1	ions: Attach wellbore diagram of DC & tag Run CBL to surface.
<ol> <li>Describe proposed or co of starting any proposed proposed completion or</li> <li>Set 5 ½" CIBP @ 1446</li> <li>Spot 25 sx cmt @ 1000</li> <li>Perf &amp; Sqz 50 sx cmt @</li> <li>Cut off well head, verifiered</li> </ol>	<ul> <li>Work). SEE RULE 19.15.7.14 NMAC recompletion. Cement 1540' of C Set CIBP @ 1650' Dump bail 35</li> <li>For chole w/ MLF. Pressure test cs 6-610'. (San Andres &amp; Grbg)</li> <li>200' to surface.</li> </ul>	ertinent details, and give For Multiple Complet H - 3240'-1700' - WC cmt. WOC & Tag g. Perf & Sqz 70 sx @ 1 Marker.	ions: Attach wellbore diagram of OC & tag Run CBL to surface. 1446-1148'. WOC & Tag (8 5/8 Shoe)
<ol> <li>Describe proposed or co of starting any proposed proposed completion or</li> <li>Set 5 ½" CIBP @ 1446</li> <li>Spot 25 sx cmt @ 1000</li> <li>Perf &amp; Sqz 50 sx cmt @</li> <li>Cut off well head, verifiered</li> </ol>	<ul> <li>Work). SEE RULE 19.15.7.14 NMAC recompletion. Cement 1540' of C</li> <li>Set CIBP @ 1650' Dump bail 35</li> <li>''. Circ hole w/ MLF. Pressure test cs</li> <li>''. Circ hole w/ MLF. Pressure test cs</li> <li>''. (San Andres &amp; Grbg)</li> <li>200' to surface.</li> <li>fy cmt @ surface, weld on Dry Hole I</li> </ul>	ertinent details, and give For Multiple Complet H - 3240'-1700' - WC cmt. WOC & Tag g. Perf & Sqz 70 sx @ 1 Marker.	ions: Attach wellbore diagram of OC & tag Run CBL to surface. 1446-1148'. WOC & Tag (8 5/8 Shoe)
<ol> <li>Describe proposed or co of starting any proposed proposed completion or</li> <li>Set 5 ½" CIBP @ 1446</li> <li>Spot 25 sx cmt @ 1000</li> <li>Perf &amp; Sqz 50 sx cmt @</li> <li>Cut off well head, verifiered</li> </ol>	<ul> <li>Work). SEE RULE 19.15.7.14 NMAC recompletion. Cement 1540' of C</li> <li>Set CIBP @ 1650' Dump bail 35</li> <li>''. Circ hole w/ MLF. Pressure test cs</li> <li>''. Circ hole w/ MLF. Pressure test cs</li> <li>''. (San Andres &amp; Grbg)</li> <li>200' to surface.</li> <li>fy cmt @ surface, weld on Dry Hole I</li> </ul>	ertinent details, and give For Multiple Complet H - 3240'-1700' - WC cmt. WOC & Tag g. Perf & Sqz 70 sx @ 1 Marker.	ions: Attach wellbore diagram of OC & tag Run CBL to surface. 1446-1148'. WOC & Tag (8 5/8 Shoe)
<ol> <li>Describe proposed or co of starting any proposed proposed completion or</li> <li>Set 5 ½" CIBP @ 1446</li> <li>Spot 25 sx cmt @ 1000</li> <li>Perf &amp; Sqz 50 sx cmt @</li> <li>Cut off well head, verifiered</li> </ol>	<ul> <li>Work). SEE RULE 19.15.7.14 NMAC recompletion. Cement 1540' of C</li> <li>Set CIBP @ 1650' Dump bail 35</li> <li>''. Circ hole w/ MLF. Pressure test cs</li> <li>''. Circ hole w/ MLF. Pressure test cs</li> <li>''. (San Andres &amp; Grbg)</li> <li>200' to surface.</li> <li>fy cmt @ surface, weld on Dry Hole I</li> </ul>	ertinent details, and give C. For Multiple Complet H - 3240'-1700' - WC cmt. WOC & Tag g. Perf & Sqz 70 sx @ 1 Marker. NOC & tag - T. Que	ions: Attach wellbore diagram of OC & tag Run CBL to surface. 1446-1148'. WOC & Tag (8 5/8 Shoe)
<ol> <li>Describe proposed or co of starting any proposed proposed completion or</li> <li>Set 5 ½" CIBP @ 1446</li> <li>Spot 25 sx cmt @ 1000</li> <li>Perf &amp; Sqz 50 sx cmt @</li> <li>Cut off well head, verif</li> </ol>	Work). SEE RULE 19.15.7.14 NMAC recompletion. Cement 1540' of C Set CIBP @ 1650' Dump bail 35 i'. Circ hole w/ MLF. Pressure test cs -610'. (San Andres & Grbg) @ 200' to surface. fy cmt @ surface, weld on Dry Hole I Perf & sqz 25 sx cmt at 357' - \ Rig Release Da	ertinent details, and give C. For Multiple Complet H - 3240'-1700' - WC cmt. WOC & Tag g. Perf & Sqz 70 sx @ 1 Marker. NOC & tag - T. Que te:	ions: Attach wellbore diagram of OC & tag Run CBL to surface. 1446-1148'. WOC & Tag (8 5/8 Shoe)
<ul> <li>13. Describe proposed or constraining any proposed proposed completion or</li> <li>1. Set 5 ½" CIBP @ 1446</li> <li>2. Spot 25 sx cmt @ 1000</li> <li>3. Perf &amp; Sqz 50 sx cmt @</li> <li>4. Cut off well head, verified</li> </ul>	Work). SEE RULE 19.15.7.14 NMAC recompletion. Cement 1540' of C Set CIBP @ 1650' Dump bail 35 ''. Circ hole w/ MLF. Pressure test cs -610'. (San Andres & Grbg) @ 200' to surface. fy cmt @ surface, weld on Dry Hole I Perf & sqz 25 sx cmt at 357' - \ Rig Release Da CHED COA's****	ertinent details, and give For Multiple Complet H - 3240'-1700' - WC cmt. WOC & Tag g. Perf & Sqz 70 sx @ 1 Marker. NOC & tag - T. Que te: Must be plugge	ions: Attach wellbore diagram of OC & tag Run CBL to surface. 1446-1148'. WOC & Tag (8 5/8 Shoe) een
<ul> <li>13. Describe proposed or coord of starting any proposed proposed completion or</li> <li>1. Set 5 ½" CIBP @ 1446</li> <li>2. Spot 25 sx cmt @ 1000</li> <li>3. Perf &amp; Sqz 50 sx cmt @</li> <li>4. Cut off well head, verified</li> <li>Spud Date:</li> </ul>	I work). SEE RULE 19.15.7.14 NMAC         recompletion.       Cement 1540' of C         Set CIBP @ 1650' Dump bail 35         ''. Circ hole w/ MLF. Pressure test cs         -610'. (San Andres & Grbg)         @ 200' to surface.         fy cmt @ surface, weld on Dry Hole I         Perf & sqz 25 sx cmt at 357' - N         Rig Release Da         CHED COA's****         ion above is true and complete to the be	ertinent details, and give For Multiple Complet H - 3240'-1700' - WC cmt. WOC & Tag g. Perf & Sqz 70 sx @ 1 Marker. NOC & tag - T. Que te: Must be plugge	ions: Attach wellbore diagram of OC & tag Run CBL to surface. 1446-1148'. WOC & Tag (8 5/8 Shoe) een
<ul> <li>13. Describe proposed or constraining any proposed proposed completion or</li> <li>1. Set 5 ½" CIBP @ 1446</li> <li>2. Spot 25 sx cmt @ 1000</li> <li>3. Perf &amp; Sqz 50 sx cmt @</li> <li>4. Cut off well head, verified</li> </ul>	I work). SEE RULE 19.15.7.14 NMAC         recompletion.       Cement 1540' of C         Set CIBP @ 1650' Dump bail 35         ''. Circ hole w/ MLF. Pressure test cs         '-610'. (San Andres & Grbg)         @ 200' to surface.         fy cmt @ surface, weld on Dry Hole I         Perf & sqz 25 sx cmt at 357' - N         Rig Release Da         CHED COA's****         ion above is true and complete to the be	ertinent details, and give For Multiple Complet H - 3240'-1700' - WC cmt. WOC & Tag g. Perf & Sqz 70 sx @ 1 Marker. NOC & tag - T. Que te: Must be plugge	ions: Attach wellbore diagram of OC & tag Run CBL to surface. 1446-1148'. WOC & Tag (8 5/8 Shoe) een
<ul> <li>13. Describe proposed or coord of starting any proposed proposed completion or</li> <li>1. Set 5 ½" CIBP @ 1446</li> <li>2. Spot 25 sx cmt @ 1000</li> <li>3. Perf &amp; Sqz 50 sx cmt @</li> <li>4. Cut off well head, verified</li> <li>Spud Date:</li> </ul>	I work). SEE RULE 19.15.7.14 NMAC         recompletion.       Cement 1540' of C         Set CIBP @ 1650' Dump bail 35         i'. Circ hole w/ MLF. Pressure test cs         -610'. (San Andres & Grbg)         @ 200' to surface.         fy cmt @ surface, weld on Dry Hole I         Perf & sqz 25 sx cmt at 357' - \         Rig Release Da         CHED COA's****         ion above is true and complete to the be         Coust       TITLE Regulation	ertinent details, and give For Multiple Complet H - 3240'-1700' - WC cmt. WOC & Tag g. Perf & Sqz 70 sx @ 1 Marker. NOC & tag - T. Que te: Must be plugge st of my knowledge and atory Technician I	ions: Attach wellbore diagram of DC & tag Run CBL to surface. 1446-1148'. WOC & Tag (8 5/8 Shoe) een ed by 2/17/2023 belief. DATE 2/10/2022 E7E 749 1299
<ul> <li>13. Describe proposed or coord of starting any proposed proposed completion or</li> <li>1. Set 5 ½" CIBP @ 1446</li> <li>2. Spot 25 sx cmt @ 1000</li> <li>3. Perf &amp; Sqz 50 sx cmt @</li> <li>4. Cut off well head, verified</li> <li>Spud Date:</li> </ul>	I work). SEE RULE 19.15.7.14 NMAC         recompletion.       Cement 1540' of C         Set CIBP @ 1650' Dump bail 35         i'. Circ hole w/ MLF. Pressure test cs         -610'. (San Andres & Grbg)         @ 200' to surface.         fy cmt @ surface, weld on Dry Hole I         Perf & sqz 25 sx cmt at 357' - \         Rig Release Da         CHED COA's****         ion above is true and complete to the be         Coust       TITLE Regulation	ertinent details, and give For Multiple Complet H - 3240'-1700' - WC cmt. WOC & Tag g. Perf & Sqz 70 sx @ 1 Marker. NOC & tag - T. Que te: Must be plugge st of my knowledge and	ions: Attach wellbore diagram of DC & tag Run CBL to surface. 1446-1148'. WOC & Tag (8 5/8 Shoe) een een ed by 2/17/2023 belief. 
<ul> <li>13. Describe proposed or coord of starting any proposed proposed completion or</li> <li>1. Set 5 ½" CIBP @ 1446</li> <li>2. Spot 25 sx cmt @ 1000</li> <li>3. Perf &amp; Sqz 50 sx cmt @</li> <li>4. Cut off well head, verified</li> <li>Spud Date:</li> <li>****SEE ATTAC</li> <li>I hereby certify that the information of the second seco</li></ul>	I work). SEE RULE 19.15.7.14 NMAC         recompletion.       Cement 1540' of C         Set CIBP @ 1650' Dump bail 35         i'. Circ hole w/ MLF. Pressure test cs         -610'. (San Andres & Grbg)         @ 200' to surface.         fy cmt @ surface, weld on Dry Hole I         Perf & sqz 25 sx cmt at 357' - V         Rig Release Da         CHED COA's****         ion above is true and complete to the be         Versa       TITLE Regulation         res       E-mail address	ertinent details, and give For Multiple Complet H - 3240'-1700' - WC cmt. WOC & Tag g. Perf & Sqz 70 sx @ 1 Marker. NOC & tag - T. Que te: Must be plugge st of my knowledge and atory Technician I	ions: Attach wellbore diagram of C & tag Run CBL to surface. 1446-1148'. WOC & Tag (8 5/8 Shoe) een een ed by 2/17/2023 belief. DATE_2/10/2022 PHONE: 575-748-1288 0/47/0000

•

# CONDITIONS FOR PLUGGING AND ABANDONMENT

## OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E)Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K)Potash---(In the R-111-P Area (Page 3 & 4), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

## DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name2. Lease and Well Number3. API Number4. Unit Letter5. QuarterSection (feet from the North, South, East or West)6. Section, Township and Range7. Plugging Date8. County(SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

### SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

# R-111-P Area

### T 18S – R 30E

Sec 10 Unit P. Sec 11 Unit M,N. Sec 13 Unit L,M,N. Sec 14 Unit C -P. Sec 15 Unit A G,H,I,J,K,N,O,P. Sec 22 Unit All except for M. Sec 23, Sec 24 Unit C,D,E,L, Sec 26 Unit A-G, Sec 27 Unit A,B,C

### T 19S – R 29E

Sec 11 Unit P. Sec 12 Unit H-P. Sec 13. Sec 14 Unit A,B,F-P. Sec 15 Unit P. Sec 22 Unit A,B,C,F,G,H,I,J K,N,O,P. Sec 23. Sec 24. Sec 25 Unit D. Sec 26 Unit A- F. Sec 27 Unit A,B,C,F,G,H.

### T 19S – R 30E

Sec 2 Unit K,L,M,N. Sec 3 Unit I,L,M,N,O,P. Sec 4 Unit C,D,E,F,G,I-P. Sec 5 Unit A,B,C,E-P. Sec 6 Unit I,O,P. Sec 7 – Sec 10. Sec 11 Unit D, G—P. Sec 12 Unit A,B,E-P. Sec 13 Unit A-O. Sec 14-Sec 18. Sec 19 Unit A-L, P. Sec 20 – Sec 23. Sec 24 Unit C,D,E,F,L,M,N. Sec 25 Unit D. Sec 26 Unit A-G, I-P. Sec 27, Sec 28, Sec 29 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 32 Unit A,B,G,H,I,J,N,O,P. Sec 33. Sec 34. Sec 35. Sec 36 Unit D,E,F,I-P.

### T 19S – R 31E

Sec 7 Unit C,D,E,F,L. Sec 18 Unit C,D,E,F,G,K,L. Sec 31 Unit M. Sec 34 Unit P. Sec 35 Unit M,N,O. Sec 36 Unit O,P.

### T 20S – R 29E

Sec 1 Unit H,I,P. Sec 13 Unit E,L,M,N. Sec 14 Unit B-P. Sec 15 Unit A,H,I,J,N,O,P. Sec 22 Unit A,B,C,F,G,H,I,J,O,P. Sec 23. Sec 24 Unit C,D,E,F,G,J-P. Sec 25 Unit A-O. Sec 26. Sec 27 Unit A,B,G,H,I,J,O,P. Sec 34 Unit A,B,G,H. Sec 35 Unit A-H. Sec 36 Unit B-G.

### T 20S – R 30E

Sec 1 – Sec 4. Sec 5 Unit A,B,C,E-P. Sec 6 Unit E,G-P. Sec 7 Unit A-H,I,J,O,P. Sec 8 – 17. Sec 18 Unit A,B,G,H,I,J,O,P. Sec 19 Unit A,B,G,H,I,J,O,P. Sec 20 – 29. Sec 30 Unit A-L,N,O,P. Sec 31 Unit A,B,G,H,I,P. Sec 32 – Sec 36.

### T 20S – R 31E

Sec 1 Unit A,B,C,E-P. Sec 2. Sec 3 Unit A,B,G,H,I,J,O,P. Sec 6 Unit D,E,F,J-P. Sec 7. Sec 8 Unit E-P. Sec 9 Unit E,F,J-P. Sec 10 Unit A,B,G-P. Sec 11 – Sec 36.

### T 21S – R 29E

Sec 1 – Sec 3. Sec 4 Unit L1 – L16,I,J,K,O,P. Sec 5 Unit L1. Sec 10 Unit A,B,H,P. Sec 11 – Sec 14. Sec 15 Unit A,H,I. Sec 23 Unit A,B. Sec 24 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 25 Unit A,O,P. Sec 35 Unit G,H,I,J,K,N,O,P. Sec 36 A,B,C,F – P.

### T 21S – R 30E

Sec 1 – Sec 36

### T 21S – R 31E

Sec 1 – Sec 36

### T 22S – R 28E

Sec 36 Unit A,H,I,P.

### T 22S – R 29E

Sec 1. Sec2. Sec 3 Unit I,J,N,O,P. Sec 9 Unit G – P. Sec 10 – Sec 16. Sec 19 Unit H,I,J. Sec 20 – Sec 28. Sec 29 Unit A,B,C,D,G,H,I,J,O,P. Sec 30 Unit A. Section 31 Unit C – P. Sec 32 – Sec 36

### T 22S – R 30E

Sec 1 – Sec 36

### T 22S – R 31E

Sec 1 – Sec 11. Sec 12 Unit B,C,D,E,F,L. Sec 13 Unit E,F,K,L,M,N. Sec 14 – Sec 23. Sec 24 Unit C,D,E,F,K,L,M,N. Sec 25 Unit A,B,C,D. Sec 26 Unit A,B,C,D,G,H. Sec 27 – Sec 34.

### T 23S – R 28E

Sec 1 Unit A

### T 23S – R 29E

Sec 1 – Sec 5. Sec 6 Unit A – I, N,O,P. Sec 7 Unit A,B,C,G,H,I,P. Sec 8 Unit A – L, N,O,P. Sec 9 – Sec 16. Sec 17 Unit A,B,G,H,I,P. Sec 21 – Sec 23. Sec 24 Unit A – N. Sec 25 Unit D,E,L. Sec 26. Sec 27. Sec 28 Unit A – J, N,O,P. Sec 33 Unit A,B,C. Sec 34 Unit A,B,C,D,F,G,H. Sec 35. Sec 36 Unit B,C,D,E,F,G,K,L.

### T 23S – R 30E

Sec 1 – Sec 18. Sec 19 Unit A – I,N,O,P. Sec 20, Sec 21. Sec 22 Unit A – N, P. Sec 23, Sec 24, Sec 25. Sec 26 Unit A,B,F-P. Sec 27 Unit C,D,E,I,N,O,P. Sec 28 Unit A – H, K,L,M,N. Sec 29 Unit A – J, O,P. Sec 30 Unit A,B. Sec 32 A,B. Sec 33 Unit C,D,H,I,O,P. Sec 34, Sec 35, Sec 36.

### T 23S – R 31E

Sec 2 Unit D,E,J,O. Sec 3 – Sec 7. Sec 8 Unit A – G, K – N. Sec 9 Unit A,B,C,D. Sec 10 Unit D,P. Sec 11 Unit G,H,I,J,M,N,O,P. Sec 12 Unit E,L,K,M,N. Sec 13 Unit C,D,E,F,G,J,K,L,M,N,O. Sec 14. Sec 15 Unit A,B,E – P. Sec 16 Unit I, K – P. Sec 17 Unit B,C,D,E, I – P. Sec 18 – Sec 23. Sec 24 Unit B – G, K,L,M,N. Sec 25 Unit B – G, J,K,L. Sec 26 – Sec 34. Sec 35 Unit C,D,E.

### T 24S – R 29E

Sec 2 Unit A, B, C, D. Sec 3 Unit A

### T 24S – R 30E

Sec 1 Unit A – H, J – N. Sec 2, Sec 3. Sec 4 Unit A,B,F – K, M,N,O,P. Sec 9 Unit A – L. Sec 10 Unit A – L, O,P. Sec 11. Sec 12 Unit D,E,L. Sec 14 Unit B – G. Sec 15 Unit A,B,G,H.

### T 24S – R 31E

Sec 3 Unit B – G, J – O. Sec 4. Sec 5 Unit A – L, P. Sec 6 Unit A – L. Sec 9 Unit A – J, O,P. Sec 10 Unit B – G, K – N. Sec 35 Unit E – P. Sec 36 Unit E,K,L,M,N.

### T 25S – R 31E

Sec 1 Unit C,D,E,F. Sec 2 Unit A – H.

Received by OCD: 2/1	10/2022	2 9:58:11 AM	N			Spud Date 12/8	y Pool	Author: Abby ( Well Name Simps	od Ope
	•••••					12/8/2008 GL:	ő	Abby @ BCM Simpson 15 B We	
	Open Hole to 3240'.	2 7/8" tbg @ 3164'	5 1/2 14#	Perfs @ 1496-1683'	8 5/8 24# Hole Size:	330 FIVE & 1000 F EE	<u> </u>	Well No. #134	CURRENT
			CSG @ 1,700		CSG @1,198 11	43	-00281 18S, R26E	34	
							Prod Csg	Surface Csg	Description
							5 1/2	8 5/8	O.D. Grade
							14#	24#	Weight
zv							1,700 7 7/8	1,198 11	Depth Hole
Z:VAbbyWellbore Diagrams/2 STRING BLANK WBD Released to Imaging:		32.7542572 -104.3664703			Queen GRBG San Andres Glorieta Yeso	Formation	/8 130	500	le Cmt Sx
RING BLANK WBD Released to Imaging:	3/7/20	22 11:29:49 AN	1		307 948 2269 2394	Top	900	0	TOC

2 7/8" tbg @ 3164' Open Hole to 324		Perfs @	1.Set 5 ½	3. Perf &	State New Mexico Spud Date <u>12/8/2008</u> GL:	Field/Pool     Atoka; Glorieta-Yeso     API #:       County     Eddy     Location:	Author: Abby @ BCM Well Name Simpson 15 B Well No.	Redwood Operating
2 7/8" tbg @ 3164' Open Hole to 3240'.	5 1/2 14# CSG @ 1,700	Perfs @ 1496-1683'	8 5/8 24# CSG @ 1,198 Hole Size: 11 1.Set 5 ½" CIBP @ 1446'. Circ hole w/ MLF. Pressure test csg. WOC & Tag (8 5/8 Shoe)	3. Perf & Sqz 50 sx cmt @ 200' to surface. 2. Spot 25 sx cmt @ 1000-610'. (San Andres & Grbg)	330 FNL & 1650 FEL 3343	30-015-00281 Sec 15, T18S, R26E	#134	PROPOSED
			.F. Pressure test cs	». res & Grbg)		Prod Csg 5	Surface Csg 8	Description C
						5 1/2	8 5/8	O.D. Grade
			Perf & Sqz 70 sx @ 1446-1148'.			14#	24#	le Weight
			@ 1446			1,700	1,198	Depth
			-1148'.			7 7/8	1	Hole
32.7542572 -104.3664703				Queen GRBG San Andres Glorieta Yeso	Formation	130	500	Cmt Sx
				307 669 948 2269 2394	Top	006	0	TOC

•

District I 1625 N. French Dr., Hobbs, NM 88240 Phone:(575) 393-6161 Fax:(575) 393-0720 District II

811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III

1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

District IV 1220 S. St Francis Dr., Santa Fe, NM 87505 Phone: (505) 476-3470 Fax: (505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. Santa Fe, NM 87505

CONDITIONS

Operator:	OGRID:
Redwood Operating LLC	330211
PO Box 1370	Action Number:
Artesia, NM 88210	80588
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### CONDITIONS

Created By		Condition Date
gcordero	None	2/17/2022

Page 8 of 8

Action 80588