

U.S. Department of the Interior BUREAU OF LAND MANAGEMENT Sundry Print Report

Well Name: MESA 8105 JV-P Well Location: T26S / R32E / SEC 1 / County or Parish/State: LEA /

NESE /

Well Number: 01 Type of Well: CONVENTIONAL GAS Allottee or Tribe Name:

WELI

Lease Number: NMNM14492 Unit or CA Name: **Unit or CA Number:** 

**US Well Number: 3002527600** Well Status: Producing Gas Well Operator: BTA OIL

PRODUCERS LLC

#### **Notice of Intent**

Sundry ID: 2691154

Type of Submission: Notice of Intent Type of Action: Plug and Abandonment

Date Sundry Submitted: 09/07/2022 Time Sundry Submitted: 01:34

Date proposed operation will begin: 09/28/2022

Procedure Description: Proposed plan to P&A the subject well as follows: MIRU Plugging Rig and Equipment. Blowdown well. NDWH. NUBOP. RIH with workstring to tag TOC @ 9865' on top of CIBP set @ 9900'. PU and circulate hole with 9.5 PPG MLF. Pressure test casing to 500 PSI. Pump 50 sx Class H cmt @ 9060' - 8960'. (T/Bone Spring) Perforate and squeeze 75 sx Class C cmt @ 6061'. Displace to 5961'. WOC & Tag. (DV Tool) Perforate and squeeze 240 sx Class C cmt @ 4844'. Displace to 4421'. WOC & Tag. (10-3/4" Csg shoe & B/Salt) Perforate and squeeze 335 sx Class C cmt @ 1450'. Displace to 850'. WOC & Tag. (T/Salt & 16" Csg shoe) Perforate and squeeze 130 sx Class C cmt @ 100'. Circulate cmt to surface. NDBOP. Dig out and cut off wellhead to 3' below grade. Confirm cement to surface in all casings. Install cap and well marker.

Approval Subject to

General Requirements and

**Special Stipulations** 

Attached

# **Surface Disturbance**

Is any additional surface disturbance proposed?: No

### **NOI Attachments**

# **Procedure Description**

WBD\_Mesa\_1\_Proposed\_Plugging\_20220907133408.pdf

WBD\_Mesa\_1\_Current\_WBD\_20220907133359.pdf

eceived by OCD: 4/11/2023 4:26:45 PM Well Name: MESA 8105 JV-P

Well Location: T26S / R32E / SEC 1 /

NESE /

County or Parish/State: LEA/ 2 of

NM

Well Number: 01

Type of Well: CONVENTIONAL GAS

Allottee or Tribe Name:

Lease Number: NMNM14492

**Unit or CA Name:** 

**Unit or CA Number:** 

**US Well Number: 3002527600** 

Well Status: Producing Gas Well

Operator: BTA OIL PRODUCERS LLC

# **Operator**

I certify that the foregoing is true and correct. Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction. Electronic submission of Sundry Notices through this system satisfies regulations requiring a

Operator Electronic Signature: BOB HALL Signed on: SEP 07, 2022 01:34 PM

Name: BTA OIL PRODUCERS LLC

Title: Environmental Manager Street Address: 104 S PECOS

City: MIDLAND State: TX

Phone: (432) 682-3753

Email address: BHALL@BTAOIL.COM

## **Field**

**Representative Name:** 

**Street Address:** 

City:

State:

Zip:

Phone:

**Email address:** 

# PLUG AND ABANDONMENT CONDITIONS OF APPROVAL

<b>OPERATOR'S NAME:</b>	BTA Oil Producers LLC
LEASE NO.:	NMNM14492
WELL NAME & NO.:	Mesa 8105 JV-P
<b>US Well Number:</b>	3002527600
LOCATION:	Section 1, T.26 S., R.32 E., NMPM
COUNTY:	Lea County, New Mexico
Sundry ID:	2691154
Karst:	□Low ⊠Medium □High □Critical
Potash:	□Secretary □R111P
Special Area:	□Prairie Chicken □Capitan Reef

Proposed plan to P&A the subject well as follows:

MIRU Plugging Rig and Equipment. Blowdown well. NDWH. NUBOP.

RIH with workstring to tag TOC @ 9865' on top of CIBP set @ 9900'.

PU and circulate hole with 9.5 PPG MLF.

Pressure test casing to 500 PSI. Pump 25 sx Class H on top of CIBP.

Pump 50Perforate and attempt squeeze 80 sx Class H cmt @-9334' to 9141' 9060' - 8960'. (T/Bone Spring) WOC and Tag. (In/Out)

Perforate and squeeze 75 sx Class C cmt @ 6061'. Displace <u>balance</u> to-<u>5900'5961'</u>. WOC & Tag. (DV Tool)

Perforate and squeeze  $\frac{240}{155}$  sx Class C cmt @  $\frac{4844'4855'}{4855'}$ . Displace to  $\frac{4421'4437'}{4437'}$ . WOC & Tag. (10-3/4" Csg shoe & B/Salt)

Perforate and squeeze 335-515 sx Class C cmt @ 1450'1440' to surface. Displace to 850'. WOC & Tag. (T/Salt & 16" Csg shoe) (In/Out) Verify at surface.

Perforate and squeeze 130 sx Class C cmt @ 100'. Circulate cmt to surface.


-Spot 1" from surface to 200'. (Cement across all annuluses). Verify at surface.


NDBOP. Dig out and cut off wellhead to 3' below grade. Confirm cement to surface in all casings.

Install cap and well marker.

# **Approval Subject to General Requirements and Special Stipulations Attached**

- No more than 3000 feet between cement plugs in cased hole.
- Wait on Cement and Tag Top of Cement Requirement:
  - 1. Shoe, Top of Salt, Base of Salt, DV tool, Perforate and Squeeze, Open Perforation.
  - 2. Formation plug is optional if a solid base is established and confirmed.





**Sundry ID** 2691154

Sunary ID	2691154	T	1		1	1
	_			_		
Plug Type	Тор	Bottom	Length	Tag	Sacks	Notes
						Spot 1" from surface
						to 200' at surface.
						(Cement across all
						annulus). Verify at
Surface Plug	0.00			Tag/Verify	100.00	surface.
Fresh Water @ 804	745.96			If solid base no		
Shoe Plug	858.82	968.00	109.18	Tag/Verify		
						Perf and squeeze at
						1440' to surface.
						Verify at surface.
Top of Salt @ 1143	1081.57	1440.00	358.43	Tag/Verify	515.00	(In/Out)
Base of Salt @ 4533	4437.67	4583.00	145.33	Tag/Verify		
Shoe Plug	4696.06	4844.00		Tag/Verify		
				If solid base no		
				need to Tag		
				(CIBP present		
				and/or		
				Mechanical		
				Integrity Test),		
				If Perf & Sqz		
				then Tag, Leak		Perf and Squeeze at
				Test all CIBP if		4855' to 4437'.
				no Open		(In/Out) Class C.
Delaware @ 4805	4706.95	4855.00		Perforations	155.00	WOC and Tag.
						Spot from 6061' to
						5900'. WOC and
DV tool plug	5900.89	6061.00	160.11	Tag/Verify	32.00	Tag. Class C.
	3333.33	0001100		1 - 1.9, 1 - 1 - 1.7		- agr chare or
				If solid base no		
				need to Tag		
				(CIBP present		
				and/or		
				Mechanical		
				Integrity Test),		
						Porf and attempt
				If Perf & Sqz		Perf and attempt
				then Tag, Leak		squeeze from 9334'
				Test all CIBP if		to 9141'. WOC and
n	0444.40	000465		no Open	00.00	Tag. Class H.
Bonesprings @ 9284	9141.16	9334.00	192.84	Perforations	80.00	(In/Out)

				If solid base no		
				need to Tag		
				(CIBP present		
				and/or		
				Mechanical		
				Integrity Test),		
				If Perf & Sqz		
				then Tag, Leak		Tag CIBP at 9865'.
				Test all CIBP if		Leak test CIBP and
				no Open		spot 25 sx on top.
CIBP Plug	9830.00	9865.00	35.00	Perforations	25.00	Class H.
Shoe Plug	12820.00	13050.00	230.00	Tag/Verify		

No more than 2000' is to be allowed between plugs in open hole, and no more than 3000' between plugs in cased hole.

Class H >7500'

Class C<7500'

Fluid used to mix the cement in R111P shall be saturated with the salts common to the section penetrated, and in suitable proportions, but not more than 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible.

Medium, Secretary: Top of salt to surface If no salt take the deepest fresh water or Karst Depth

High, Critical: Bottom of Karst to surface or Deepest fresh water, whichever is greater

R111P: 50 Feet from Base of Salt to surface.

Class C: 1.32 ft^3/sx Class H: 1.06 ft^3/sx

Onshore Order 2.III.G Drilling Abandonment Requirements: "All formations bearing usable-quality water, oil, gas, or geothermal resources, and/or a prospectively valuable deposit of minerals shall be protected.

Cave Karst/Potash Cement	Medium	Top of Salt to surface		
Shoe @ Shoe @	918.00 4794.00	тос @	750.00	
Shoe @	13000.00	тос @	5470 and 9865	

DV Tool @ 6011.00 CIBP @ 9865.00

# BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

# Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90<sup>th</sup> day provide this office, prior to the 90<sup>th</sup> day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

- 2. <u>Notification:</u> Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-689-5981.
- 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.
- 5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. **Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.** 

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. <u>Dry Hole Marker</u>: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10<sup>th</sup> day, the BLM is to be contacted with justification to receive an extension for completing the cut off.

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds). A weep hole shall be left if a metal plate is welded in place.

- 7. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**
- 8. <u>Trash:</u> All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation objectives.



# **United States Department of the Interior**

#### BUREAU OF LAND MANAGEMENT

Carlsbad Field Office 620 E. Greene St. Carlsbad, New Mexico 88220-6292 www.blm.gov/nm



In Reply Refer To: 1310

#### **Reclamation Objectives and Procedures**

**Reclamation Objective:** Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its predisturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any/all contaminants, scrap/trash, equipment, pipelines and powerlines (Contact service companies, allowing plenty of time to have the risers and power lines and poles removed prior to reclamation, don't wait till the last day and try to get them to remove infrastructure). Strip and remove caliche, contour the location to blend with the surrounding landscape, re-distribute the native soils, provide erosion control as needed, rip (across the slope and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

- 1. The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No. 1.
- 2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
- 3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
- 4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you

have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.

- 5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
- 6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
- 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Jim Amos Supervisory Petroleum Engineering Tech/Environmental Protection Specialist 575-234-5909 (Office), 575-361-2648 (Cell)

Arthur Arias Environmental Protection Specialist 575-234-6230

Crisha Morgan Environmental Protection Specialist 575-234-5987

Jose Martinez-Colon Environmental Protection Specialist 575-234-5951

Mark Mattozzi Environmental Protection Specialist 575-234-5713

Robert Duenas Environmental Protection Specialist 575-234-2229

Trishia Bad Bear, Hobbs Field Station Natural Resource Specialist 575-393-3612

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720 District II

811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720 District III

1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

COMMENTS

Action 206517

#### **COMMENTS**

Operator:	OGRID:
BTA OIL PRODUCERS, LLC	260297
104 S Pecos	Action Number:
Midland, TX 79701	206517
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### COMMENTS

Created B	Comment	Comment Date
plmartin	DATA ENTRY PM	4/12/2023

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720 District II

811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720 District III

1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

CONDITIONS

Action 206517

#### **CONDITIONS**

Operator:	OGRID:
BTA OIL PRODUCERS, LLC	260297
104 S Pecos	Action Number:
Midland, TX 79701	206517
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### CONDITIONS

Created By		Condition Date
kfortner	Like approval from BLM	4/12/2023