
ceived by OCD: 5/25/2023 11:27:35	AM				Page 1
Submit 1 Copy To Appropriate District Office	State of New Me	exico		Forn	n C-103
District I - (575) 393-6161	Energy, Minerals and Natu	ural Resources		Revised Augu	
1625 N. French Dr., Hobbs, NM 88240 <u>District II</u> – (575) 748-1283			WELL API NO.		
811 S. First St., Artesia, NM 88210 <u>District III</u> – (505) 334-6178	OIL CONSERVATION		30-025-27181		
1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Fran		5. Indicate Type	of Lease	
District IV - (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM	Santa Fe, NM 8	7505		X FEE	
87505			6. State Oil & Ga	as Lease No.	
SUNDRY NOTIC	CES AND REPORTS ON WELLS	3	7. Lease Name o	r Unit Agreement	Name
(DO NOT USE THIS FORM FOR PROPOS DIFFERENT RESERVOIR LISE "APPLIC	ALS TO DRILL OR TO DEEPEN OR PLATION FOR PERMIT" (FORM C. 101) FOR	UG BACK TO A			
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)			New Mexico "B'		
	as Well Other		8. Well Number	001	
2. Name of Operator	· LTD C		9. OGRID Numb	er	
3. Address of Operator	prises, LTD. Co.		149538		
	dow, Denton, TX 76210		10. Pool name or Wildcat Vacuum; Atoka-Morrow North		
4. Well Location	10 W, Deliton, 17 70210		vacuum; Atoka-N	AOITOW NORTH	
Unit Letter H :	1080 foot from the N				
Section 3	1980feet from theNort		660feet from		line
Section 3		Range 34E	NMPM Lea	County	
	11. Elevation (Show whether DR,	RKB, RT, GR, etc.,			
PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING DOWNHOLE COMMINGLE 13. Describe proposed or completion of starting any proposed word proposed completion or recompletion or recompletion or recompletion.	PLUG AND ABANDON XX CHANGE PLANS	REMEDIAL WORK COMMENCE DRI CASING/CEMENT OTHER: Detrinent details, and	SEQUENT REF	PORT OF: ALTERING CASI P AND A	ated date
4" Diameter 4' tall above gro	SEE ATTA		ned conditions	of approval	
I hereby certify that the information al	ove is true and complete to the be	st of my knowledge	and belief.		
SIGNATURE	TITLE OW	K.	DA	TE_ 2-21-7	13
Type or print name Kevin Jo For State Use Only APPROVED BY: Conditions of Approval (if	E-mail address:	Kpj12608	2gmail on PHO	DNE: 405-517	8688
APPROVED BY: Conditions of Approval (if	Fortner_TITLE	impliance of	fficer A AT	TE_5/25/23	

Proposed Plugging Procedures Asher Enterprises, LTD CO New Mexico B State #1 30-025-27181

Run CBL if one does not exist

- 1. Tag existing CIBP at 8500'. Circulate MLF and test casing to 500#. Spot 25 sx Class H cement on top of CIPB.
- 2. Perforate at 6550' and squeeze with 40 sx Class H cement. WOC and tag.
- 3. Perforate at 4719' and squeeze with 40 sx Class C. WOC and tag. Top Queen
- 4. Perforate at 4450' and squeeze with 40 sx. WOC and tag above 4350'. Intermediate Shoe
- 5. Perforate at 3593' and squeeze with 40 sx. WOC and tag. Base Salt & Top Yates
- 6. Perforate at 2340' and squeeze with 40 sx. WOC and tag. Top Salt
- 7. Perforate at 565'. Check for good communication at intermediate ad surface heads. Squeeze with 75 sx. WOC and tag.
- 8. Perforate at 150'. Circulate cement to surface in/out 5 1/2" x 8 5/8" and 8 5/8" x 13 3/8". Approx. 90 sx
- 9. Remove wellhead and ensure cement is to surface in all strings of casing. Install marker.



CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - 1) Glorieta
 - J) Yates.
 - K) Cherry Canyon Eddy County
 - L) Potash---(In the R-111-P Area (Page 3 & 4), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

R-111-P Area

T 18S - R 30E

Sec 10 Unit P. Sec 11 Unit M,N. Sec 13 Unit L,M,N. Sec 14 Unit C -P. Sec 15 Unit A G,H,I,J,K,N,O,P. Sec 22 Unit All except for M. Sec 23, Sec 24 Unit C,D,E,L, Sec 26 Unit A-G, Sec 27 Unit A,B,C

T 19S - R 29E

Sec 11 Unit P. Sec 12 Unit H-P. Sec 13. Sec 14 Unit A,B,F-P. Sec 15 Unit P. Sec 22 Unit A,B,C,F,G,H,I,J K,N,O,P. Sec 23. Sec 24. Sec 25 Unit D. Sec 26 Unit A-F. Sec 27 Unit A,B,C,F,G,H.

T 19S - R 30E

Sec 2 Unit K,L,M,N. Sec 3 Unit I,L,M,N,O,P. Sec 4 Unit C,D,E,F,G,I-P. Sec 5 Unit A,B,C,E-P. Sec 6 Unit I,O,P. Sec 7 – Sec 10. Sec 11 Unit D, G—P. Sec 12 Unit A,B,E-P. Sec 13 Unit A-O. Sec 14-Sec 18. Sec 19 Unit A-L, P. Sec 20 – Sec 23. Sec 24 Unit C,D,E,F,L,M,N. Sec 25 Unit D. Sec 26 Unit A-G, I-P. Sec 27, Sec 28, Sec 29 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 32 Unit A,B,G,H,I,J,N,O,P. Sec 33. Sec 34. Sec 35. Sec 36 Unit D,E,F,I-P.

T 19S - R 31E

Sec 7 Unit C,D,E,F,L. Sec 18 Unit C,D,E,F,G,K,L. Sec 31 Unit M. Sec 34 Unit P. Sec 35 Unit M,N,O. Sec 36 Unit O,P.

T 20S - R 29E

Sec 1 Unit H,I,P. Sec 13 Unit E,L,M,N. Sec 14 Unit B-P. Sec 15 Unit A,H,I,J,N,O,P. Sec 22 Unit A,B,C,F,G,H,I,J,O,P. Sec 23. Sec 24 Unit C,D,E,F,G,J-P. Sec 25 Unit A-O. Sec 26. Sec 27 Unit A,B,G,H,I,J,O,P. Sec 34 Unit A,B,G,H. Sec 35 Unit A-H. Sec 36 Unit B-G.

T 20S - R 30E

Sec 1 – Sec 4. Sec 5 Unit A,B,C,E-P. Sec 6 Unit E,G-P. Sec 7 Unit A-H,I,J,O,P. Sec 8 – 17. Sec 18 Unit A,B,G,H,I,J,O,P. Sec 19 Unit A,B,G,H,I,J,O,P. Sec 30 Unit A-L,N,O,P. Sec 31 Unit A,B,G,H,I,P. Sec 32 – Sec 36.

T 20S - R 31E

Sec 1 Unit A,B,C,E-P. Sec 2. Sec 3 Unit A,B,G,H,I,J,O,P. Sec 6 Unit D,E,F,J-P. Sec 7. Sec 8 Unit E-P. Sec 9 Unit E,F,J-P. Sec 10 Unit A,B,G-P. Sec 11 – Sec 36.

T 21S - R 29E

Sec 1 – Sec 3. Sec 4 Unit L1 – L16,I,J,K,O,P. Sec 5 Unit L1. Sec 10 Unit A,B,H,P. Sec 11 – Sec 14. Sec 15 Unit A,H,I. Sec 23 Unit A,B. Sec 24 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 25 Unit A,O,P. Sec 35 Unit G,H,I,J,K,N,O,P. Sec 36 A,B,C,F – P.

T 21S - R 30E

Sec 1 – Sec 36

T 21S - R 31E

Sec 1 – Sec 36

T 22S - R 28E

Sec 36 Unit A,H,I,P.

T 22S - R 29E

Sec 1. Sec2. Sec 3 Unit I,J,N,O,P. Sec 9 Unit G – P. Sec 10 – Sec 16. Sec 19 Unit H,I,J. Sec 20 – Sec 28. Sec 29 Unit A,B,C,D,G,H,I,J,O,P. Sec 30 Unit A. Section 31 Unit C – P. Sec 32 – Sec 36

T 22S - R 30E

Sec 1 – Sec 36

T 22S - R 31E

Sec 1 – Sec 11. Sec 12 Unit B,C,D,E,F,L. Sec 13 Unit E,F,K,L,M,N. Sec 14 – Sec 23. Sec 24 Unit C,D,E,F,K,L,M,N. Sec 25 Unit A,B,C,D. Sec 26 Unit A,BC,D,G,H. Sec 27 – Sec 34.

T 23S - R 28E

Sec 1 Unit A

T 23S - R 29E

Sec 1 – Sec 5. Sec 6 Unit A – I, N,O,P. Sec 7 Unit A,B,C,G,H,I,P. Sec 8 Unit A – L, N,O,P. Sec 9 – Sec 16. Sec 17 Unit A,B,G,H,I,P. Sec 21 – Sec 23. Sec 24 Unit A – N. Sec 25 Unit D,E,L. Sec 26. Sec 27. Sec 28 Unit A – J, N,O,P. Sec 33 Unit A,B,C. Sec 34 Unit A,B,C,D,F,G,H. Sec 35. Sec 36 Unit B,C,D,E,F,G,K,L.

T 23S - R 30E

Sec 1 – Sec 18. Sec 19 Unit A – I,N,O,P. Sec 20, Sec 21. Sec 22 Unit A – N, P. Sec 23, Sec 24, Sec 25. Sec 26 Unit A,B,F-P. Sec 27 Unit C,D,E,I,N,O,P. Sec 28 Unit A – H, K,L,M,N. Sec 29 Unit A – J, O,P. Sec 30 Unit A,B. Sec 32 A,B. Sec 33 Unit C,D,H,I,O,P. Sec 34, Sec 35, Sec 36.

T 23S - R 31E

Sec 2 Unit D,E,J,O. Sec 3 – Sec 7. Sec 8 Unit A – G, K – N. Sec 9 Unit A,B,C,D. Sec 10 Unit D,P. Sec 11 Unit G,H,I,J,M,N,O,P. Sec 12 Unit E,L,K,M,N. Sec 13 Unit C,D,E,F,G,J,K,L,M,N,O. Sec 14. Sec 15 Unit A,B,E – P. Sec 16 Unit I, K – P. Sec 17 Unit B,C,D,E, I – P. Sec 18 – Sec 23. Sec 24 Unit B – G, K,L,M,N. Sec 25 Unit B – G, J,K,L. Sec 26 – Sec 34. Sec 35 Unit C,D,E.

T 24S – R 29E

Sec 2 Unit A, B, C, D. Sec 3 Unit A

T 24S - R 30E

Sec 1 Unit A – H, J – N. Sec 2, Sec 3. Sec 4 Unit A,B,F – K, M,N,O,P. Sec 9 Unit A – L. Sec 10 Unit A – L, O,P. Sec 11. Sec 12 Unit D,E,L. Sec 14 Unit B – G. Sec 15 Unit A,B,G,H.

T 24S - R 31E

Sec 3 Unit B – G, J – O. Sec 4. Sec 5 Unit A – L, P. Sec 6 Unit A – L. Sec 9 Unit A – J, O,P. Sec 10 Unit B – G, K – N. Sec 35 Unit E – P. Sec 36 Unit E,K,L,M,N.


T 25S - R 31E

Sec 1 Unit C,D,E,F. Sec 2 Unit A – H.

Proposed Plugging Procedures Asher Enterprises, LTD CO New Mexico B State #1 30-025-27181

- 1. Tag existing CIBP at 8500'. Circulate MLF and test casing to 500#. Spot 25 sx Class H cement on top of CIPB.
- 2. Perforate at 6550' and squeeze with 40 sx Class H cement. WOC and tag.
- 3. Perforate at 4719' and squeeze with 40 sx Class C. WOC and tag. Top Queen
- 4. Perforate at 4450' and squeeze with 40 sx. WOC and tag above 4350'. Intermediate Shoe
- 5. Perforate at 3593' and squeeze with 40 sx. WOC and tag. Base Salt & Top Yates
- 6. Perforate at 2340' and squeeze with 40 sx. WOC and tag. Top Salt
- 7. Perforate at 565'. Check for good communication at intermediate ad surface heads. Squeeze with 75 sx. WOC and tag.
- 8. Perforate at 150'. Circulate cement to surface in/out 5 1/2" x 8 5/8" and 8 5/8" x 13 3/8". Approx. 90 sx
- 9. Remove wellhead and ensure cement is to surface in all strings of casing. Install marker.

Asher Enterprises, LTD Co New Mexico B State #1 API 30-025-27181 Before WBD 13 3/8" 48# casins set @ 515' with 530 sx. Circulated 8 5/8" 24# & 32# casing set at 4400' Cemented w/2025 sx TOC @ 625' TOC @ 6550' CIBP @ 8500' with 2 sx cement on top 10/11/2001 TA'd Perforations 8530' to 8584' CIBP @ 8809' with 30' cement on top CIBP with 36' of cement on top Perforations 13618' to 13635' 5 1/2" 17# &20 casing set at 13391' Cemented w/1500 sx cement TOC @ Surface



District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720 District II

811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720 District III

1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. **Santa Fe, NM 87505**

COMMENTS

Action 220650

COMMENTS

Operator:	OGRID:
ASHER ENTERPRISES LTD. CO.	149538
3904 Magggies Meadow	Action Number:
Denton, TX 76210	220650
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

COMMENTS

Created By	Comment	Comment Date
plmartine	z DATA ENTRY PM.	5/25/2023

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720 District II

811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720 District III

1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. **Santa Fe, NM 87505**

CONDITIONS

Action 220650

CONDITIONS

Operator:	OGRID:
ASHER ENTERPRISES LTD. CO.	149538
3904 Magggies Meadow	Action Number:
Denton, TX 76210	220650
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

CONDITIONS

Created By		Condition Date
kfortner	See attached COA Note change to procedure	5/25/2023