Office St	ate of New Me	xico		Form C-103 <sup>1</sup>			
<u>District I</u> – (575) 393-6161 Energy, M	Energy, Minerals and Natural Resources		Revised July 18, 2013				
1625 N. French Dr., Hobbs, NM 88240 District II – (575) 748-1283	Hobbs, NM 88240		WELL API NO. 30-025-10110				
811 S. First St., Artesia, NM 88210 OIL CON	ISERVATION	5	5. Indicate Type of Lease				
1000 Rio Brazos Rd. Aztec. NM 87410	South St. Fran	icis Dr.	STATE FEE				
<u>District IV</u> – (505) 476-3460	anta Fe, NM 87	$\begin{array}{c c} 505 & 6. \end{array}$	State Oil & Gas Leas	se No.			
1220 S. St. Francis Dr., Santa Fe, NM 87505							
SUNDRY NOTICES AND REPO (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT PROPOSALS.)	JG BACK TO A PR SUCH	Lease Name or Unit GRIZZELL I					
1. Type of Well: Oil Well  Gas Well  Other			Well Number 001				
2. Name of Operator			OGRID Number 33	0447			
CONTANGO RESOURCES, LLC  3. Address of Operator			. Pool name or Wildo	eat			
111 E. 5 <sup>TH</sup> STREET, SUITE 3	00, FORT WORT		INEBRY OIL & GAS (OI				
4. Well Location							
Unit Letter <u>G</u> : <u>1,980</u> feet fro	m the <u>NORTH</u>	[ line and <u>1,980</u>	feet from the	EASTline			
Section 8 Township			County Ll	EA			
· ·		RKB, RT, GR, etc.)					
3,42	7' GR						
12. Check Appropriate Bo	x to Indicate N	ature of Notice, Rep	ort or Other Data				
NOTICE OF INTENTION TO	).	SUBSE	QUENT REPOR	T OF:			
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ REMEDIAL WORK				RING CASING			
TEMPORARILY ABANDON   CHANGE PLAN		COMMENCE DRILLIN	<del></del>	D A 🔲			
PULL OR ALTER CASING MULTIPLE COI	MPL	CASING/CEMENT JC	В				
DOWNHOLE COMMINGLE  CLOSED-LOOP SYSTEM							
OTHER:		OTHER:					
13. Describe proposed or completed operations. of starting any proposed work). SEE RULE	(Clearly state all p	pertinent details, and give. For Multiple Comple	re pertinent dates, included tions: Attach wellboard	luding estimated date re diagram of			
proposed completion or recompletion.							
Description of Procedure:							
1. Notify OCD 24 hours prior to MIRU to P&A.	5.0602 B		· C: 1 · 11	/ , 1 1 1			
2. Tag TOC on CIBP @ +/-5,327'. Set 5" CIBP @ +/-3. Spot 25 sxs Class C cmt @ 4,930' - 5,060' (Sqz'd l				w/ water-based mud.			
4. Pull 5-1/2" tieback string. Run CBL on 7" csg from							
5. Spot 25 sxs Class C cmt @ 3,248' – 3,398' (5" Line		т тос					
6. Spot 25 sxs Class C cmt @ 2,276' – 2,426' (Bottom 7. Spot 55 sxs Class C cmt @ 1,016' – 1,338' (Anhyd:				ITH CONDITION			
8. Circ 60 sxs Class C cmt @ surface – 344'.	ine & Top of San	. WOC. Tag TOC.	- 11	THE CONDITION			
9. Cut off wellhead, verify cmt to surface, weld on dry	hole marker.		annavel) W	III vv.			
			APPROVI				
Notify NMOCD 24 hours							
prior to any work.							
Spud Date: Adhere to NMOCD COAs	Rig Release Da	te:					
attached.							
	1 , , , , 1 1	, C 1 1 1	11 1 0	_			
I hereby certify that the information above is true and complete to the best of my knowledge and belief.							
SIGNATURE	TITLE Re	gulatory Analyst	DATE	7/26/2023			
SIGNATURE	IIILE(O)	<u></u>	DATE				
Type or print name Kristy Polk	_ E-mail address	: kristy.polk@conta	ngo.com PHONE:	918-748-3349			
For State Use Only							
APPROVED BY: John Harrison	TITLE Pet	roleum Specialist	DATE	7/31/23			
Conditions of Approval (if any):			DATE				

# CONDITIONS FOR PLUGGING AND ABANDONMENT

#### OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E) Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - 1) Glorieta
  - J) Yates.
  - K) Cherry Canyon Eddy County
  - L) Potash---(In the R-111-P Area (Page 3 & 4), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

# **DRY HOLE MARKER REQUIRMENTS**

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

# R-111-P Area

#### T 18S - R 30E

Sec 10 Unit P. Sec 11 Unit M,N. Sec 13 Unit L,M,N. Sec 14 Unit C -P. Sec 15 Unit A G,H,I,J,K,N,O,P. Sec 22 Unit All except for M. Sec 23, Sec 24 Unit C,D,E,L, Sec 26 Unit A-G, Sec 27 Unit A,B,C

## T 19S - R 29E

Sec 11 Unit P. Sec 12 Unit H-P. Sec 13. Sec 14 Unit A,B,F-P. Sec 15 Unit P. Sec 22 Unit A,B,C,F,G,H,I,J K,N,O,P. Sec 23. Sec 24. Sec 25 Unit D. Sec 26 Unit A-F. Sec 27 Unit A,B,C,F,G,H.

#### T 19S - R 30E

Sec 2 Unit K,L,M,N. Sec 3 Unit I,L,M,N,O,P. Sec 4 Unit C,D,E,F,G,I-P. Sec 5 Unit A,B,C,E-P. Sec 6 Unit I,O,P. Sec 7 – Sec 10. Sec 11 Unit D, G—P. Sec 12 Unit A,B,E-P. Sec 13 Unit A-O. Sec 14-Sec 18. Sec 19 Unit A-L, P. Sec 20 – Sec 23. Sec 24 Unit C,D,E,F,L,M,N. Sec 25 Unit D. Sec 26 Unit A-G, I-P. Sec 27, Sec 28, Sec 29 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 32 Unit A,B,G,H,I,J,N,O,P. Sec 33. Sec 34. Sec 35. Sec 36 Unit D,E,F,I-P.

## T 19S - R 31E

Sec 7 Unit C,D,E,F,L. Sec 18 Unit C,D,E,F,G,K,L. Sec 31 Unit M. Sec 34 Unit P. Sec 35 Unit M,N,O. Sec 36 Unit O,P.

#### T 20S - R 29E

Sec 1 Unit H,I,P. Sec 13 Unit E,L,M,N. Sec 14 Unit B-P. Sec 15 Unit A,H,I,J,N,O,P. Sec 22 Unit A,B,C,F,G,H,I,J,O,P. Sec 23. Sec 24 Unit C,D,E,F,G,J-P. Sec 25 Unit A-O. Sec 26. Sec 27 Unit A,B,G,H,I,J,O,P. Sec 34 Unit A,B,G,H. Sec 35 Unit A-H. Sec 36 Unit B-G.

## T 20S - R 30E

Sec 1 – Sec 4. Sec 5 Unit A,B,C,E-P. Sec 6 Unit E,G-P. Sec 7 Unit A-H,I,J,O,P. Sec 8 – 17. Sec 18 Unit A,B,G,H,I,J,O,P. Sec 19 Unit A,B,G,H,I,J,O,P. Sec 30 Unit A-L,N,O,P. Sec 31 Unit A,B,G,H,I,P. Sec 32 – Sec 36.

## T 20S - R 31E

Sec 1 Unit A,B,C,E-P. Sec 2. Sec 3 Unit A,B,G,H,I,J,O,P. Sec 6 Unit D,E,F,J-P. Sec 7. Sec 8 Unit E-P. Sec 9 Unit E,F,J-P. Sec 10 Unit A,B,G-P. Sec 11 – Sec 36.

## T 21S - R 29E

Sec 1 – Sec 3. Sec 4 Unit L1 – L16,I,J,K,O,P. Sec 5 Unit L1. Sec 10 Unit A,B,H,P. Sec 11 – Sec 14. Sec 15 Unit A,H,I. Sec 23 Unit A,B. Sec 24 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 25 Unit A,O,P. Sec 35 Unit G,H,I,J,K,N,O,P. Sec 36 A,B,C,F – P.

## T 21S - R 30E

Sec 1 – Sec 36

# T 21S - R 31E

Sec 1 – Sec 36

# T 22S - R 28E

Sec 36 Unit A,H,I,P.

#### T 22S - R 29E

Sec 1. Sec2. Sec 3 Unit I,J,N,O,P. Sec 9 Unit G – P. Sec 10 – Sec 16. Sec 19 Unit H,I,J. Sec 20 – Sec 28. Sec 29 Unit A,B,C,D,G,H,I,J,O,P. Sec 30 Unit A. Section 31 Unit C – P. Sec 32 – Sec 36

## T 22S - R 30E

Sec 1 – Sec 36

## T 22S - R 31E

Sec 1 – Sec 11. Sec 12 Unit B,C,D,E,F,L. Sec 13 Unit E,F,K,L,M,N. Sec 14 – Sec 23. Sec 24 Unit C,D,E,F,K,L,M,N. Sec 25 Unit A,B,C,D. Sec 26 Unit A,BC,D,G,H. Sec 27 – Sec 34.

## T 23S - R 28E

Sec 1 Unit A

## T 23S - R 29E

Sec 1 – Sec 5. Sec 6 Unit A – I, N,O,P. Sec 7 Unit A,B,C,G,H,I,P. Sec 8 Unit A – L, N,O,P. Sec 9 – Sec 16. Sec 17 Unit A,B,G,H,I,P. Sec 21 – Sec 23. Sec 24 Unit A – N. Sec 25 Unit D,E,L. Sec 26. Sec 27. Sec 28 Unit A – J, N,O,P. Sec 33 Unit A,B,C. Sec 34 Unit A,B,C,D,F,G,H. Sec 35. Sec 36 Unit B,C,D,E,F,G,K,L.

#### T 23S - R 30E

Sec 1 – Sec 18. Sec 19 Unit A – I,N,O,P. Sec 20, Sec 21. Sec 22 Unit A – N, P. Sec 23, Sec 24, Sec 25. Sec 26 Unit A,B,F-P. Sec 27 Unit C,D,E,I,N,O,P. Sec 28 Unit A – H, K,L,M,N. Sec 29 Unit A – J, O,P. Sec 30 Unit A,B. Sec 32 A,B. Sec 33 Unit C,D,H,I,O,P. Sec 34, Sec 35, Sec 36.

## T 23S - R 31E

Sec 2 Unit D,E,J,O. Sec 3 – Sec 7. Sec 8 Unit A – G, K – N. Sec 9 Unit A,B,C,D. Sec 10 Unit D,P. Sec 11 Unit G,H,I,J,M,N,O,P. Sec 12 Unit E,L,K,M,N. Sec 13 Unit C,D,E,F,G,J,K,L,M,N,O. Sec 14. Sec 15 Unit A,B,E – P. Sec 16 Unit I, K – P. Sec 17 Unit B,C,D,E, I – P. Sec 18 – Sec 23. Sec 24 Unit B – G, K,L,M,N. Sec 25 Unit B – G, J,K,L. Sec 26 – Sec 34. Sec 35 Unit C,D,E.

## T 24S – R 29E

Sec 2 Unit A, B, C, D. Sec 3 Unit A

### T 24S - R 30E

Sec 1 Unit A – H, J – N. Sec 2, Sec 3. Sec 4 Unit A,B,F – K, M,N,O,P. Sec 9 Unit A – L. Sec 10 Unit A – L, O,P. Sec 11. Sec 12 Unit D,E,L. Sec 14 Unit B – G. Sec 15 Unit A,B,G,H.

#### T 24S - R 31E

Sec 3 Unit B – G, J – O. Sec 4. Sec 5 Unit A – L, P. Sec 6 Unit A – L. Sec 9 Unit A – J, O,P. Sec 10 Unit B – G, K – N. Sec 35 Unit E – P. Sec 36 Unit E,K,L,M,N.

# T 25S - R 31E


Sec 1 Unit C,D,E,F. Sec 2 Unit A – H.


Plugging Plan
Grizzell B 1
30-025-10110
Contango Resources Inc. OGRID 330447

Notify OCD 24 hours prior to MIRU to P&A.

# Description of Procedure:

- 1. Notify OCD 24 hours prior to MIRU to P&A.
- 2. Tag TOC on CIBP @ +/-5,327'. Set 5" CIBP @ +/-5,060'. Pressure test csg to 500 psi for 30 mins. Circulate well w/ water-based mud.
- 3. Spot 25 sxs Class C cmt @ 4,930' 5,060' (Sqz'd Blinebry Perfs & Glorieta). WOC. Tag TOC.
- 4. Pull 5-1/2" tieback string. Run CBL on 7" csg from 3,348' to surface.
- 5. Spot 25 sxs Class C cmt @ 3,248' 3,398' (5" Liner Top).
- 6. Spot 25 sxs Class C cmt @ 2,276' 2,426' (Bottom of Salt). WOC. Tag TOC.
- 7. Spot 55 sxs Class C cmt @ 1,016' 1,338' (Anhydrite & Top of Salt). WOC. Tag TOC.
- 8. Circ 60 sxs Class C cmt @ surface 344'.
- 9. Cut off wellhead, verify cmt to surface, weld on dry hole marker.





District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

CONDITIONS

Action 245062

# **CONDITIONS**

Operator:	OGRID:
Contango Resources, LLC	330447
111 E. 5TH STREET	Action Number:
FORT WORTH, TX 76102	245062
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### CONDITIONS

Created	d By	Condition	Condition Date
john.h	harrison	Approved w/ conditions. Adhere to NMOCD COAs attached.	7/31/2023