Sundry Print Report

U.S. Department of the Interior BUREAU OF LAND MANAGEMENT

Well Name: E J GARNER COM Well Location: T21S / R27E / SEC 26 / County or Parish/State: EDDY /

SESE / 32.4455779 / -104.1549034

Well Number: 1 Type of Well: CONVENTIONAL GAS Allottee or Tribe Name:

WELL

Lease Number: FEE **Unit or CA Name:** E J GARNER COM **Unit or CA Number:**

NMNM72080

COMPANY

Notice of Intent

Sundry ID: 2864390

Type of Submission: Notice of Intent

Type of Action: Plug and Abandonment

Date Sundry Submitted: 07/21/2025 Time Sundry Submitted: 12:36

Date proposed operation will begin: 07/30/2025

Procedure Description: Matador is requesting to plug and abandon the E J Garner Com #001 per the required COA, following the procedure below: Notify BLM 24 hrs before MIRU. Safety mtg, MIRU, check pressures, ND wellhead, NU & test BOPs, TIH and retrive RBP. Run bit and scrapter to 11400'. Spot cement from 10663' to 10148'. WOC and Tag. 64 sxs Class H. Circulate wellbore full of MLF; Pressure Test casing to 500psi for 30 minutes & Bubble Test; Spot 25 sks class H cmt (Open Wolfcamp Perfs) (Est. 9,174') WOC & Tag. 6,200': Spot a 40 sks class C cmt balanced plug (Est. 5,795' / Req. 6038') (TOC) WOC & Tag 5,432': Perf & squeeze 55 sks class C cmt plug (Est. 5,209' / Req. 5,278') (Bone Springs) WOC & Tag. 4,450': Perf & squeeze 44 sks class C cmt plug (Est. 4,227' / Req. 4,350') (Brushy Canyon) WOC & Tag. 3,077': Perf & squeeze 170 sks class C cmt plug (Est. 2,419' / Req. 2,528')(Cherry Canyon, Intermediate Shoe, & Bell Canyon) WOC & Tag. 1,153' Perf & circulate 283 sks class C cmt to surface. Cut off wellhead and verify cmt to surface on all csg strings. Install dry hole marker per NMOCD specifications. *Current and proposed wellbore diagrams attached **Mud laden fluid (MLF) mixed at 25sks/100 bbls water will be spotted between each plug

Surface Disturbance

Is any additional surface disturbance proposed?: No

APPROVAL SUBJECT TO
GENERAL REQUIREMENTS AND
SPECIAL STIPULATIONS
ATTACHED

NOI Attachments

Procedure Description

Combined_20250721123638.pdf

eceived by OCD: 8/5/2025 8:26:43 AM Well Name: E J GARNER COM

Well Location: T21S / R27E / SEC 26 /

SESE / 32.4455779 / -104.1549034

County or Parish/State: Page 2 of

NM

Well Number: 1

Type of Well: CONVENTIONAL GAS

WELL

Allottee or Tribe Name:

Lease Number: FEE

Unit or CA Name: E J GARNER COM

Unit or CA Number: NMNM72080

US Well Number: 3001522722

Operator: MATADOR PRODUCTION

COMPANY

Operator

I certify that the foregoing is true and correct. Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction. Electronic submission of Sundry Notices through this system satisfies regulations requiring a

Operator Electronic Signature: BRETT JENNINGS Signed on: JUL 21, 2025 12:36 PM

Name: MATADOR PRODUCTION COMPANY

Title: Regulatory Analyst

Street Address: 5400 LBJ FREEWAY STE 1500

City: DALLAS State: TX

Phone: (972) 629-2160

Email address: BRETT.JENNINGS@MATADORRESOURCES.COM

Field

Representative Name:

Street Address:

City: State: Zip:

Phone:

Email address:

APPROVED by Long Vo Petroleum Engineer Carlsbad Field Office 575-988-50402 LVO@BLM.GOV

Lea County Notification: 575-689-5981

Eddy County Notification: BLM NM CFO PluggingNotifications@BLM.GOV

Secondary Contact: 575-361-2822

Form 3160-5 (June 2019)

UNITED STATES DEPARTMENT OF THE INTERIOR

FORM APPROVED
OMB No. 1004-0137
Expires: October 31, 202

BUR	EAU OF LAND MANAC	GEMENT		5. Lease Serial No.	
Do not use this t	OTICES AND REPOR form for proposals to C Use Form 3160-3 (APL	drill or to re-	enter an	6. If Indian, Allottee or Trib	e Name
SUBMIT IN	TRIPLICATE - Other instructi	ons on page 2		7. If Unit of CA/Agreement	, Name and/or No.
I. Type of Well Gas W	Vell Other			8. Well Name and No.	
2. Name of Operator				9. API Well No.	
3a. Address	3b	. Phone No. (inclu	de area code)	10. Field and Pool or Explo	ratory Area
4. Location of Well (Footage, Sec., T., K	.,M., or Survey Description)			11. Country or Parish, State	
12. CHE	CK THE APPROPRIATE BOX	(ES) TO INDICA	 ΓΕ NATURE (OF NOTICE, REPORT OR O	THER DATA
TYPE OF SUBMISSION			TYPE	E OF ACTION	
Notice of Intent	Acidize	Deepen		Production (Start/Resume	e) Water Shut-Off
Trouce of Intent	Alter Casing	Hydraulic 1	Fracturing [Reclamation	Well Integrity
Subsequent Report	Casing Repair	New Const	ruction [Recomplete	Other
	Change Plans	Plug and A	bandon [Temporarily Abandon	
Final Abandonment Notice	Convert to Injection	Plug Back	[Water Disposal	
is ready for final inspection.)	See Attack		lure		
4. I hereby certify that the foregoing is	true and correct. Name (Printe				
		Title			
Signature		Date	:		
	THE SPACE F	OR FEDERA	L OR STA	TE OFICE USE	
Approved by Long Vo	2		Title Petr	roleum Engineer	8-4-2025 Date
Conditions of approval, if any, are attackertify that the applicant holds legal or earlich would entitle the applicant to con	equitable title to those rights in t		Office Ca	arlsbad Field Office	

Title 18 U.S.C Section 1001 and Title 43 U.S.C Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)

GENERAL INSTRUCTIONS

This form is designed for submitting proposals to perform certain well operations and reports of such operations when completed as indicated on Federal and Indian lands pursuant to applicable Federal law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local area or regional procedures and practices, are either shown below, will be issued by or may be obtained from the local Federal office.

SPECIFIC INSTRUCTIONS

Item 4 - Locations on Federal or Indian land should be described in accordance with Federal requirements. Consult the local Federal office for specific instructions.

Item 13: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by the local Federal office. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to the top of any tubing left in the hole; method of closing top of well and date well site conditioned for final inspection looking for approval of the abandonment. If the proposal will involve **hydraulic fracturing operations**, you must comply with 43 CFR 3162.3-3, including providing information about the protection of usable water. Operators should provide the best available information about all formations containing water and their depths. This information could include data and interpretation of resistivity logs run on nearby wells. Information may also be obtained from state or tribal regulatory agencies and from local BLM offices.

NOTICES

The privacy Act of 1974 and the regulation in 43 CFR 2.48(d) provide that you be furnished the following information in connection with information required by this application.

AUTHORITY: 30 U.S.C. 181 et seq., 351 et seq., 25 U.S.C. 396; 43 CFR 3160.

PRINCIPAL PURPOSE: The information is used to: (1) Evaluate, when appropriate, approve applications, and report completion of subsequent well operations, on a Federal or Indian lease; and (2) document for administrative use, information for the management, disposal and use of National Resource lands and resources, such as: (a) evaluating the equipment and procedures to be used during a proposed subsequent well operation and reviewing the completed well operations for compliance with the approved plan; (b) requesting and granting approval to perform those actions covered by 43 CFR 3162.3-2, 3162.3-3, and 3162.3-4; (c) reporting the beginning or resumption of production, as required by 43 CFR 3162.4-1(c)and (d) analyzing future applications to drill or modify operations in light of data obtained and methods used.

ROUTINE USES: Information from the record and/or the record will be transferred to appropriate Federal, State, local or foreign agencies, when relevant to civil, criminal or regulatory investigations or prosecutions in connection with congressional inquiries or to consumer reporting agencies to facilitate collection of debts owed the Government.

EFFECT OF NOT PROVIDING THE INFORMATION: Filing of this notice and report and disclosure of the information is mandatory for those subsequent well operations specified in 43 CFR 3162.3-2, 3162.3-3, 3162.3-4.

The Paperwork Reduction Act of 1995 requires us to inform you that:

The BLM collects this information to evaluate proposed and/or completed subsequent well operations on Federal or Indian oil and gas leases.

Response to this request is mandatory.

The BLM would like you to know that you do not have to respond to this or any other Federal agency-sponsored information collection unless it displays a currently valid OMB control number.

BURDEN HOURS STATEMENT: Public reporting burden for this form is estimated to average 8 hours per response, including the time for reviewing instructions, gathering and maintaining data, and completing and reviewing the form. Direct comments regarding the burden estimate or any other aspect of this form to U.S. Department of the Interior, Bureau of Land Management (1004-0137), Bureau Information Collection Clearance Officer (WO-630), 1849 C St., N.W., Mail Stop 401 LS, Washington, D.C. 20240

(Form 3160-5, page 2)

Additional Information

Additional Remarks

Install dry hole marker per NMOCD specifications.

- *Current and proposed wellbore diagrams attached
- **Mud laden fluid (MLF) mixed at 25sks/100 bbls water will be spotted between each plug

Location of Well


 $0. \ SHL: \ SESE \ / \ 660 \ FSL \ / \ 990 \ FEL \ / \ TWSP: \ 21S \ / \ RANGE: \ 27E \ / \ SECTION: \ 26 \ / \ LAT: \ 32.4455779 \ / \ LONG: \ -104.1549034 \ (\ TVD: \ 0 \ feet, \ MD: \ 0 \ feet \)$ $BHL: \ SESE \ / \ 660 \ FSL \ / \ 990 \ FEL \ / \ TWSP: \ 21S \ / \ SECTION: \ / \ LAT: \ 0.0 \ / \ LONG: \ 0.0 \ (\ TVD: \ 0 \ feet, \ MD: \ 0 \ feet \)$

Received by OCD: 8/5/2025 8:26:43 AM

Medium Karst, 350'

EJ Garner Com #001 660' FSL & 990' FEL Sec. 26-T21S-R27E Eddy County, NM API: 3001522722

CURRENT WELLBORE SCHEMATIC Spudded: 12/7/1978



	Casing Information					
	Hole Size	Casing Size	Туре	Weight (lb/ft)	Joints	Depth Set
Surface	17-1/2"	13-3/8"		48#		450
Intermediate	11"	8-5/8"	K-55	24#		2,605
Production	7-7/8"	5-1/2"	N-80	17#		11,800
DV Tool	•	•	•			

	Cementing Record			
	Туре	TOC	Date Run	
Surface	800 sks x 500 sks x 650 sks Cl C	Surface	12/7/1978	
Intermediate	300 sks RFC x 900 sks x 200 sks Cl C	Surface	12/14/1997	
Production	1250 sks Cl H	5965	1/19/1979	CBL Ran 3/3/25

	Tubing Information	
Item	Notes	Depth
Tubing Anchor	Baker Retreiva "D"	9,608'
Plug Back Total Depth	PBTD	11,346'

Geologic Markers				
Rustler	225			
Base of Salt	965			
Capitan	1,103			
Bell Canyon	2,588			
Cherry Canyon	3,027			
Brushy Canyon	4,400			
Bone Spring	5,382			
Wolf Camp	9,703			
Strawn	10,303			
Atoka	10,750			

	Perforation Information	
Date	Formation	Depth
2/18/1979	Lower Morrow	(11,697'-11,740')
2/21/1979	Middle Morrow	(11,471'-11,616')
11/11/1983	Wolf Camp perfs	(9711'-9775')

	Plugging Information	
Date	Туре	Depth
2/18/1979	Baker "FB" PKR W/DR PIUG	(11,640')
2/21/1979	Baker "FB" PKR W/DR PIUG	(11,400')
11/11/1983	Baker Retrieva "D"	(9,608')

Received by OCD: 8/5/2025 8:26:43 AM Page 7 of 16



CURRENT WELLBORE SCHEMATIC Spudded: 12/7/1978

170 sks class C cmt


55 sks class C cmt

55 sks class C cmt

40 sks class C cmt

25 sks class H cmt

TD: 11,800 PBTD: 9580



Casing Information Hole Size Weight (lb/ft) Joints Depth Set Casing Size Type Surface 17-1/2" 13-3/8" 48# 450 11" 24# Intermediate 8-5/8" K-55 2,605 Production 7-7/8" 5-1/2" N-80 17# 11,800 DV Tool

	Cementing Record			_
	Туре	TOC	Date Run	
Surface	800 sks x 500 sks x 650 sks Cl C	Surface	12/7/1978	
Intermediate	300 sks RFC x 900 sks x 200 sks Cl C	Surface	12/14/1997	
	1250 sks Cl H	5965	1/19/1979	CBL Ran 3/3/25

Geologic Markers				
Rustler	225			
Base of Salt	965			
Capitan	1,103			
Bell Canyon	2,588			
Cherry Canyon	3,027			
Brushy Canyon	4,400			
Bone Spring	5,382			
Wolf Camp	9,703			
Strawn	10,303			
Atoka	10,750			

Capitan	1,103
Bell Canyon	2,588
Cherry Canyon	3,027
Brushy Canyon	4,400
Bone Spring	5,382
Wolf Camp	9,703
Strawn	10,303
Atoka	10,750

	Perforation Information	
	Formation	Depth
2/18/1979	Lower Morrow	(11,697'-11,740')
2/21/1979	Middle Morrow	(11,471'-11,616')
11/11/1983	Wolf Camp perfs	(9711'-9775')

Dat⊭	Plugging Information	
	Туре	Depth
2/18/1979	Baker "FB" PKR W/DR PIUG	(11,640')
2/21/1979	Baker "FB" PKR W/DR PIUG	(11,400')
11/11/1983	Baker Retrieva "D"	(9,608')

4,450': Perf and Squeeze.

Min (In 55 sxs/Out 74 sxs)

Squeeze 55 sks class C cmt (Est. 4,227' / Req. 4,350') (Brushy Canyon) WOC & Tag

5,432': Perf and Squeeze.

Squeeze 55 sks class C cmt (Est. 5,209' / Req. 5,278') (Bone Springs) WOC & Tag Min (In 16 sxs/Out 21 sxs)

Squeeze 170 sks class C cmt (Est. 2,419' / Req. 2,528') (Cherry Canyon, Intermediate Shoe, & Bell Canyon) WOC & Tag

6,200': Spot a 40 sks class C cmt balanced plug (Est. 5,795' / Req. 6038') (TOC) WOC & Tag

9,661': Set CIBP at 9661'. Circulate wellbore full of MLF; Pressure Test casing to 500psi for 30 minutes & Bubble Test; Run RCBL to surface; Spot 25 sks class H cmt (Open Wolfcamp Perfs) (Est. 9,174') WOC & Tag##

2/28/2025	Baker Retrieva D wo Seals	9,585' WLM	
11/11/1983	Baker Retrieva "D"	(9,608')	
11/11/1983	Wolf Camp perfs	(9711'-9775')	
			TIH and retri
			sxs class H. (
2/24/4070	D - 1 ED DVD 14/DD DU16	(4.4.4001)	

rieve RBP. Run bit and scraper to 11400'. Spot cement from 10663' to 10148'. WOC and Tag. 64 (Atoka and Strawn)

2/21/1979	Baker "FB" PKR W/DR PlUG	(11,400')
2/21/1979	Middle Morrow	(11,471' 11,616')
2/18/1979	Baker "FB" PKR W/DR PIUG	(11,640')
2/18/1979	Lower Morrow	(11,697' 11,740')

REVISED 1:00 pm, Aug 04, 2025

Released to Imaging: 8/8/2025 1:27:22 PM

TOC:

TOC: 13-3/8"

8-5/8"

TOC: 5,965' per CBL 3/3/2025

*Run CBL from CIBP to surface.

11,800

Submit results to BLM.

5-1/2"

Outside of Lesser Prairie Chicken Area

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

Notification: Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Lea County, call 575-689-5981. Eddy County, please email notifications to: BLM NM CFO PluggingNotifications@BLM.GOV. The Eddy County inspector on call phone, 575-361-2822, will remain active as a secondary contact.

<u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.

<u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of water. Minimum nine (9) pounds per gallon.

Cement Requirement: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours for Class C or accelerated cement (calcium chloride) and 6 hours for Class H. Tagging the plug means running in the hole with a string of tubing or drill pipe and placing sufficient weight on the plug to ensure its integrity. Other methods of tagging the plug may be approved by the BLM authorized officer or BLM field representative.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. **Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.**

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

Fluid used to mix the cement in R111Q shall be saturated with the salts common to the section penetrated, and in suitable proportions but not less than 1% and not more than 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible.

Above Ground Level Marker: If outside of Lesser Prairie-Chicken Habitat an above ground level marker shall be utilized. All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified BY PHONE (numbers listed in 2. Notifications) a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within fourteen (14) calendar days of the well being plugged. If the cut off cannot be done by the 14th day, the BLM is to be contacted with justification to receive an extension for completing the cut off.

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds). A weep hole shall be left if a metal plate is welded in place.

Below Ground Level Marker: If within Lesser Prairie-Chicken Habitat a below ground level marker shall be utilized. All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified BY PHONE (numbers listed in 2. Notifications) a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within fourteen (14) calendar days of the well being plugged. If the cut off cannot be done by the 14th day, the BLM is to be contacted with justification to receive an extension for completing the cut off. Upon the plugging and subsequent abandonment of wells that are located in lesser prairie-chicken habitat, the casings shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The well bore shall then be covered with a metal plate at least ½ inch thick and welded in place. A weep hole shall be left in the plate and/or casing. The following information shall be permanently inscribed on the plate: well name and number, name of operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

NMOCD also requires the operator to notify NMOCD when this type of dry hole marker is used. This can be done on the subsequent report of abandonment which is submitted to the BLM after the well is plugged. State that a below ground cap was installed as required in the COA's from the BLM.

Operator to verify the ground marker type with the BLM before setting dry hole Marker.

<u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file via the AFMSS 2 WISx Module a Subsequent Report of Plugging and Abandonment to BLM. Please include the following information:

- -The report should give in detail the manner in which the plugging work was carried out, the Extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left In the well.
- -The final copy of CBL.
- -Any email correspondence regarding changes to originally approved procedure.
- -Show date well was plugged.

<u>Trash</u>: All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation objectives.

Timing Limitation Stipulation/ Condition of Approval for Lesser Prairie-Chicken:

From March 1st through June 15th annually, abandonment activities will be allowed except between the hours from 3:00 am and 9:00 am. Normal vehicle use on existing roads will not be restricted.



United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office 620 E. Greene St. Carlsbad, New Mexico 88220-6292 www.blm.gov/nm



In Reply Refer To: 1310

Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its pre-disturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any/all contaminants, scrap/trash, equipment, pipelines and powerlines (Contact service companies, allowing plenty of time to have the risers and power lines and poles removed prior to reclamation, don't wait till the last day and try to get them to remove infrastructure). Strip and remove caliche, contour the location to blend with the surrounding landscape, re-distribute the native soils, provide erosion control as needed, rip (across the slope and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No.

For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.

The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.

Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and

Released to Imaging: 8/8/2025 1:27:22 PM

access road prior to the removal of reclamation equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.

The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.

It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.

At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Jim Amos Supervisory Petroleum Engineering Tech/Environmental Protection Specialist 575-234-5909 (Office), 575-361-2648 (Cell)

Arthur Arias Environmental Protection Specialist 575-234-6230

Crisha Morgan Environmental Protection Specialist 575-234-5987

Jose Martinez-Colon Environmental Protection Specialist 575-234-5951

Angela Mohle Environmental Protection Specialist 575-234-9226

Robert Duenas Environmental Protection Specialist 575-234-2229

Terry Gregston Environmental Protection/HAZMAT Specialist 575-234-5958

Sundry ID	2864390						
Plug Type	Тор	Bottom	Length	Tag	Sacks	Cement Class	Notes
Surface Plug	0.00		100.00	Tag/Verify			
Fresh Water @ 350	296.50						
Top of Salt @ 450 13.375 inch- Shoe Plug	395.50 395.50		104.50	Tag/Verify Tag/Verify			
Base of Salt @ 670	613.30			Tag/Verify			
Yates @ 945	885.55		109.45	If solid			
				If solid base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no			Perf and circulate from 1153' to
				Open			surface. Verify at
				Perforatio			surface. (In 114
Capitan Reef @ 1068 8.625 inch- Shoe Plug	1007.32 2528.95			ns Tag/Verify	283.00	С	sxs/Out 169 sxs)
Delayara © 2045	2720.05	2005 00		If solid base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio	120.00		Perf and squeeze from 3077' to 2528'. WOC and Tag. (In
Delaware @ 2815	2736.85	2865.00	128.15	ns	129.00	С	55 sxs/Out 74 sxs)
				If solid base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio			Perf and squeeze from 5432' to 5278'. WOC and Tag. (In
Bonesprings @ 5382	5278.18	5432.00			37.00	С	16 sxs/Out 21 sxs)
						•	

Spacer Plug @ 5150 6038.50 6038.50 6038.50 6030.00 6038.50 6030.50 603			1					1
Spacer Plug @ 6150 638.50 638.50 6300.00 161.50 Tag 40.00 C WOC and Tag. Wolf base no need to need to Tag. Reprint Test, if Ferrioratio Reprint T								Spot cement from
If solid base no need to Tag								
base no need to Tag C(IBP present and/or Mechanic M	Spacer Plug @ 6150	6038.50	6200.00	161.50	Tag	40.00	С	WOC and Tag.
base no need to Tag C(IBP present and/or Mechanic M								
base no need to Tag C(IBP present and/or Mechanic M								
need to Tag (CIBP present and/for Mechanic al Integrity Test.); If Feat & Garden								
Tag (CIBP present and/or Mechanic at Integrity Test), if Perf & Sign then Tag, Leak Test all CIBP if no Open Protection Described base no need to Tag (CIBP present and/or Mechanic at Integrity Test), if Perf & Sign then Tag, Leak Test all CIBP if no Open Protection Described base no need to Tag (CIBP present and/or Mechanic at Integrity Test), if Perf & Sign then Tag, Leak Test all CIBP in Copen Trag (CIBP present and/or Mechanic at Integrity Test), if Perf & Sign then Tag, Leak Test all CIBP and Sign then Tag, Leak Test all CIBP in Open Copen Mechanic at Integrity Test), if Perf & Sign then Tag, Leak Test all CIBP in Open Copen Mechanic at Integrity Test), if Perf & Sign then Tag, Leak Test all CIBP in Open Copen Mechanic at Integrity Test), if Perf & Sign then Tag, Leak Test all CIBP in Open Copen Mechanic at Integrity Test), if Perf & Sign then Tag, Leak Test all CIBP in Open Copen Mechanic at Integrity Test, if Perf & Sign then Test at CIBP in Open Copen Mechanic at Integrity Test, if Perf & Sign then Test at CIBP in Open Copen Mechanic at Integrity Test, if Perf & Sign then Test at CIBP in Open Copen								
CIBP Present and/or Mechanic al Integrity Test), If Perf & Sagt then Tag, Leak Test all CIBP if no Open Perforatio Depen								
Description								
Moderatic Mode					`			
Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open O								
A Integrity Test), If Perf & Sig. then Test all CiBP Fro Open Perforatio								
Test), If Perf & Sigt then Tegt, Leak Test all CiBP fino Open Perforatio Perfora								
Perf & Sig then Tag, Leak Test all CISP if no Open Perforatio								
Wolfcamp @ 8943 8803.57 8963.00 189.43 ns								
Molfcamp @ 8943 8803.67 8993.00 189.43								
Test all CIBP if no Open Perforatio Set CIBP at 980 Set CIBP								
Wolfcamp @ 8943 8803.57 8993.00 189.43 185								
Wolfcamp @ 8943 8803.57 8993.00 189.43 ns								
Wolfcamp @ 8943 8803.57 8993.00 189.43 rs								
Set CIBP at 9661: CIBP Plug								
If solid base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio Strawn @ 10302 10148.98 10352.00 203.02 If solid base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP and Spot 25 sxs on top. Set CIBP at 9661'. Leak test CIBP and spot 25 sxs on top.								
Dase no need to Tag (CIBP present and/or Mechanic al Integrity Test), if Perf & Sqz then Tag (CIBP present and/or Mechanic al Integrity Test all cIBP if no Open Perforatio Dase no need to Tag (CIBP present and/or Mechanic al Integrity Test), if Perf & Sqz then Tag, Leak Test all cIBP if no Open Perforatio Dase no need to Tag (CIBP present and/or Mechanic al Integrity Test), if Perf & Sqz then Tag, Leak Test all cIBP if no Open Perforatio Dase no need to Tag (CIBP present and/or Mechanic al Integrity Test), if Perf & Sqz then Tag, Leak Test all cIBP if no Open Squ then Tag, Leak Test all CIBP if no Scraper to 11400. Spot cement from 10663' to 10148. Morrow @ 11330 1130.00 2013.31 is Squ the Open Squ the Norrow @ 11330 1130.00 2133.30 if solid	Wolfcamp @ 8943	8803.57	8993.00	189.43	ns			
Dase no need to Tag (CIBP present and/or Mechanic al Integrity Test), if Perf & Sqz then Tag (CIBP present and/or Mechanic al Integrity Test all cIBP if no Open Perforatio Dase no need to Tag (CIBP present and/or Mechanic al Integrity Test), if Perf & Sqz then Tag, Leak Test all cIBP if no Open Perforatio Dase no need to Tag (CIBP present and/or Mechanic al Integrity Test), if Perf & Sqz then Tag, Leak Test all cIBP if no Open Perforatio Dase no need to Tag (CIBP present and/or Mechanic al Integrity Test), if Perf & Sqz then Tag, Leak Test all cIBP if no Open Squ then Tag, Leak Test all CIBP if no Scraper to 11400. Spot cement from 10663' to 10148. Morrow @ 11330 1130.00 2013.31 is Squ the Open Squ the Norrow @ 11330 1130.00 2133.30 if solid								
Dase no need to Tag (CIBP present and/or Mechanic al Integrity Test), if Perf & Sqz then Tag (CIBP present and/or Mechanic al Integrity Test all cIBP if no Open Perforatio Dase no need to Tag (CIBP present and/or Mechanic al Integrity Test), if Perf & Sqz then Tag, Leak Test all cIBP if no Open Perforatio Dase no need to Tag (CIBP present and/or Mechanic al Integrity Test), if Perf & Sqz then Tag, Leak Test all cIBP if no Open Perforatio Dase no need to Tag (CIBP present and/or Mechanic al Integrity Test), if Perf & Sqz then Tag, Leak Test all cIBP if no Open Squ then Tag, Leak Test all CIBP if no Scraper to 11400. Spot cement from 10663' to 10148. Morrow @ 11330 1130.00 2013.31 is Squ the Open Squ the Norrow @ 11330 1130.00 2133.30 if solid					lf a a li -l			
CIBP Plug 9626.00 9661.00 35.00 system Set CIBP at 9661. Leak test CIBP at 9661.								
Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP in Open Perforatio Dase no need to Tag (CIBP present and/or Mechanic al Integrity Test). If Perf & Sqz then Tag, Leak Test all CIBP and Spot 25 sxs on top. CIBP Plug								
CIBP present and/or Mechanic al Integrity Test), If Perf & Set CIBP at 9661. CIBP Plug								
Dispension Dis								
Set CIBP at 9661*. Set CIBP at 9661*. Set CIBP at 9661*. CIBP Plug					,			
Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio Date in the performance of the								
All Integrity Test), if Perf & Sqz then Tag, Leak Test all CIBP Plug 9626.00 9661.00 35.00 ns 25.00 H spot 25 sxs on top. CIBP Plug 9626.00 9661.00 35.00 ns 25.00 H spot 25 sxs on top. Set CIBP at 9661'. Leak test CIBP and spot 25 sxs on top.								
Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio								
Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio Department Departm								
Sqz then Tag, Leak Test all CIBP if no Open Perforatio Leak test CIBP at 9661*.								
Tag, Leak Test all CIBP if no Open Perforatio Perforatio Perforatio Perforatio Perforatio Den Set CIBP and Spot 25 sxs on top. Strawn @ 10302 10148.98 10352.00 203.02 If solid If solid base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio Den Green to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio Den Green to 11400'. Spot cement from Perforatio Perforatio 10663' to 10148'. WOC and Tag. Atoka @ 10613 10456.87 10663.00 206.13 ns 64.00 H WOC and Tag.								
Test all CIBP if no Open Perforatio Set CIBP at 9661'. Leak test CIBP and spot 25 sxs on top.								
CIBP Plug 9626.00 9661.00 35.00 lns 25.00 H spot 25 sxs on top. Set CIBP at 9661. Leak test CIBP and spot 25 sxs on top. Strawn @ 10302 10148.98 10352.00 203.02 If solid base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio CIBP if no Open Atoka @ 10613 10456.87 10663.00 206.13 lns 64.00 H WOC and Tag. Morrow @ 11330								
CIBP Plug 9626.00 9661.00 35.00 ns 25.00 H spot 25 sxs on top. Strawn @ 10302 10148.98 10352.00 203.02 If solid If solid base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open RBP. Run bit and Scraper to 11400. Spot 25 sxs on top. Atoka @ 10613 10456.87 10663.00 206.13 In s 64.00 H WOC and Tag. Morrow @ 11330 1500 1 1380.00 213.30 If solid								
CIBP Plug 9626.00 9661.00 35.00 ns 25.00 H spot 25 sxs on top. Strawn @ 10302 10148.98 10352.00 203.02 If solid base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio Open Perforatio 25.00 H spot 25 sxs on top. Leak test CIBP and spot 25 sxs on top.								Set CIRP at 0661'
CIBP Plug 9626.00 9661.00 35.00 ns 25.00 H spot 25 sxs on top. Strawn @ 10302 10148.98 10352.00 203.02 If solid If solid base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio Open Till and retreive RBP. Run bit and scraper to 11400'. Spot cement from 10663' to 10148'. Atoka @ 10613 10456.87 10663.00 206.13 ns 64.00 H WOC and Tag. Morrow @ 11330 11166.70 11380.00 2013.30 If solid If solid WOC and Tag.								
Strawn @ 10302	CIPP Plus	0626.00	0661 00	35.00		25.00	ш	
If solid base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no CIBP if no Open Spot cement from Perforatio Atoka @ 10613			10353.00			25.00	П	spot 25 sxs off top.
base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Scraper to 11400'. Open Perforatio Open Perforatio Atoka @ 10613	3trawii @ 10302	10140.90	10332.00	203.02	ii 30iiu			
base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Scraper to 11400'. Open Perforatio Open Perforatio Atoka @ 10613								
base no need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Scraper to 11400'. Open Perforatio Open Perforatio Atoka @ 10613					If solid			
Need to Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio								
Tag (CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Spot cement from Perforatio Atoka @ 10613								
CIBP present and/or Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all RBP. Run bit and CIBP if no Scraper to 11400'. Open Perforatio Open Perforatio Spot cement from 10663' to 10148'.								
Present and/or Mechanic Mec					(CIBP			
Atoka @ 10613								
Mechanic al Integrity Test), If Perf & Sqz then Tag, Leak Test all RBP. Run bit and CIBP if no Scraper to 11400'. Spot cement from 10663' to 10148'.								
All Integrity Test), If Perf & Sqz then Tag, Leak Test all CIBP if no Open Spot cement from 10663' to 10148'. Atoka @ 10613								
Test), If Perf & Sqz then Tag, Leak TIH and retreive RBP. Run bit and Scraper to 11400'. Open Perforatio Atoka @ 10613								
Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio Perforatio Perf & Sqz then Tag, Leak Test all CIBP if no Open Perforatio Spot cement from 10663' to 10148'.								
Sqz then Tag, Leak Test all CIBP if no Open Perforatio Spot cement from 10663' to 10148'.								
Tag, Leak Test all CIBP if no Open Perforatio Atoka @ 10613 10456.87 10663.00 206.13 ns 64.00 H WOC and Tag. Morrow @ 11330 Tag, Leak Test all CIBP if no Open Perforatio Scraper to 11400'. Spot cement from 10663' to 10148'. WOC and Tag.								
Test all CIBP if no Open Perforatio CIBP if no Open								TIH and retreive
Atoka @ 10613 10456.87 10663.00 206.13 Ins 64.00 H WOC and Tag. Morrow @ 11330 11166.70 11380.00 213.30 If solid If solid								
Atoka @ 10613 10456.87 10663.00 206.13 ns 64.00 H WOC and Tag. Morrow @ 11330 11166.70 11380.00 213.30 If solid If solid								
Atoka @ 10613 10456.87 10663.00 206.13 ns 64.00 H WOC and Tag. Morrow @ 11330 11166.70 11380.00 213.30 If solid								
Atoka @ 10613 10456.87 10663.00 206.13 ns 64.00 H WOC and Tag. Morrow @ 11330 11166.70 11380.00 213.30 If solid H WOC and Tag.					Perforatio			
Morrow @ 11330 11166.70 11380.00 213.30 If solid	Atoka @ 10613	10456.87	10663.00			64.00	Н	
	Morrow @ 11330	11166.70	11380.00	213.30	If solid			
	5.5 inch- Shoe Plug							

No more than 2000' is to be allowed between plugs in open hole, and no more than 3000' between plugs in cased hole. Class H >7500' Class C<7500'

Fluid used to mix the cement in R111P shall be saturated with the salts common to the section penetrated, and in suitable proportions, but not more than 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible.

Medium, Secretary: Top of salt to surface If no salt take the deepest fresh water or Karst Depth

High, Critical: Bottom of Karst to surface or Deepest fresh water, whichever is greater R111P: 50 Feet from Base of Salt to surface.

Class C: 1.32 ft^3/sx Class H: 1.06 ft^3/sx

Onshore Order 2.III.G Drilling Abandonment Requirements: "All formations bearing usable-quality water, oil, gas, or geothermal resources, and/or a prospectively valuable deposit of minerals shall be protected.

CIBP@

9661.00

	Top of S	Salt to surface	
Cave Karst/Potash Cement Requirement:	<u>Medium</u>		
Wild Life	Outside of Lesser	Prairie Chicken A	rea
13.375 inch- Shoe Plug @	450.00		
8.625 inch- Shoe Plug @	2605.00		
5.5 inch- Shoe Plug @	11800.00	TOC @	5965.00
Perforatons Top @	9711.00	Perforations	9794.00

Sante Fe Main Office Phone: (505) 476-3441

General Information Phone: (505) 629-6116

Online Phone Directory https://www.emnrd.nm.gov/ocd/contact-us

State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. Santa Fe, NM 87505

CONDITIONS

Action 492016

CONDITIONS

Operator:	OGRID:
MATADOR PRODUCTION COMPANY	228937
One Lincoln Centre	Action Number:
Dallas, TX 75240 492016	
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

CONDITIONS

Created By	Condition	Condition Date
gcordero	Set CIBP @ 9660' with 35' cement - Test casing 500psi/30min - WOC & Tag - T Wolfcamp perforations	8/8/2025
gcordero	Run CBL from CIBP to surface.	8/8/2025
gcordero	A Cement Bond Log (CBL) is required to be submitted to electronic permitting.	8/8/2025
gcordero	Submit Cement Bond Logs (CBL) prior to submittal of C-103P.	8/8/2025