

Neill and Steffan #3 H-3-26N-24E

Place cement plug 1550 ft to 1500 ft

Fill 5 1/2-inch casing with heavy mud to 600 feet

Cement plug 600' to 500'

Shoot off or perforate casing just above plug, squeeze with 50 sacks cement if perforated and place cement plug 500 feet to 400 feet inside casing

If shot off and casing pulled place cement plug 500' to 400 feet in open hole.

Fill with heavy mud to 50 feet - cement plug to surface and erect regulation marker in surface plug.

