

# Plugging Procedure

Bruce A. Hillman

T-4 Patton Co N7

Sec 18 - 11 - 26

Quadrangle Co -

Set plug from 600' to 712' T.D.

Set plug from 70 to 120'

Set (each plug at surface)

Install Marker