

Submit 3 Copies to Appropriate District Office	State of New Mexico Energy, Minerals, and Natural Resources Department	Form C-103 Revised 1-1-89		
<b>OIL CONSERVATION DIVISION</b>		<b>WELL API NO.</b> 30-021-20074		
DISTRICT I P.O. Box 1980, Hobbs, NM 88240	P.O. Box 2088 Santa Fe, New Mexico 87504-2088	5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>		
DISTRICT II P.O. Drawer DD, Artesia, NM 88210		6. State Oil & Gas Lease No.		
DISTRICT III 1000 Rio Brazos Rd., Aztec, NM 87410		7. Lease Name or Unit Agreement Name  BRAVO DOME CO2 GAS UNIT		
<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		8. Well No.  1831-231G		
1. Type of Well OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER CO2		9. Pool name or Wildcat  BRAVO DOME CO2 GAS UNIT		
2. Name of Operator  AMOCO PRODUCTION COMPANY				
3. Address of Operator  P.O. Box 303, AMISTAD, NEW MEXICO 88410				
4. Well Location Unit Letter <u>G</u> : <u>1980</u> Feet From The <u>North</u> Line and <u>1980</u> Feet From The <u>East</u> Line Section <u>23</u> Township <u>18N</u> Range <u>31E</u> NMPM <u>Harding</u> County				
10. Elevation (Show whether DF, RKB, RT, GR, etc.) <u>4371</u> <u>GR</u>				
11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data <table style="width:100%; border-collapse: collapse;"><tr><td style="width:50%; vertical-align: top; border-right: 1px solid black; padding: 5px;">NOTICE OF INTENTION TO:  PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER: <input type="checkbox"/></td><td style="width:50%; vertical-align: top; padding: 5px;">SUBSEQUENT REPORT OF:  REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input checked="" type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER: <input type="checkbox"/></td></tr></table>			NOTICE OF INTENTION TO:  PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER: <input type="checkbox"/>	SUBSEQUENT REPORT OF:  REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input checked="" type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER: <input type="checkbox"/>
NOTICE OF INTENTION TO:  PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER: <input type="checkbox"/>	SUBSEQUENT REPORT OF:  REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input checked="" type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER: <input type="checkbox"/>			
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. <div style="border: 1px solid black; padding: 10px; margin-top: 10px;"><p>7/9/2000 MIRUSU, kill well with fresh water, NUBOP, release packer, lay down production tubing and packer, run cast iron bridge plug with wireline, set CIBP at 2,151 feet, SDON.</p><p>7/10/2000 Run workstring, tag CIBP at 2,151 feet, displace casing with corrosion inhibited fluid, pressure test casing to 500 psi, cap CIBP with 5 sacks of class C cement from 2151' - 2103', pull workstring to 1,755 feet, spot 10 sacks of cement from 1755' - 1659', pull workstring to 30 feet, fill casing with cement, NDBOP, RDMOSU, cut off wellhead, install PXA marker, cut off well anchors and clean location.</p><p style="text-align: right; font-style: italic;">OK 8/17/00</p></div>				
I hereby certify that the information above is true and complete to the best of my knowledge and belief.				
SIGNATURE <u>DJ Holcomb</u> TITLE <u>Field Foreman</u> DATE <u>7-12-2000</u>				
TYPE OR PRINT NAME <u>Danny J. Holcomb</u> TELEPHONE NO. <u>(505) 374-3010</u>				
APPROVED BY <u>[Signature]</u> TITLE <u>DISTRICT SUPERVISOR</u> DATE <u>8/18/00</u>				
CONDITIONS OF APPROVAL, IF ANY				